

WMS Pro- Operator login using SSO

1 month ago

Updated

- In Active Directory Domain services - group, Delegate control for 'Read all user information'
- The domain users on active directory must have an email address (it uses this email address to match with the WMS Pro login)
- In WMS Pro, go to Administration >Settings >Operator Management and enable LDAP Settings,
Enter the Domain Operator Login and Password, that is a member of this group.

The screenshot shows the WMS Pro Settings page. The left sidebar is a navigation menu with the following items:

- Site maps
- Cardholders
- User access
- History logs
- Reports
- Status & control
- Administration** (highlighted with a red box)
- Controllers
- Devices
- Automations
- External APIs
- Maps
- Regions
- Sites
- Holiday types
- Card programmers
- Reader config cards
- Cardholder admin
- Alarm responses
- Roles
- Operators
- Settings** (highlighted with a red box)

The main content area is titled "Settings" and "Show and change application settings." It has tabs for Appearance, Operator management, Security, Email (SMTP), and Database maintenance. The "Operator management" tab is selected and highlighted with a red box. The "Operator management" tab contains the following sections:

- Session Timeout Control**
 - Session Time Out Control Enabled
 - Show Lock Screen When Timed Out
- Timeout (seconds): 1200
- Countdown Modal Wait Time (Seconds): 30
- LDAP Settings** (highlighted with a red arrow)
 - Enable LDAP authentication.
 - Domain name:
 - Login name:
 - Password:

- Then, Login to WMS Pro as this domain operator (use its email address)
- Domain operator is logged in with the 'User' role and no regions, by default:

The screenshot shows a 'Roles' page with a header 'Use roles to group permissions.' and a 'Filter roles by permissions (0)' button. Below is a table with columns 'Actions' and 'Role name'. It lists two entries:

Actions	Role name
Action buttons for Admin	Admin Static
Action buttons for User, highlighted with a red box	User Static Default

- Domain operator is now visible as an operator in WMS Pro
- Domain operator can now login to WMS Pro with the login name or email address
- If all floating licenses are used, additional AD operators will be unable to login and will not be created in WMS Pro.
- To change the password of an AD operator, this must be changed in Active Directory and then the operator can log in again to WMS Pro with the new password.

Operators logging into WMS Pro using Active Directory (AD) Credentials cannot change/edit their password from WMS Pro Operator Page as it is managed through the domain controller.