



METHOD

***To Figure Mold Capacity,**
Fill your molds with water
Pour water into measuring cup
= That's how much
chocolate you will use!

Supplies

- 1 Gram MMJ Distillate
- 1.5 TBS Coconut Oil
- 1/3-1/2 Cup Chocolate
- Measuring spoons/cups
- (2) whisks, (2) Small bowls + (2) plates
- Chocolate molds
- Parchment paper, cut into small strips
- Storage container for refrigerator
- Thermometer
- Microwave

Steps

Microwaves Vary!
Go LOW + SLOW
Check Frequently.
If chocolates burn?...
Sorry, dude, START OVER.

1. Pre-warm your distillate: Placing in coffee mug w/ warm tap water.
2. Slowly heat 1 TBS Coconut oil in microwave safe bowl until it reaches about 110 degrees.
3. Squeeze out the pre-warmed distillate into the warmed coconut oil and whisk until well incorporated (about two minutes).
4. Heat *1/2 cup** chocolate chunks/chips and remaining 1/2 TBS coconut oil on 50% power for about two minutes, whisking frequently.
5. Once chocolate reaches 110 degrees, pour into THC + Coconut oil mixture and whisk until fully incorporated.
6. Pour chocolate/THC mixture into molds.
7. Pop in freezer for twenty minutes or until quick set.
8. Move to fridge overnight or for at least a few hours.
9. Remove from molds, label for dosage, store in fridge.