ACCELERATED MULTI-ENGINE GROUND SCHOOL CHECK-RIDE PREP







Copyright SkyView Aviation, LLC

Multi-Ground Training

Introductions

- Documents you will need
 - Pilot Logbook
 - Pilot Certificate
 - Medical or Basic Med (originals)
 - IACRA login
 - FTN number
 - Photo ID
 - Birth Cert / Passport
- Other important items
 - Headset
 - View Limiting Device (foggles)
 - Skyview Course Fee Balance
 - DPE Fee (cash \$875) **NO CHECKS PLEASE**







Training Schedule



Before Arrival – Complete ME Ground School via Zoom

Day 1

Arrival, Check-in, Documents, Ground, Pre-flight & Maneuvers, Intro to Single Engine Operations, OEI RNAV

Day 2

AM, Ground, Pre-flight, Single Engine Operations

PM, Ground, Pre-flight, Emergency Procedures & Instrument Approaches

Day 3

AM, Ground, Pre-flight, Check-ride Prep, Mock Check-ride Flight PM, Pre-flight, Check-ride with your DPE





Multi-Ground Training

Training (part 1)

- Commercial Maneuvers
- Flying Light Twins
- Multi-Engine Terms
- Single Engine Aerodynamics
- The Critical Engine
- Critical Engine Factors
- Zero Side-Slip
- Determining Vmc
- Recovering from Vmc
- Vmc versus Stalls
- Factors which influence Vmc

Training (part 2)

- Emergency Engine Out
- V-Speeds
- Performance Charts
- Oral Exam Review
- Travel Air Systems Review
- Landing Gear Discussion
- Maneuvers Review







Multi-Ground Training

Training (part 1)

- Commercial Maneuvers
- Flying Light Twins
- Multi-Engine Terms
- Single Engine Aerodynamics
- The Critical Engine
- Critical Engine Factors
- Zero Side-Slip
- Determining Vmc
- Recovering from Vmc
- Vmc versus Stalls
- Factors which influence Vmc

Training (part 2)

- Emergency Engine Out
- V-Speeds
- Performance Charts
- Oral Exam Review
- Travel Air Systems Review
- Landing Gear Discussion
- Maneuvers Review







Commercial Multi-Maneuvers

ABS

- **1.** Slow Flight
- 2. Steep Turns (50° Com/45°PVT) (+/- 100') (+/-5°)
- 3. Stalls (Power off, Power on, Accelerated)
- 4. Normal Take-off & Landing
- 5. Short Field Take-off & Landing
- 6. Emergency Descent
- 7. Engine Failure (Take-off roll, initial climb, cruise)
- 8. Single engine pattern with landing
- 9. In air engine restart
- **10**. Single engine instrument approach
- **11.** Vmc demonstration







Flying Light Twins

- The Most Critical Phase of Flight
 - Takeoff
- Far Part 23 Certification
 - Max Gross < 12,500
 - **6,000-12,500**
 - 6,000 or less
 - Vso < 61 kts</p>
- Climb Performance (none required for TA)
- How much power is lost when you lose an engine?
- Performance Loss? _____>80%

SKYVIEW

AVIATION LLO

Drag Factors

Clint Mathis, CFI, CFII, MEI

Flight Instructor Commercial Pilot

(931) 305-5502

www.3daymulti.com

flyme@3daymulti.com

- Full Flaps 400 fpm approx.
- Windmilling Prop 400 fpm approx.
- Gear Extended 150 fpm approx.





Flying Light Twins (General)

The most important phase of multi-engine flying is: Preflight Planning Most critical phase of light twin flying is **Takeoff**

FAR Part 23 puts forth certification requirements for light twins with a max gross weight of less than 12,500 lbs.

Certification Requirements:

At 5,000 ft. international standard atmosphere the airplane performance must be determined by the manufacturer for certification.

6001 – 12,500 lbs. – Must climb clean at 5,000' ISA Rate of climb (ROC) = (.027 x Vso²)

6,000 lbs. or less – If Vso = 61 kts CAS or greater. Must perform a positive ROC (.027 x Vso²)

If Vso = less than 61 kts Does not have to do anything. Can be a negative ROC.

Examples:

C-310 5,300 lbs. Vso = 63.9 kts. 63.9² x .027 = 110.2 fpm ROC Reality ROC = 119 fpm

BE-76 3,900 lbs. Vso = 60 kts. Reality ROC = 50 fpm

Climb Performance

Climb performance is dependent on the excess power needed to overcome drag. When a twinengine airplane loses an engine, the airplane loses 50% of its available power. This power loss results in a loss of approximately 80% of the aircraft's excess power and climb performance.

Drag is a major factor relative to the amount of excess power available. An increase in drag (such as the loss of one engine) must be offset by additional power. This additional power is now taken from the excess power, making it unavailable to aid the aircraft in climb.

When an engine is lost it is essential to achieve optimum single engine climb performance by:

Maximizing thrust- full power Minimizing drag- flaps & gear up, feather prop

Drag Factors:

- 1. Full Flaps- 400 fpm approx.
- Windmilling Prop- 400 fpm approx.
 Gear Extended- 150 fpm approx.



egory Carlton, CFI, CFII, MEI Flight Instructor Commercial Pilot



(270) 703-1640 🎕 www.3daymulti.com 🚱 lyme@3daymulti.com 🙆

6

50%

7

Multi-Engine Terms and definitions

- Service Ceiling This is the maximum density altitude where the best rate of climb airspeed (Vy) will produce a 100 fpm climb with both engines at max continuous power.
- Absolute Ceiling This is the maximum density altitude that the airplane can attain or maintain at max gross weight in the clean configuration and max continuous power. As altitude increases, Vx increases, while Vy decreases. Where these two speeds converge is absolute ceiling.
- Single Engine Service Ceiling- This is the maximum density altitude at which the aircraft can maintain a 50 fpm climb with one engine operating at full power and one engine with a feathered propeller. This is critically important, especially when flying over mountainous terrain. If the aircraft is above the single engine service ceiling when an engine fails, it will slowly drift down to its single engine service ceiling. This should be determined during flight planning using the single engine service ceiling chart from the POH.
 - Example: Aircraft cruising altitude: 12,000' MEA: 9,500' Single engine service ceiling: 6,000' If the aircraft has an engine failure at 12,000', it will drift down to 6,000'. If you are IMC this could be very bad. Always plan for an engine to fail! Choose a different route with a lower MEA.





Multi-Engine Terms and definitions, continued

- Vyse This is best rate of climb single engine. This is identified by the blue radial on the airspeed indicator. Always pitch for blue line when an engine fails. It will give you the best single engine performance, although it may not be a climb.
- Vxse Best angle of climb single engine. If you have obstacles to clear with an engine failed, use Vxse.
 Once the obstacles are cleared, pitch for Vyse.
- Vsse The minimum speed at which an intentional engine cut can be performed. It gives a safety
 margin from Vmc for safe engine cuts while training.
- Vmc This is the calibrated airspeed at which, following the sudden critical loss of thrust, it is possible to maintain control of the airplane.
- Zero Fuel Weight This is the maximum weight of passengers and baggage, less the fuel weight that the plane an withstand before structural damage occurs





Single Engine Aerodynamics



- Compared to counter-rotating props
- What happens with the loss of an engine?
- Why does this happen?

Yaw and Roll toward the dead engine Asymmetric - Lift, Thrust, and Drag

Asymmetric thrust will cause a yawing moment around the C.G. towards the dead engine.

Accelerated slipstream (or induced flow) is extra lift created by air accelerated from an operating engine forced over the wing. There is a lack of this induced flow over the wing with the failed engine. This results in a rolling moment around the C.G. toward the inoperative engine.

DEAD FOOT – DEAD ENGINE

To counteract the roll and yaw, you must apply rudder towards the operating engine!

Let's talk about the "Critical Engine"





What is a "Critical Engine"

A critical engine is the engine which, if lost, will most adversely affect the performance and handling characteristics of the aircraft. The effect of the critical engine is most significant when operating at low airspeeds with a high-power setting, thus producing more p-factor and torque.

On conventional twins with the propellers rotating clockwise, the critical engine is the left engine. On aircraft with counter-rotating propellers, such as the Beechcraft Duchess or Piper Seminole, there is no critical engine due to the turning tendencies cancelling each other out. An engine can also be termed as a critical engine if important systems are operated off that engine. (i.e. landing gear, pressure system, etc.)





Factors used in determining the critical engine



Factor

- P-Factor
- Accelerated Slipstream
- Spiraling Slipstream
- Torque

Explained

- Right propeller blade (farther away) is producing more thrust (yawing moment)
- The air being forced over the wing by the operating engine creates extra lift (rolling moment)
- Loss of air from the left engine (out) impact rudder control (less effective rudder)
- Torque tries to roll the airplane opposite of the propeller's direction of rotation. If the left engine fails, torque tries to roll the aircraft to the left, making it more difficult to raise the dead engine.





Counter-acting the "dead engine" - Zero Side-Slip



- Just using rudder to maintain direction will put the aircraft into a sideslip, which introduces the fuselage to the relative wind creating a large amount of drag. We need to minimize this drag as much as possible while still maintaining heading. The solution is to improve performance by using a zero-sideslip condition.
- When the aircraft is banked 2°- 5° toward the operating engine, the dihedral of the wing will create a horizontal component of lift. This will minimize the rudder deflection required to align the longitudinal axis of the airplane to the relative wind. With this bank, the appropriate amount of rudder deflection will be indicated on the inclinometer by the ball being halfway deflected toward the operating engine.



Determining Vmc

FAR 23.149- Vmc is the calibrated airspeed, at which, when the critical engine is suddenly made inoperative it is possible to:

- Maintain control of the airplane with the engine still inoperative.
- Maintain straight flight at the same speed with an angle of bank not more than 5 degrees.

As airspeed decreases the rudder becomes less effective, eventually an airspeed will be reached where full rudder deflection will be required to maintain directional control. This airspeed is Vmc. Any further reduction in airspeed will result in loss of directional control. Published Vmc is defined by the red radial on the airspeed indicator.

Vmc guarantees directional control only!!





How does the manufacturer determine Vmc?

- C- Critical engine failed and windmilling
- O- Operating engine at maximum takeoff power
- M- Maximum gross weight
- B- Bank of no more than 5 degrees
- A- Aft center of gravity
- T- Takeoff configuration (gear up, flaps up)
- S- Standard temperature (15°C) and pressure (29.92" Hg)





Factors which influence Vmc

Vmc is defined using a very specific set of conditions. Published Vmc and actual Vmc can be two very different numbers. Vmc only addresses directional control related aircraft and is not to performance.

While controllability is important, single engine performance is just as important.

You must be able to balance both controllability and performance to keep a serious situation from getting out of control. In some cases, an element that provides an increase in controllability can actually hurt performance.

Condition	V _{MC}	Performance
Below Maximum Weight	Increases	Increases
Maximum Weight	Decreases	Decreases
Landing Gear Up	Increases	Increases
Landing Gear Down	Decreases	Decreases
Wing Flaps Retracted	Increases	Increases
Wing Flaps Extended	Decreases	Decreases
Forward CG	Decreases	Decreases
Aft CG	Increases	Increases
Cowl Flaps Open	Decreases	Decreases
Cowl Flaps Closed	Increases	Increases
Windmilling Propeller	Increases	Decreases
Feathered Propeller	Decreases	Increases
Above Standard Temperature	Decreases	Decreases
Below Standard Temperature	Increases	Increases
1° to 5° Bank	Decreases	Increases
No Bank	Increases	Decreases
> 5° Bank	Decreases	Decreases
Out of Ground Effect	Increases	Decreases
In Ground Effect	Decreases	Increases





athis CELCEIL ME

Recognizing & Recovering from Vmc

Warning signs you are getting close to Vmc:

- Loss of directional control The rudder pedal is depressed to its fullest travel and the airplane is still yawing or rolling toward the inoperative engine.
- Stall warning horn or buffeting of the controls- A single engine stall is very dangerous and could result in a spin. Light twins are not known for good stall/spin recovery.
- A rapid decay of control effectiveness- This could lead to the loss of control of the aircraft.

To recover from Vmc, you must simultaneously:

- Reduce power on the operating engine- Reduce power on the operating engine reduces the asymmetric air flow.
- Pitch down- Lowering the nose of the aircraft will get the air flowing again over the control surfaces and allow you to regain directional control.









Vmc versus Stalls

Normally aspirated engines lose efficiency as density altitude increases. Since the operating engine is not producing as much thrust as at sea level, asymmetrical airflow will be reduced, which will lower Vmc. We must remember, though, that stall speed is an indicated airspeed that will remain constant as altitude increases or decreases. Eventually, the two speeds will be at the same point.

There exists an altitude where each of the following exists:

- VMC is less than VS (stall occurs first)
- VMC is the same as VS (stall and yaw coincide)
- VMC is greater than VS (yaw occurs first)

Here, the airplane will "stall and yaw" simultaneously under a condition of asymmetrical thrust. The airplane could experience an abrupt change in attitude or enter into a spin.

The density altitude where VMC and VS are equal is called the **critical density altitude**.



Figure 13-14. Graph depicting relationship of V_{MC} to V_S.







Memorize These Steps!

Action when an engine fails:

- 1. Maintain Directional Control & Pitch for Blueline
- 2. POWER UP- right left center: mixtures full, props full, throttles full
- 3. CLEAN UP- flaps up, gear up
- 4. IDENTIFY- Dead foot, Dead engine
- 5. VERIFY- cautiously retard throttle to idle If Below 3,000' AGL
- SECURE- feather the prop Mixture to idle cut-off Use the checklist! If Above 3,000' AGL
- 1. 1-5 Above then...
- 2. **RECTIFY-** Floor to the door:
 - A. Fuel, Fuel, Fuel (mixture, boost pumps, fuel selectors)
 - B. Ignition (check mags)
 - C. Air (alternate air)
- 3. SECURE- feather the prop Mixture to idle cut-off Use the checklist!











V Speeds for normal operations

Vr	Rotation Speed	85mph
Vx	Best Angle of Climb	90mph
Vy	Best Rate of Climb	110mph
Vxse	Best Angle 1 Engine	98mph
Vyse	Best Rate 1 Engine	108mph
Vso	Stall w/ Flaps down	70mph
Vmc	Min Control 1 Engine	80mph
Va	Maneuvering (Max Gross)	160mph
Vno	Max Structural Cruise	185mph
Vne	Never Exceed	240mph
Vle/Vlo	Max Gear Speeds	150mph
Vfe	Flap Extension	130mph
Best Glide	Max Gross	120mph

Certain items in the are lower and noted as "at 5,000'" Skyview uses a higher limit for an added margin of safety

Basic Single Engine Procedures



#1 Cardinal Rule – Maintain control and airspeed at all times

Apply max power to operating engine Reduce drag to an absolute minimum Secure failed engine and related sub-systems

Sample Take-off Briefing

1. We'll be using runway _____ and conditions are _____

2. Any loss of directional control we will reduce power to idle, use rudder to control the aircraft, and brake to stop.

3. Any loss of power prior to rotation, or if not reaching 70% of rotation speed by 50% of the runway, we will reduce power to idle, use rudder to control the aircraft, and brake to stop.

4. After rotation, gear still down, runway remaining, we will reduce power to idle, use rudder to control the aircraft, land, and brake to stop.

5. After rotation, and below 400' AGL, we will pitch for blueline and land straight ahead +/- 30 degrees. (NOTE: if conditions permit – see #6)

6. After rotation, gear up and above 400'AGL, we will pitch for blueline, maintain directional control, run the drill (mixtures, props, throttles, flaps up, gear up, identify, verify, feather), continue the climb to pattern and return and land.





BOOM, Engine Died!!!

Action when an engine fails:

- 1. Maintain Directional Control & Pitch for Blueline
- 2. POWER UP- right left center: mixtures full, props full, throttles full
- 3. CLEAN UP- flaps up, gear up
- 4. **IDENTIFY** Dead foot, Dead engine
- 5. VERIFY- cautiously retard throttle to idle If Below 3,000' AGL
- SECURE- feather the prop Mixture to idle cut-off Use the checklist! If Above 3,000' AGL
- 1. 1-5 Above then...
- 2. **RECTIFY-** Floor to the door:
 - A. Fuel, Fuel, Fuel (mixture, boost pumps, fuel selectors)
 - B. Ignition (check mags)
 - C. Air (alternate air)
- 3. SECURE- feather the prop Mixture to idle cut-off Use the checklist!









Performance Charts

<u>Know your performance!</u> Your CFI will cover the performance charts with you, but it's good to have a basic understanding of several of them before you start your flight training. Refer to the POH for these numbers.

Accelerate-Stop Distance

Accelerate-Stop distance is the distance required to accelerate to liftoff speed and, assuming failureof an engine at the instant liftoff speed is attained, bringing throttles to idle and stopping the airplane.

Accelerate-Go Distance Note: won't apply to the Travel Air

Accelerate-Go distance is the distance required to accelerate to liftoff speed and, assuming failureof an engine at the instant liftoff speed is attained, continuing the takeoff and climbing to 50'. Know before you try to takeoff whether you can maintain control and climbout if you lose an engine with the gear still down!

Takeoff Weight To Achieve A Positive Single Engine Rate Of Climb at Liftoff

This chart is for exactly what the title implies. Plug in your weight from the weight & balance to determine if you will be able to climb at liftoff, period. If you can't, then you are committed to pulling throttles to idle and stopping the airplane. Accelerate-Go would be impossible in this case.

Remember, These charts were printed many years ago when the airplanes were new. Always assume that your airplane will not live up to the performance stated in the charts. Always plan for worst case scenario and always give yourself an out. Always fly under the assumption "what if".





Clint Mathis, CFI, CFII, MEI Flight Instructor Commercial Pilot



Oral Exam Guide

It is important to understand and be able to demonstrate your knowledge in these areas for your oral exam.



www.3daymulti.com flyme@3daymulti.com

SKYVIEN AVIATION. LLC

JJ

Reecheral

Vmc

A thorough knowledge of Vmc is probably the most important subject on the oral exam.

- 1. Be able to define Vmc.
- 2. How does the manufacturer determine Vmc speed?
- 3. What happens to Vmc if the aircraft is loaded aft of the CG limit?

How is Vmc Determined? COMBATS

Critical engine failed and windmilling Operating engine at max t/o power Max gross weight Bank up to 5° into the good engine Aft CG Takeoff configuration Standard day, 29.92" Hg, 15°C

Know the factors that affect Vmc

Lowers Vmc (good)

Add power to the critical engine Reduce drag Reduce power on the good engine Forward CG Gear down Lower pressure Higher altitude Higher temperature

Increases Vmc (bad)

Reducing bank Higher pressure Lower temperature Lower altitude

How will these affect your performance?

Critical Engine

Be able to define critical engine. How is it determined? Why do some airplanes have a critical engine and some don't? Does the Travel Air have a critical engine?

Performance Charts

Know your performance!!

- 1. Takeoff distance
- 2. Accelerate-stop distance
- 3. Accelerate-go distance
- 4. Takeoff weight to achieve single engine climb
- 5. Climb performance: 2 engine, 1 engine
- 6. Cruise chart: TAS, fuel flow, range
- 7. Single engine service ceiling
- 8. Landing distance: flaps up, flaps down

Weight and Balance

Complete your weight & balance! Be able to use the charts and graphs in the POH. Explain zero fuel weight.

Aircraft Systems

Know your systems! Fuel system Landing gear Electrical system Constant speed, full feathering props Heater system Pressure system Fuel cross feed

Airspeeds

Red line Blue line Vy, Vx, Vyse, Vxse, Vmc, Va, Vlo, Vle, Vso, Vs1, Vsse, Vno, Vne





regory Carlton, CFI, CFII, ME Flight Instructor Commercial Pilot (270) 703-1640 🔇

vw.3davmulti.com 🚱

lyme@3daymulti.com 🖻

SKYVIEW

BOOM, Engine Died!!!

Action when an engine fails:

- 1. Maintain Directional Control & Pitch for Blueline
- 2. POWER UP- right left center: mixtures full, props full, throttles full
- 3. CLEAN UP- flaps up, gear up
- 4. **IDENTIFY** Dead foot, Dead engine
- 5. VERIFY- cautiously retard throttle to idle If Below 3,000' AGL
- SECURE- feather the prop Mixture to idle cut-off Use the checklist! If Above 3,000' AGL
- 1. 1-5 Above then...
- 2. **RECTIFY-** Floor to the door:
 - A. Fuel, Fuel, Fuel (mixture, boost pumps, fuel selectors)
 - B. Ignition (check mags)
 - C. Air (alternate air)
- 3. SECURE- feather the prop Mixture to idle cut-off Use the checklist!









Aircraft Systems





Eng	ines	Fuel System	Landing Gear	44.4 Mar.
Specs: 2 x Lycoming	IO-360 B1B	Fuel Capacity: 112 total (106 useable)	Sungear system: Uses a torque motor to	1
4-cyl horizontally oppo	sed, fuel-injected,	4 Tanks: Two MAIN: 25 gal ea (22 usable)	rotate a circular disk, which is connected to	
air cooled, naturally as	spirated, Max 28.5"	Two AUX: 31 gal ea (all usable)	push pull rods attached to the landing gear.	
2 x 180 hp each = Tot	al 360 hp	4 fuel pumps: 2 eng drive & 2 elec boost*	The push pull rods push the gear and doors	
Oil capacity: 6-8 qts	per engine (5 qt min)	8 fuel sumps: 4 ea wing	out and pulls them in.	When should you get a gear
Fuel burn: 10 gals / h	r perside	Fuel grade: 100LL (blue dyed & 6 lbs/gal)	'WOW' or Squat switch: On L Main Gear.	warning?
Ducu	- lla na	X-Feed: Emergency Only	Prevents the gear from retracting on ground.	
Prop	ellers	Fuel Limitations:	Other safety systems: Gear warning horn,	1. Gear up with low MP
Specs: Two-bladed H	artzell constant speed,	1. ALWAYS T/O & LAND on MAINS.	nose gear indicator and nose gear mirror	2. Full haps, gear up
full feathering props. N	Aaximum 2700 RPM	NEVER T/O with < 10 gals (yellow arc).	Gear hand crank: For emergency use	3. Gear selector up on ground
Maintains constant F	RPM: With oil pressure	3. WAIT 30s before t/o after high-speed taxi.	(roughly 50 turns counterclockwise)	Always verify flans and soa
through the prop gove	rnor	Electrical	Landing checks: "Down & Green"	Always verify haps and gear
(speeder springs / flyw	eights / pilot valve)		(verified twice and one in the mirror)	when using.
Nitrogen unfeatherin	g accumulator:	28V system: 2 x 12V battery (series)	Locks: Mechanical Up-Locks, and over-	Nose Gear Indicator light
Brings prop out of feat	her Why use Nitrogen?	2 x 28V alternators – 60 amps	center linkage w/ spring locks gear down	Nose Gear in the mirror
Locking pins: Preven	its props from	Circuit breakers: Protects the system	Heater	Elaps up or down (visually)
feathering when engin	e is < 800 RPM.	Voltage regulator: Parallels Loads	Included	
Saves wear and tear of	on starters.	Gear and Flaps System: 100% electrical	Janitrol 35,000 BTU Compustion Heater:	
ALTITUDE LIMITATIONS AT 4,200 lbs		Stortor Limitations	Located in the nose compartment. Self-	
			Drawa fuel from left main tank and ignites in	
Two Engine	Single Engine	10 Seconds on. 20 Seconds Off	the nose. Blower then circulates hot air	
Service Celling	Service Celling	(limit to 6 attempts) – wait 30 minutes	throughout the cabin	
$10,100^{2}$ (100 from)	4.400° (E0 ferm)	(mine to battempts) wait 50 minutes	anoughout the cubin.	1



18,100' (100 fpm)

4,400' (50 fpm)



Travel Air Landing Gear System

The Travel Air has a Sun Gear system which uses a torque motor to rotate a circular disk, which is connected to push pull rods attached to the landing gear.

The push pull rods push the gear and doors out and pulls them in.

This system has a Squat switch on the left Main Gear. This prevents the gear from retracting on ground.

Other safety systems: Gear warning horn, nose gear indicator, and nose gear mirror.

Gear hand crank: For emergency use (roughly 50 turns counterclockwise)

Landing checks: "Down & Green" (verified twice and one in the mirror)

Locks: Mechanical Up-Locks, and over-center linkage w/ spring locks gear down









BOOM, Engine Died!!!

Action when an engine fails:

- 1. Maintain Directional Control & Pitch for Blueline
- 2. POWER UP- right left center: mixtures full, props full, throttles full
- 3. CLEAN UP- flaps up, gear up
- 4. **IDENTIFY** Dead foot, Dead engine
- 5. VERIFY- cautiously retard throttle to idle If Below 3,000' AGL
- SECURE- feather the prop Mixture to idle cut-off Use the checklist! If Above 3,000' AGL
- 1. 1-5 Above then...
- 2. **RECTIFY-** Floor to the door:
 - A. Fuel, Fuel, Fuel (mixture, boost pumps, fuel selectors)
 - B. Ignition (check mags)
 - C. Air (alternate air)
- 3. SECURE- feather the prop Mixture to idle cut-off Use the checklist!









Travel Air Full Feathering Props

The Travel air has full feathering propellers and the system includes unfeathering accumulators to aid in unfeathering the propeller after an engine re-start. The propeller system is a constant speed propeller system similar to that shown below. Locking pins keep the propeller from feathering at shut-down at low RPM below 800 RPM. Note the drag caused by a windmilling propeller as compared to a feathered propeller.





Watch this video by Seth Lake, DPE about the unfeathering accumulators on the Travel Air.

Gregory Carlton, CFI, CFII, MEI Flight Instructor Commercial Pilot



SKYVIEW

BOOM... You just lost an engine!!!!

Action when an engine fails:

- 1. Maintain Directional Control & Pitch for Blueline
- 2. POWER UP- right left center: mixtures full, props full, throttles full
- 3. CLEAN UP- flaps up, gear up
- 4. **IDENTIFY** Dead foot, Dead engine
- VERIFY- cautiously retard throttle to idle If Below 3,000' AGL
- SECURE- feather the prop Mixture to idle cut-off Use the checklist! If Above 3,000' AGL
- 1. 1-5 Above then...
- 2. **RECTIFY-** Floor to the door:
 - A. Fuel, Fuel, Fuel (mixture, boost pumps, fuel selectors)
 - B. Ignition (check mags)
 - C. Air (alternate air)
- 3. SECURE- feather the prop Mixture to idle cut-off Use the checklist!





Why can't we rely on engine gauges to identity the inoperative engine?



(270) 703-1640 🔇 www.3daymulti.com 🚯 rme@3daymulti.com 🞱



Emergency Procedures

(+	
	00	0	-
	- V 1	P-	



ENGINE FIRE ON-GROUND 1. Starter Continue Cranking - Observe Starter Limitations (10 Seconds On) - If Engine Doesn't Start and/or Fire Persists 2. Evacuation Initiate EVACUATION 1. Mixtures Cut-Off 2. Throttles Idle 3. Magnetos Off 4. Battery & Alternators Off 5. Fuel Selectors Off 6. Evacuation Initiate	ENGINE FAILURE / FIRE IN-FLIGHT 1. Power Max Ava a. Mixture b. Prop c. Throttle 2. Landing Gear 3. Flaps 4. Identify Malfunction 5. Throttle Lever Verify 6. Prop Lever Verify 6. Prop Lever Feather 7. Affected Engine Mixture Lever C 8. Fuel Selector 9. Cowl Flap
 ENGINE FAILURE ON RUNWAY 1. "Abort-Abort-Abort" 2. Chop - power idle 3. Stop - apply brakes 4. Maintain directional control on runway 	 11. Alternator 12. Magnetos Land as soon as possible - If flight time o single engine is to exceed 30 minutes: CROSSFEED (One Engine Inoperative) che
EMERGENCY DESCENT 1. Autopilot Off 2. Throttles Idle 3. Props Full 4. Landing Gear Down (Max 150 MPH) 5. Airspeed Max 150 MPH 6. Altitude As Required; note MEA/MSA Note: In the event of a dual engine failure the best glide speed (Vg) is 120 MPH, with both props feathered and landing gear / flaps retracted. The glide ratio is 2.5 Miles for every 1,000' of ALT. SQUAWK 7700 – 121.5 (MAYDAY)	ENGINE RESTART Caution: The reason for engine failure s be determined before attempting an air 1. Complete the ENGINE FAILURE check 2. Airspeed 12 3. Magnetos 12 3. Magnetos 6 4. Alternator 6 5. Cowl Flap 4 6. Fuel Selector 4 7. Throttle Lever 4 8. Mixture Lever 4 9. Prop Lever 4 10. Starter 5 11. Warm-Up 15" MP, 2000

AILURE / FIRE IN-FLIGHT			
r Max Available Mixture		Warni	ng:
Prop			
Ihrottle			
ng Gear Up			
		Warni	ng:
ty Malfunction L or R			
tie Lever Verify L or R			
Lever Feather L or R			
ed Engine Mixture Lever Cut-Off			
elector			
Flap Closed			
Pump		Cautio	on:
latorOff			
etosOff			
oon as possible - If flight time on			Land
ine is to exceed 30 minutes:			Land
D (One Engine Inoperative) checklist			Hand
FSTART			
The reason for engine failure should		Note:	
mined before attempting an air start			
plete the ENGINE FAILURE checklist			
eed			
netos On			
nator On			
Flap Closed			Hand
Selector Aux / Main		_	and
ttle Lever Idle			Lanu
ure Lever Rich			Land
Lever Full		Cautio	on:
er Engage / As Required			
m-Up 15" MP, 2000 RPM			

MANUAL GEAR EXTENSION

- Warning: Keep cranking until the physical limit of the handle is reached. DO NOT rely on the green indicator light, as the gear may be down but not fully locked in this condition.
- Varning: If the gear is manually extended in an actual emergency situation, DO NOT move any landing gear controls or reset any circuit breakers until the aircraft is on jacks, as the failure may be in the gear-up circuit. This could cause the gear to retract on the ground.
- Caution: The manual extension system is designed only to lower the landing gear. DO NOT attempt to retract the landing gear manually.

۰	Landing Gear Relay C/B Pull
۰	Landing Gear Handle Down
۰	Handcrank Engage / Turn CC

Note: Pull Handcrank out to engage manual extension and turn the crank counter-clockwise about 50 turns; verify with mechanical indicator.

LANDING GEAR RETRACTION (AFTER PRACTICE MANUAL EXTENSION)

	Hando	crank Stor	wed
	Landing Gear Relay C/B		
	Landing Gear Handle Up		
ut	ion:	DO NOT operate the landing gear electrically with the Handcran engaged, damage to the mechanism could occur rendering the	k
		manual gear extension system inoperative.	7.3

Clint Mathis, CFI, CFII, MEI Flight Instructor Commercial Pilot



BOOM... You just lost an engine!!!!

Action when an engine fails:

- 1. Maintain Directional Control & Pitch for Blueline
- 2. POWER UP- right left center: mixtures full, props full, throttles full
- 3. CLEAN UP- flaps up, gear up
- 4. **IDENTIFY** Dead foot, Dead engine
- VERIFY- cautiously retard throttle to idle If Below 3,000' AGL
- SECURE- feather the prop Mixture to idle cut-off Use the checklist! If Above 3,000' AGL
- 1. 1-5 Above then...
- 2. **RECTIFY-** Floor to the door:
 - A. Fuel, Fuel, Fuel (mixture, boost pumps, fuel selectors)
 - B. Ignition (check mags)
 - C. Air (alternate air)
- 3. SECURE- feather the prop Mixture to idle cut-off Use the checklist!









Other links and resources





https://3daymulti.com/study-materials







Appendix



SkyView Aviation, LLC 3 Day Accelerated Multi Rating