

Lockout/Tagout Procedure Form

Procedure Description

Instructions: The Authorized Employee and the Program Administrator will complete this digital, fillable form for each piece of equipment separately. This form should inventory all energy sources and LOTO points for each piece

Equipment Description: 3- Roper Whitney Auto-Brakes (Model: AB1016E2)		
Serial Number: 180-10-17, 262-12-20, 183-09-07	Location of Equipment: Main Shop	Area or Department: Shop
Number of Lockout Points:	Lockout Device(s) Needed:	
2	Breaker Lock and Notice Sign	

Lockout Procedure:

- 1. Shut machine sown on the bottom right of the computer screen
- 2.Flip red power switch on back of machine off
- 3. Switch breaker box off and install lock
- 4. Post Notice on front of machine

Procedure to Verify Lockout is Complete:

Before removal of any guards or any maintenance can be completed double check that eh maine os turned off and that the breaker is switched off with proper lockout tagout cover installed and locked

Release and Start Up Procedure:

- 1. Authorized personal to inspect that all covers and guards are on properly in place and machine is in good working order
- Unlock breaker lock and flip breaker on.
- 3. Turn on power switch
- 4. Remove LOTO notice

