

Cricut

QUICK SWAP TOOLS



QUICK SWAP HOUSING

- One housing unit with interchangeable tips
- Quick release button at the top
- Compatible with the Maker & Maker 3 machines

SCORING WHEELS



SINGLE

Create score lines for easy folding

DOUBLE

ENGRAVING

Etch designs on hard materials

TIPS



DEBOSS

Create indent pattern impressions

BLADES



WAVY

Cut wavy lines

PERFORATED

Cut broken lines for easy perforation

