

Lock-in Golf Grip lockingolfgrip.com/videos

Finally, a product that FORCES you to grip the golf club correctly every time!!! Set it to practice hooks, draws, fades and slices!! Set it to go straight!! You can even set it to practice your bunker shots!!

Whether you have a weak grip like Ben Hogan and Corey Pavin, or a neutral grip like Jack Nicholas and Ernie Else, or a strong grip like Dustin Johnson and Lydia Ko, the Lock-in Golf Grip will FORCE you to grip the golf club the same way every time. Find what works best for you and “lock it in”. Then, get that muscle memory!


The Lock-in Golf Grip FORCES the back of your leading hand and heel pad to be positioned properly on the golf club grip. Then, simply take your other hand and cover up your thumb with your palm. The only importance of the lower hand is to have the palm facing the target at setup.

Any golf professional will tell you that the proper grip is the most important aspect of the golf swing.

Prepare for practice for the first time:

Do these five steps to create the shot that you desire.


Step 1) Attach the round alignment cap to the butt end of the golf club so that the Cap Line is lined up with the Groove Lines on your golf club.



Step 2) Attach the Lock-in Golf Grip to the golf club as shown. Firmly tighten until the Lock-in Golf Grip does not slide around. For the driver, align the the Dot on the Alignment Cap up with the Large Line on the Lock-in Golf Grip. For the iron, align the Line on the Alignment Cap up with the Large Line on the Lock-in Golf Grip.



Step 3) Grip the golf club making sure your knuckles are below the Lock-in Golf Grip and the Lock-in Golf Grip is firmly placed up against the back of your hand. Then, practice hitting balls making sure that the palm of your lower hand is facing the target when you are set up to hit the ball. And on your downswing, focus on turning your hips open. For more information, watch video “How to Fix Your Slice” www.lockingolfgrip.com/videos



Step 4) If the majority of your balls curve to the left, adjust the Lock-in Golf Grip 1 millimeter to the left and repeat step 3 until you are hitting the golf shot that you desire.



Step 5) Once the desired shot is found, remove the alignment cap and mark the position of the Lock-in Golf Grip by using the supplied white writing utensil. Then, hit as many balls as possible to create that muscle memory. The writing utensil provided is semi-permanent and can be safely removed with soap and water. This gives the golfer an easy way to return its position for the next practice session.



Prevent Flipping:

The Lock-in Golf Grip will tell you if you are flipping on the down swing. If the golf ball on the attachment screw brushes up against the side of your arm, then you are flipping. See “Prevent Flipping the Hands” video at <https://lockingolfgrip.com/videos> for more information.

Other settings:

Once your desired shot is obtained, you can adjust the Lock-in Golf Grip to practice curving the ball more to the right or left. Simply rotate the Lock-in Golf Grip using the drawn on line as a guide. Also, you can practice your bunker shots by setting the Lock-in Golf Grip to the Green side sand setting.



Other Information:

The reason for the dot on the alignment cap.

When using a driver, the ball is teed up and lined up off of the front foot. This will encourage the club to hit the ball on the upswing.

When using an iron or a club that is hit off of the ground, the ball is lined up closer to the center of your stance (between your feet). This will encourage the club to hit the ball on the downswing.

This slight change in setup is the reason for differences in hand position.

Also, the Lock-in Golf Grip comes in two sizes. “Large” for larger hands and most adults, and “Small” for smaller hands, women and most kids.