

## BROW LAMINATE POST CARE



Avoid getting brows wet for  
24-48 hrs



Apply oil every single night at  
least 1 hour before bed to  
allow for it to soak in.



For easy/best styling, shape  
your brows while WET.



Book your maintenance for  
every 6-8 wks.



Condition your brows.  
Add it into your shower  
routine & apply to the brow.



Avoid steam, sauna,  
sweating for the first 24-  
48hrs.



No rubbing or rigorously  
washing brows, swipe in the  
direction of the hair growth.



Apply a leave in conditioning  
treatment or bond repair to  
your brows weekly.



Brush your brows gently  
everyday to the desired  
shape.