## Standard Size Chart WOMEN'S SWIM | 2022 VERSION



	B
1	
	6

International Sizing	XXS	XS		S		М		L		XL	
	G B	GE	3	GВ	G	В	G	В	G E	;	
US	2	4		6		8		10		12	
AU/UK	6	8		10		12		14		16	
Cup	30	32		34		36		38		40	
Bust (cm)	79	83		87		91		95		99	
Underbust (cm)	5864	6268		6672	707	'6		7480		7884	
Waist (cm)	5261	5665		6069	647	'3	6877		72	81	
Hip (cm)	6782		7186	7590	799	4	8398		8	7102	
Lower Hip (cm)	7281	7691		8095	849	19	8810	3	92107	7	
Crotch (cm)	4,5	4.5		4.5		4.5		4.5		5	
Length (cm)	62	66		67.5	67.5 69		70.5		72		
Bust (In)	31,1	32.7		34.2	2 35.8		37.4		3	9	
Underbust (in)	2325,2	24.226.7		2628.	3 27	27.529.9		29.131.5		30.733	
Waist (in)	20,524,1	2225.6		23.627	23.627.1 25.228		26.830.3		28.331.9		
Hip (in)	26,432,3	29.935.8		29.535.4 3		31.637.6 33.239.2		239.2	34.840.8		
Lower Hip (in)	20,331,9	29.935.8		31.537	.4	3339		34.640.5		36.242.1	
Crotch (in)	1,8	1.8		1.8		1.8		1.8		1.8	
Length (in)	24,5	24.5		24.5		24.5		24.5		24.5	

**G** = Garment Measurement | **B** = Body Measurement

- Use a tape measure to measure, holding the tape securely around for key points.

  (A) Bust. Measure over the fullest area of the bust & straight around the back.

  (B) Underbust. Measure directly under the bust & straight around the back. (B) **Underbust.** Measure directly under the bust & straight around the back.
  - © Waist. The waist is below the abdomen between the rib cage and hips.

  - (a) Hip. Measure around the hipbones, ensuring the tape goes straight around the body.

    (b) Lower Hip. Measure the fullest part of the hip ensuring the tape is straight around the body.
  - © Crotch. Measure distance in between your leg opening and at the lowest point of your crotch.