




60MM PAVERS

CITYSTONE™

Joint patterns are what give the CityStone series its recognizable surface texture and classic appeal. CityStone is a proven paver on projects including patios, sidewalks, and plazas. This paver creates a timeless design with enduring beauty and durability.



DIMENSIONS


Product		Width (in.)	Length (in.)	Height (in.)	Millimeter (Thickness)	Weight/ Unit (lbs.)	Sq. Ft./ Cube	Pieces/ Cube	Weight/ Cube (lbs.)	Pieces/ Sq. Ft.	Part # Standard
Bundled	4x8	4	8	2 3/8	60	6	103	80	2,971	2.33	36378
	8x8	8	8	2 3/8	60	12		80			
	8x12	8	12	2 3/8	60	18		80			
Bundled	8x16	8	16	2 3/8	60	24	103	20	2,971	0.58	36478
	16x16	16	16	2 3/8	60	48		20			
	16x24	16	24	2 3/8	60	72		20			

NOTES: Full cubes only. Standard finish only.

PRODUCT DETAILS

- Made of durable concrete with iron oxide pigments that will not fade with extended UV exposure. Meets or exceeds applicable requirements of ASTM C936 and C1782.
- Joints and surfaces meet ADA gap and lippage requirements.
- Smooth surfaces and finely chamfered edges combine to create a sleek and contemporary look.

AVAILABLE COLORS



INSTALLATION INSTRUCTIONS

STEP 1: Excavate unsuitable, unstable or unconsolidated subgrade material and compact the area which has been cleared. Backfill and level with dense graded aggregate suitable for base material - typically minimum 4-8 inches thick (101.6mm - 203.2mm). Compact base to optimum moisture/density or as otherwise directed by Site Engineer/ Architect/Landscape Architect.


STEP 2: Place bedding course of washed sand conforming to the grading requirements of ASTM C 33 to a maximum uniform depth of 1-inch (25.4mm). Screed to the grade and profile required.

STEP 3: Install CityStone with joints to a nominal 1/8 inch (3mm).

STEP 4: Where required, cut pavers with an approved cutting device to fit accurately, neatly and without damaged edges.

STEP 5: Use a low-amplitude plate compactor capable of at least minimum of 4,000 lbf (18 kN) at a frequency of 75-100 Hz to vibrate the pavers into the sand. Remove any cracked or damaged pavers and replace with new units.

STEP 6: Post compaction, spread and sweep dry ASTM C 33 or ASTM C 144 sand over the entire paving area.




STEP 7: Make one more pass with the plate compactor to completely fill the joints with sand.


STEP 8: Sweep paver surface clean for final acceptance by owner/ owner's agent.

NOTE: Colors are shown as accurately as possible in brochures and samples, but due to the nature of the product, regional color differences and variables in print reproduction, colors may not match exactly. For best results in maintaining color consistency, pavers must be installed from several cubes at a time. Efflorescence, a whitish, powder-like deposit, may appear on concrete pavers. This is a natural occurrence in any concrete product and will usually wear off over time.


INSTALLATION PATTERNS



Demi Pattern 01



Demi Pattern 02



Demi and Supra Pattern



www.keystonehardscapes.com

Pedricktown | 345 Route 130 | Pedricktown, NJ 08067 | (856) 299-5339



FOLLOW US

© 2020 The QUIKRETE Companies – KHS 05/2020