



Made in Colorado, for Colorado's Climate!



Old Western Paint Co., Inc.

2001 W. Barberry Pl.
Denver, CO 80204
Phone: 303-825-5147
Fax: 303-825-2437
www.oldwesternpaint.com

Colorado Pro 600

Interior Production Finishes
0656 Flat Wall & Ceiling Paint

Description

Colorado Pro 600 Interior Flat Wall & Ceiling 0656 is a professional production quality interior latex flat paint that meets the requirements of painters, contractors and building managers. Ideal for new-home construction, multi-family construction, commercial construction, or anywhere where a quality interior flat latex is desired. Designed for interior walls and ceilings, this easy-to-apply product provides excellent performance at an economical price.

Application and Substrate Information

Mix or stir thoroughly before using. Paint should be applied using appropriate brush, roller, or through airless spray equipment (2,000 psi, 0.015" – 0.021" tip). A second coat may be applied at a minimum of 3-4 hours after applying the first coat as drying conditions allow.

May be applied to properly prepared gypsum board, drywall, concrete/masonry block, plaster, wood and metal. See General Surface Preparation for further details.

For best results, temperatures (air, surface and material temperatures) should be between 50°F – 90°F (10°-32°C) before applying.

Product Data

Gloss/Sheen (85°)	< 2 units (flat/matte)
VOC Content (g/L)	< 20
Viscosity (Krebs Units)	100 (± 3)
Density (lb/gal)	11.7
Scrubs (ASTM D2486)	225 cycles
Volume Solids	33 %
Coverage (1.5 dry film)	330 ft ² *

*Theoretical value; may vary based on substrate porosity/application method

Features and Benefits

- ✓ Formulated and made in Colorado
- ✓ Very low VOC
- ✓ Provides a rich, very low flat finish
- ✓ Non-spattering when rolled
- ✓ Very good touch-up

Thinning

Thinning is not required, though a small amount of water can be added if desired. Thinned paint is more prone to in-can settling and biological contamination if not used immediately and/or stored over long periods of time.

Dry Time

Will dry to touch in one hour or less; may be recoated after four hours. Dry time may be affected by poor ventilation, low temperatures, amount of colorant and/or high humidity areas.

Clean-up

Clean all tools and equipment with warm, soapy water.

Environmental/Health Considerations

Formulated without lead, mercury, and other heavy metals. Does not contain ethylene glycol. No reportable amount of crystalline silica.



Made in Colorado, for Colorado's Climate!



Old Western Paint Co., Inc.

2001 W. Barberry Pl.
Denver, CO 80204
Phone: 303-825-5147
Fax: 303-825-2437
www.oldwesternpaint.com

General Surface Preparation

All foreign material, including loose or peeling paint, dirt, grease, oil, wax, chalk, mildew, rust, dust, curing agents, etc., must be removed prior to use. Failing to do so may compromise proper adhesion and overall performance. Caulk all cracks and open seams. Putty all nail holes. An appropriate primer should be used when coating bare or porous substrates. A stain blocking primer is recommended over areas where stains would 'bleed through' to the surface. Glossy surfaces should be dulled prior to coating, and rough or patched surfaces should be sanded.

Specific Substrate Recommendations

Siding: Not recommended for exterior application.

Concrete/Masonry Block: New concrete should cure for at least 30 days prior to priming and painting. The surface pH should be below 10 before applying an alkali resistant primer. Block filler should be used over masonry block.

Metal: Ferrous metal should be primed with a waterborne or solventborne rust resistant metal primer. Non-ferrous metal and zinc treated metal should be primed with an all-purpose metal primer.

Drywall/Gypsum Board: Nails and screws should be countersunk and properly covered using putty or drywall mud, then sanded to be flush with the rest of the surface. Primer is recommended for new drywall and porous surfaces.

Wood: Unpainted wood should be sanded smooth, wiped, and primed with an appropriate primer. For redwood or cedar, a stain blocking primer should be used to prevent bleed-through from soluble tannin stains.

Recommended Primers

Concrete/Masonry	1251 Elevation 100% Acrylic Primer
Drywall	0710 Colorado Pro Primer/Sealer
Drywall	0610 Colorado Pro 600 Primer
Metal	1255 Elevation All-Prime
Plaster	1251 Elevation 100% Acrylic Primer
Wood	1251 Elevation 100% Acrylic Primer
Wood (tannin)	1255 Elevation All-Prime
Cement Block	1250 Elevation Block Filler

Packaging

Available 1-gallon and 5-gallon containers. Actual volume amounts of paint are indicated on the label. Volume is adjusted to account for the addition of colorants.

Intended Use

To be used in a manner consistent with latex wall paints and finishes. Do not take internally. Keep out of reach of children and pets. Not recommended for floors or where water can puddle. Keep from freezing.

WARNING: If you scrape, sand or remove old paint, you may release lead dust. LEAD IS TOXIC AND MAY CAUSE SERIOUS ILLNESS IF YOU ARE EXPOSED, ESPECIALLY FOR CHILDREN OR THOSE WHO ARE PREGNANT. Wear a properly fitted NIOSH-approved respirator and prevent skin contact to minimize lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. For further information, contact the U.S.E.P.A. National Lead Information Hotline at 1-800-424-LEAD or visit www.epa.gov/lead.

Disclaimer

All information and data appearing in this document are provided in good faith and are believed to be reliable and accurate to the best of our knowledge at the date of publication. None of the provided information is to be considered a warranty or quality specification or all-inclusive and is given only as a guidance. It is the user's responsibility to determine the intended utilization of the product. No guarantee, expressed or implied, is made by Old Western Paint Co., Inc. And the user assumes all risk and responsibility.