


Carl Miles Heel Guard™


Installation FOR H-D TAPERED RIDER FOOTBOARD

Average time: 30 minutes

Step 1 Hold the Heel Guard™ in position just in front of the rear mounting tabs, align the rod with the inside edge of the footboard and mark the outer edges of the bracket on the bottom of the footboard base (PIC 1).




Step 2 Remove the footboard from the motorcycle. Turn the footboard upside down and hold the Heel Guard™ in place on the marks made in STEP 1. The Heel Guard™ bracket has 2 mounting holes, mark both carefully. (PIC 2).




Step 3 Remove the rubber pad assembly from the footboard base. Pull carefully on the pad while pushing its rubber darts through the footboard base. Center punch the marks made on the footboard base and drill 2 - 1/4" holes.

Step 4 It may be necessary to trim the rubber pad slightly to provide clearance for the screw heads. Set the footboard base in place on the rubber pad. With a ball point pen, scribe the outlines of the holes on the bottom of the rubber pad. (PIC 3).




Step 5 With a utility knife or razor blade, carefully cut away the raised lip on the bottom edge of the pad.

Step 6 Fasten the Heel Guard™ to the footboard base with two 1/4" - 20 x 5/8" button head cap screws and two nylock nuts included (PIC 4) & (PIC 5).



Step 7 Lubricate the five rubber darts on the bottom of the rubber pad with soapy water and reinstall it on the footboard base. Use your fingernail or needlenose pliers to gently work the darts completely through the holes. **BE CAREFUL NOT TO DAMAGE THE DARTS!**



Step 8 Reinstall the footboard on the motorcycle.

NOTE For safety, always wear boots. If shoes are worn, tuck in shoe laces.