
OVERDENTURE WITH LOCATOR: INDIRECT TECHNIQUE STEP-BY-STEP CHAIRSIDE PROTOCOL

1st AppointmentImplant Level
Impression



- Place a LOCATOR impression coping on each abutment.
- 2. Syringe Medium Body Impression Material around each coping.
- 3. Fill the impression tray and insert it over the copings and onto the tissue.
- 4. Allow material to set and remove the impression tray. Impression is ready to send to lab.

2nd Appointment
Jaw Relation
Record, Shade, &
Opposing



- With patient sitting upright, mark the midline, high lip line, and corner of the mouth in the wax rim.
- 2. Determine the VDO.
- 3. Take an impression of the opposing dentition and impression of the current denture for study model.
- 4. Select the shade and mold of the denture teeth.
- 5. Send case to lab with master model.

3rd AppointmentTeeth Try-in



- 1. Place the try-in overdenture in patients mouth. Verify fit, esthetics, and function.
- 2. Send the entire case back with labslip stating either: A) Reset instructions B) Proceed to finish.
- 3. Include new bite registration.

4th Appointment Final Delivery



- 1. Place the overdenture in the mouth and press down to engage the male on the abutment.
- 2. If the retention is not satisfactory, remove the male and replace with the next level of retention as demonstrated below.
- 3. Your case is successfully completed.

STANDARD MALES

Dual retention to maximize stability and pivoting action that accommodates up to 20° divergence between two implants.



EXTENDED RANGE MALES Pivoting action accommodates up to 40° of total divergence between two implants.



Extra Light
Retention Male
08529

Light
Retention Male
08527

Regular detention Male 08524

Zero Retention Male 08558

REPLACEMENT MALES

Extra Light Retention Ma 08548

ght Lig Male Retention 8 089

EXTENDED PANGE

08915 ®

08547



Please call us at (800) 277-8336 with any questions.