

## Ford Wiper and Headlight Knobs & Ignition Switch Instructions

### Wiper knob (1973-1979 F-Series / 1978-1979 Bronco)


1. Remove knob from shaft by using a pick on the backside of the knob.
2. Remove old knob and attachment clip.
3. Place knob and position the set screw so it tightens on the shaft with the top of the knob remaining horizontal, allow for approx. 1/16" of movement of the knob to the attachment nut to allow for the washer to activate. Then tighten set screw.
4. Confirm function of the Wiper switch.

### Headlights knob with shaft (1973-1979 F-Series / 1978-1979 Bronco)

1. Remove knob and shaft by turning knob all the way clockwise and then pushing the button on the Headlight Electrical Switch which is located behind the dash.
2. Insert the knob with shaft into the Headlight Electrical switch thru the opening in the attachment nut.
3. Confirm the shaft clicks into the switch. (If it does **not** click into the switch then loosen the set screw and remove knob from shaft. Then push shaft into switch. Then place knob over shaft and align set screw to a flat section on the shaft and tighten)
4. Rotate the shaft counter-clockwise about ½ turn and confirm Parking light (first click) and Headlights (2<sup>nd</sup> click) functions correctly.

### Ignition Switch Bezel and Tumbler Cover (1967-1979 F-Series / 1978-1979 Bronco / 1965-1968 Car)

1. Disconnect the negative terminal from battery. 2. Remove Ignition Tumbler Cylinder (what the key goes in) by placing the key into the Tumbler and placing it into "ACC" position. Then use a paper clip or preferably a (1.25mm or 0.050") allen wrench and while pushing it into the hole of the Tumbler and at the same time turn the key counter-clock wise to remove the Tumbler. 3. Remove the Ignition Switch Bezel from the Ignition Switch by using the 3 prong Ignition Switch Bezel Removal tool and unscrewing the Ignition Switch Bezel. 4. Remove Bezel from the dash. 5. If using the Tumbler Cover then place it over the Tumbler and align the slots and insert key. Then insert the allen wrench into the hole to make sure the two parts are aligned. Then place 1 drop of super glue (Pic A). Let dry for 5 minutes. 6. Hold Tumbler in hand and place thumb on the Tumbler Cover to hold it in place while removing the allen wrench and key. (insure slots and holes are aligned) 7. Place on flat surface and apply 1 drop of Super glue at 3 different locations at the interface of Cover and Tumbler. (Pic B) Let glue set up for an hour or best overnight in the vertical position as shown. 8. Place new Ignition Switch Bezel into dash and screw it onto the Ignition Switch using the 3 prong Ignition Switch Bezel tool. 9. Insert Tumbler into Ignition Switch by placing key into Tumbler along with allen wrench in the hole and twist clockwise and push into Switch starting at approx. at the 10 position. 10. Connect negative terminal on battery and test.



Pic A



Pic B