

## **Heatmiser controls – simple guide to changes**

Now that your controls have been commissioned and set, the only changes that will be needed are to the Clock when Daylight saving time comes into effect, and if temperatures aren't to your requirements. Each room is different, so over time as you settle in, I expect changes will want to be made.

### **Thermostat control keys**

You will find 5 touchscreen keys on the face, and 6 features (Power – Clock – Holiday – Edit – Hold – Setup) It is always Tick to move forward, and whatever is flashing is what you control.

### **Changing the clock**

If you press > or < to highlight CLOCK, then press tick. You can then adjust the day, hours and minutes. It's always TICK to accept and move through.

### **Changing your Control settings**

Same applies, in TICK to accept, and whatever is flashing is what you control. If you select EDIT off the main menu, then choose between Mon-Fri or Sat-Sun by pressing > then Tick (Remember to do both overall). You have 4 settings a day, and I would recommend you maintain a maximum 3 degree differential between peak and off peak temperatures.

### **Temporary Changes**

If you would like a temporary increase in temperature, then increase by pressing up to set over what's displayed, and to the temperature required, then press tick, and this will override the set temperature until the next time setting comes into effect. E.g Demanding 23 degrees in the evening will then revert to type at the set SLEEP time.