



# Power



Images are for illustration purpose only

### ENGINE

PERKINS heavy duty diesel engine  
4-cycle, water cooled, Turbocharged,  
direct injection

12/24 Volt starter and charge  
alternator with battery, rack and  
cables

Replaceable air, fuel and oil filter

Industrial type radiator

Flexible fuel piping

Oil sump drain valve and extension  
pipe

Industrial/Residential type exhaust  
silencer.

Jacket Water Heater

Diesel gen-set maintenance and  
operating instructions and electrical  
circuit diagram

### ALTERNATOR

Brushless, single bearing, 4-pole  
alternator coupled with flexible disc  
coupling

H type insulation class

IP 23 protection

Self exciting

Electronic AVR

### CONTROL PANEL

DeepSea mains sensing or remote  
start control module

Emergency stop push button

Output circuit breaker

Static battery charger

Ready for remote monitoring

### CANOPY

Modular type sound-proof canopy

Built from galvanized steel and epoxy,  
polyester powder painted

Lockable doors on both sides of  
canopy designed for easy access to  
essential replacement parts

Emergency stop push button

Control Panel viewing window

Bunded base fuel tank (Optional)

Forklift Pockets (Optional)

Power cable entry with a gland plate

### Standby Power

Applicable for supplying  
power to varying electrical  
load for the duration of  
power interruption of a  
reliable utility source,  
Overload is not allowed.

### Prime Power

The maximum power  
which a generating set is  
capable of delivering con-  
tinuously whilst supplying  
a variable electrical load.  
Average load should be  
70%.The generator can  
be overloaded 10% for 1  
hour per 12 hrs.

### Base Power

Continuous power rating  
is used in applications  
where supplying power is  
at a constant 100% load  
for an unlimited number  
of hours each year.



EA Power Systems reserves the right to make changes in model, technical specifications, color, equipment & accessories without prior notice

EA Power Systems Ltd.

3rd Floor St Georges House 6 St Georges Way  
LE11QZ Leicester United Kingdom

www.eapowers.com +44(0)1163180570

Registered in England & Wales No:11023250





MODEL		EAP1110	EAP1250	EAP1385	
OUTPUT	Standby	kVA	1110	1250	1385
		kW	888	1000	1000
	Prime	kVA	1009	1125	1250
		kW	807	900	1000
ENGINE	Engine	PERKINS	PERKINS	PERKINS	
	Model	4008-TAG2A	4008-30TAG3	4012-46TWG2A	
	Configuration	INLINE	INLINE	V	
	No. of Cylinders	8	8	12	
	Speed	rpm	1500	1500	1500
	Displacement	l	30,56	30,56	45,84
	Bore x Stroke	mm	160 x 190	160 x 190	160 x 190
	Compression Ratio		13,6: 1	13,1: 1	13,6 : 1
	Aspiration		Turbocharged	Turbocharged	Turbocharged
	Governor Type		Electronic	Electronic	Electronic
	Cooling		Water	Water	Water
	Coolant Capacity	l	149	140	210
	Lubrication Oil Capacity	l	153	153	177
	Fuel Consumption l/h	100%Load	215	244	259
75% Load		162	188	196	
50%Load		111	120	143	
ALTERNATOR	Phase	3	3	3	
	Pole	4	4	4	
	No. of Leads	12	12	12	
	Excitation System	AVR	AVR	AVR	
	Insulation Class	H	H	H	
	IP Protection	IP23	IP23	IP23	
	Power Factor	0,8	0,8	0,8	
	Frequency	Hz	50	50	50
	Voltage	V	400	400	400
SIZE	Canopy Set Dimensions (LxWxH) & Weight	mm	5550 x 2200 x 3310	5550 x 2200 x 3310	7000 x 2438 x 3620
		kg	12710	12980	17356
	Open Set Dimensions (LxWxH) & Weight	mm	5300 x 2200 x 2460	5300 x 2200 x 2460	4800 x 2090 x 2375
		kg	10955	11225	10194
	Fuel Tank Capacity	l	2072	2072	2500

EA Power Systems reserves the right to make changes in model, technical specifications, color, equipment & accessories without prior notice

EA Power Systems Ltd.

3rd Floor St Georges House 6 St Georges Way

LE11QZ Leicester United Kingdom

www.eapowers.com +44(0)1163180570

Registered in England & Wales No:11023250





### CONTROL MODULE

DSE 7 Series Control Module

State of the art, microprocessor controlled

4line, 64 x 132 pixel display LCD display

Automatic mains failure sensing

Front panel manual programming

User friendly setup and button layout

Remote start

Event logging, showing date and time

Stop/Reset, Manual

### Displays

Engine Speed (rpm)

Oil pressure

Fuel Level (%)

Coolant temperature

Running Hours

Battery voltage monitoring

Generator Voltage (LL. LN)

Generator Current (L1-L2-L3)

Generator Frequency (Hz)

Generator Load & Power Monitoring (kW. kVA. kVAR.

pf)

Mains Voltage (LL. LN)

Mains Frequency

Generator Set Ready

Mains Ready



### Alarms

High coolant temperature

Low Fuel Level

Low oil pressure

Charge failure

Battery Low/High voltage

Fail to start

Fail to stop

High/Low Generator voltage

Generator Over/Under frequency

Generator Over/Under Speed