





# 2017 NATIONWIDE PWBA ROCHESTER OPEN



<b>DISTANCE:</b>	<b>51 FEET</b>	<b>VOLUME:</b>	<b>19.114 mL</b>
<b>RATIO:</b>	<b>2.02:1</b>	<b>FORWARD:</b>	<b>11.742 mL</b>
<b>DROP BRUSH:</b>	<b>51 FEET</b>	<b>REVERSE:</b>	<b>7.372 mL</b>
<b>TANKS:</b>	<b>CURVE &amp; CURVE</b>	<b>PUMP:</b>	<b>38μL</b>



### FORWARD LOADS DATA

#	START	STOP	LOADS	MICS	SPEED	BUFF	TANK	DISTANCE	T.OIL
1	2L	2R	5	38	22	3	A - CURVE	0 → 12	7,030
2	5L	5R	4	38	22	3	A - CURVE	12 → 25	4,712
3	2L	2R	0	38	22	3	A - CURVE	25 → 51	0

### REVERSE LOADS DATA

#	START	STOP	LOADS	MICS	SPEED	BUFF	TANK	DISTANCE	T.OIL
1	2L	2R	0	38	30	3	B - CURVE	51 → 28	0
2	11L	11R	2	38	22	3	B - CURVE	28 → 22	1,444
3	10L	10R	1	38	22	3	B - CURVE	22 → 19	798
4	9L	9R	2	38	18	3	B - CURVE	19 → 14	1,748
5	6L	7R	2	38	14	3	B - CURVE	14 → 10	2,128
6	3L	5R	1	38	14	3	B - CURVE	10 → 8	1,254
7	2L	2R	0	38	10	3	B - CURVE	8 → 0	0

**THIS PATTERN IS DESIGNED FOR:**  
DUAL CONDITIONING TANKS

This pattern may require adjustments if using a lane machine that does not have these features

**KEGEL PATTERN LIBRARY APP**

GET IT ON **Google Play** | **Download on the App Store**

[PATTERNLIBRARY.KEGEL.NET](http://PATTERNLIBRARY.KEGEL.NET)

SCAN QR CODE TO  
SHARE AND  
DOWNLOAD  
THIS PATTERN

