





# EASY STREET V2



<b>DISTANCE:</b>	<b>39 FEET</b>	<b>VOLUME:</b>	<b>22.4 mL</b>
<b>RATIO:</b>	<b>12.00:1</b>	<b>FORWARD:</b>	<b>12.8 mL</b>
<b>DROP BRUSH:</b>	<b>34 FEET</b>	<b>REVERSE:</b>	<b>9.6 mL</b>
<b>TANKS:</b>	<b>KEGEL</b>	<b>PUMP:</b>	<b>50µL</b>



### FORWARD LOADS DATA

#	START	STOP	LOADS	MICS	SPEED	BUFF	TANK	DISTANCE	T.OIL
1	2L	2R	2	50	18	3	A - Kegel	0 → 3	3,700
2	10L	10R	4	50	18	3	A - Kegel	3 → 13	4,200
3	11L	11R	2	50	18	3	A - Kegel	13 → 18	1,900
4	13L	13R	4	50	18	3	A - Kegel	18 → 28	3,000
5	2L	2R	0	50	22	3	A - Kegel	28 → 33	0
6	2L	2R	0	50	30	3	A - Kegel	33 → 39	0

### REVERSE LOADS DATA

#	START	STOP	LOADS	MICS	SPEED	BUFF	TANK	DISTANCE	T.OIL
1	2L	2R	0	50	30	3	A - Kegel	34 → 33	0
2	14L	14R	2	50	18	3	A - Kegel	33 → 28	1,300
3	13L	13R	4	50	18	3	A - Kegel	28 → 18	3,000
4	12L	12R	4	50	14	3	A - Kegel	18 → 10	3,400
5	11L	11R	2	50	14	3	A - Kegel	10 → 6	1,900
6	2L	2R	0	50	14	3	A - Kegel	6 → 0	0

**THIS PATTERN IS DESIGNED FOR:**  
REVERSE DROP BRUSH

This pattern may require adjustments if using a lane machine that does not have these features



**KEGEL PATTERN LIBRARY APP**



[PATTERNLIBRARY.KEGEL.NET](http://PATTERNLIBRARY.KEGEL.NET)



SCAN QR CODE TO  
SHARE AND  
DOWNLOAD  
THIS PATTERN

