





# SPHINX



<b>DISTANCE:</b>	<b>40 FEET</b>	<b>VOLUME:</b>	<b>25.2 mL</b>
<b>RATIO:</b>	<b>2.00:1</b>	<b>FORWARD:</b>	<b>15.8 mL</b>
<b>DROP BRUSH:</b>	<b>35 FEET</b>	<b>REVERSE:</b>	<b>9.4 mL</b>
<b>TANKS:</b>	<b>ICE</b>	<b>PUMP:</b>	<b>50µL</b>



### FORWARD LOADS DATA

#	START	STOP	LOADS	MICS	SPEED	BUFF	TANK	DISTANCE	T.OIL
1	2L	2R	7	50	14	3	B - ICE	0 → 12	12,950
2	10L	10R	1	50	14	3	B - ICE	12 → 14	1,050
3	11L	11R	1	50	18	3	B - ICE	14 → 16	950
4	12L	12R	1	50	18	3	B - ICE	16 → 19	850
5	2L	2R	0	50	18	3	B - ICE	19 → 30	0
6	2L	2R	0	50	30	3	B - ICE	30 → 40	0

### REVERSE LOADS DATA

#	START	STOP	LOADS	MICS	SPEED	BUFF	TANK	DISTANCE	T.OIL
1	2L	2R	0	50	30	3	B - ICE	35 → 31	0
2	12L	12R	2	50	22	3	B - ICE	31 → 25	1,700
3	11L	11R	2	50	22	3	B - ICE	25 → 19	1,900
4	10L	10R	2	50	22	3	B - ICE	19 → 13	2,100
5	2L	2R	2	50	14	3	B - ICE	13 → 9	3,700
6	2L	2R	0	50	14	3	B - ICE	9 → 0	0

### THIS PATTERN IS DESIGNED FOR:

REVERSE DROP BRUSH

This pattern may require adjustments if using a lane machine that does not have these features



KEGEL PATTERN LIBRARY APP



PATTERNLIBRARY.KEGEL.NET



SCAN QR CODE TO  
SHARE AND  
DOWNLOAD  
THIS PATTERN

