

SOLAR PRO 300ZB TW/CW

300W LED 25-50°zoom profile light

USER MANUAL

• Package and accessories

- 1. 300W LED zoom profile light 25-50 $^{\circ}$
- 2. 3 pin signal connector 1 pair
- 3. Power plug 1 pair

• Functions •

- Input voltage 100-240V 50-60HZ
- Power consumption 300W
- Manual zoom
- Zooming scale: 25-50°
- DMX dim or manual button dim
- 16 bit above no flicker linear dimming
- Inner size: 76×28.5×28.5cm
- Packing size: 89×30.5×31.5cm
- G.W.: 14kg
- N.W.: 16kg

• Keys instruction •

 $\bigcirc \rightarrow$ Confirm $\bigcirc \rightarrow$ Function

Press Function key display different functions cyclically.

- Press decrease key and increase key to adjust each function's value.
- ◆ Press confirm key to confirm the function and value .

Special remind: when the multi units power cable mutual input / output connected, each group can connect10 units, power cable must use 3×2.5^2 grounding.


• Screen display and its function •			
No.	Screen	Function instruction	
1	DMX-ADR 001 V	Already connect with DMX wire. press "O" and "O" keys can adjust address.	
2	DMX-ADR 001 X	not connect with DMX wire. Can set master/slave connected, press "O" key or "O" key can adjust address you want.	
3	ADJ-CW 255	Enter manual button dim mode press " vey and " vey to dim	


Û→ Increase

Q→ Decrease

• Screen display and its function •







4	DMX SING OFF/ON	Prior for DMX, press 0 "or " $\mathbf{\hat{0}}$ " choose the function DMX SING ON/OFF, and ten press $\mathbf{\hat{o}}$ to save/confirm the function
5	DMX KEEP OFF/ON	for DMX keep/off, press Q "or " D " choose the function you want, and ten press C to save/confirm the function

• DMX channels functions

Only 1 DMX channel 0-255 dim

• Master/slave connect introduce •

Set all units address same as "001", off DMX signal, can set any unit as master, set functions on the master unit by the Function key all units are synchronal