



KAWASAKI Undertail Installation instructions



**BEFORE THE
UNDERTAIL**



WHAT YOU NEED

1- MASKING TAPE

2- DRILL

3- PHILLIPS SCREWDRIVER

4- HAND SAW BLADE OR DREMEL

5- DRILL BIT # 3/16 (TABS – AREA NEAR LENSES)

6- DRILL BIT # 15/64 (NYLON SCREW RIVETS FOR THE BACK)

7- ELECTRIC TAPE



WHAT COMES WITH THIS UNDERTAIL?





REMOVE THE REAR SECTION OF THE BODY

There are plastic body connectors as well as bolts inside the tail in addition to the Allen-head bolts on the outside surface.

NOTE: KEEP YOUR STOCK RIVETS FOR LATER USE.





REMOVE THE TAIL SECTION & SEAT






REMOVE THE TAIL SECTION & SEAT






REMOVE THE TAIL SECTION & SEAT






REMOVE THE TAIL SECTION & SEAT





REMOVE THE TAIL SECTION & SEAT



REMOVE THE TAIL SECTION & SEAT





REMOVE THE TAIL SECTION & SEAT





CUTTING OF THE SECTION OF REAR FENDER

The next page will show you a picture of the excess plastic needed to be cut.

You won't loose your cargo space area.

Use a hand saw blade or Dremmel to cut it.

Get somebody to help if necessary.



CUT & REMOVE SECTION OF REAR FENDER





CUT & REMOVE SECTION OF REAR FENDER

Use a hand saw blade or Dremmel to do it.



Should look like this




INSTALL THE TAIL SECTION






PANORAMIC VIEW OF THE CARGO SPACE AREA






TESTING THE BLINKERS



Before installing the undertail make sure to test the blinkers as shown in the pictures





INSTALLING THE SOCKETS & BOLTS


With this undertail you can use your own stock sockets. You only have to remove the area indicated in the picture. That way you don't have to cut any wires.





INSTALLING THE SOCKETS & BOLTS

- 1-Use **your own sockets**, that way you won't have to cut any wires.
- 2-Plug in the sockets thru the white base; place the washers & nuts and adjust them. Don't tight them too hard.





INSTALLING THE SOCKETS & BOLTS



Should look like this

INSTALLING THE UNDERTAIL

Start by sliding in the undertail. Get somebody to help you!!





INSTALLING THE UNDERTAIL



Align everything (top & bottom)

INSTALLING THE UNDERTAIL



Once aligned, hold it in place using masking tape.



INSTALLING THE UNDERTAIL



TABS

Drill a hole in the TABS (red arrows). The drill should go thru the **tail section & undertail**.

Get somebody to help you hold before drilling.
Use drill bit 3/16 with the hardware provided.
Then, bolt in the screws & nuts





INSTALLING THE UNDERTAIL



Drill a hole on the other side too. The drill should go thru the tail section & undertail. Use drill bit 3/16 with the hardware provided. Then, bolt in the screws & nuts



INSTALLING THE UNDERTAIL



Should look like this



INSTALLING THE UNDERTAIL



Now drill a hole in the back of undertail, where the predrilled holes are in the tail section. The drill should go thru the tail section & undertail.

Then bolt in (USE YOUR STOCK RIVETS) Repeat this step on the other side too)





Your are done!

AFTER THE UNDERTAIL

