


How to Build a Green Strobe Rocket

CAUTION!!

Working with pyrotechnic devices is a very rewarding endeavor that can become a lifetime passion. To ensure continued enjoyment of this hobby, please follow appropriate safety guidelines. Work in an open area outdoors, keep all pyrotechnic mixtures in closed containers, limit any compositions to only the amount needed for a particular item, store finished items in an appropriate day box or magazine, be sure to wear appropriate non-synthetic clothing, wear eye protection and keep a source of water nearby. FireSmith cannot be held responsible for any accidents or incidents resulting from the construction and use of any pyrotechnic devices. It is highly recommended to check and adhere to all local, state and federal regulations. Please consider joining the PGI and any pyro clubs in your area so that you may construct pyrotechnic items in a safe and legal environment. Additional information can be found at www.pgi.org.



Strobe rockets are always a crowd pleaser. With a brief shriek followed by a loud popping ascent, these rockets are always entertaining. Though strobe rockets are thought by some to be complicated to construct, they are quite easy to manufacture using specific fuels and common building practices. The techniques depicted in this tutorial will produce a strobe rocket that emits bright green flashes and a loud "popping" sound. The rocket finishes with a white-tailed shriek prior to the header being deployed.

Do keep in mind the fuels depicted in this tutorial are some of the most powerful and sensitive compositions used in the pyrotechnic hobby. The potassium dichromate used in producing strobe fuel is quite hazardous and should be used with appropriate personal protection gear (gloves, eye protection and a respirator).

The fuel around the bottom 2/3rds of the spindle is either a potassium or sodium benzoate whistle fuel. Strobe fuel is then pressed to a height of 3/16" - 1/4" above the spindle. A plug of whistle fuel with 5-10% titanium is pressed above the strobe fuel to act as both a bulkhead and delay.

The formula for the fuels in this construction guide are as follows (a tutorial depicting the manufacture of these fuels is located on the FireSmith website). It is very important that these fuels only be compacted by pressing. NEVER ram or pound whistle or strobe fuel. Proper compaction of fuel is important. I press my rockets to just about 9,000psi on the fuel grain (though anything in the 8,000-9,000psi range will work fine).

Potassium Benzoate Whistle Fuel:
Potassium Perchlorate 64
Potassium Benzoate 32
Copper Oxchloride 2
Petroleum Jelly 3
(5-10% 80-150 Mesh Ti Sponge or Flake for fuel above the spindle)

Green Strobe Fuel:

Ammonium Perchlorate (90-100 micron) 60

Barium Sulfate 15

Magnalium (200 mesh) 17

Magnalium (-325 mesh) 8

Potassium Dichromate 5

Petroleum Jelly 3

Quality paper tubes must be used to produce these rockets. The single best source is the NEPT line of tubes. You will need to cut these tubes to the following length(s):

1lb = 7.5"

2lb = 8.75"

3lb = 10"

4lb = 12"

6lb = 16"



Required Materials:

FireSmith Nozzleless, Universal or Super BP Core Burn Tooling

Tube Support

Tube Extender

Spindle Remover

Press

Potassium or Sodium Benzoate Whistle Fuel (both with and without titanium)

Strobe Fuel

Small Funnel

Teaspoon

NEPT Paper Tube

3/16" dia x 14" Brass or Wood Rod

3/16" Hex Key



Step 1

Flip the tube support upside down, lower the taper rings and insert the empty tube into the tube support.



Step 2

Flip the tube support right side up, drop the taper rings over the support and lightly snug them up with hand pressure.



Step 3

Slide the tube & tube support assembly onto the motor spindle.



Step 4

Gather the #1 rammer (the longest rammer with the largest diameter bore).



Step 5

Using a teaspoon and a funnel, dump one increment of whistle fuel into the tube.

*An appropriate increment size is about 1/2 the ID (inside diameter) of the motor tube. If you experience CATO's, try cutting increment sizes in half. A good starting point is as follows:

1lb = 1-2 teaspoons

2lb = 2-3 teaspoons

3lb = 3-4 teaspoons

4lb = 4-5 teaspoons

6lb = 5-6 teaspoons



Step 6

Insert the #1 rammer into the motor tube and press the fuel down by hand. A light amount of force is all that is needed to initially compact the fuel.



Step 7

Place the motor into the press and compact this increment of fuel to 8,000-9,000psi. The actual force being applied to the fuel isn't as important and being able to consistently reach that force with the press. Anywhere from 8,000-9,000psi will work fine.

*Do note the location of the line machined into the top of the rammer. If that dips below the top of the tube, tooling damage may result.



Step 8

Remove the entire assembly from the press, insert the T-puller into the rammer and with a light twisting motion, remove the #1 rammer from the motor.

*A wise safety precaution is to avoid placing any part of one's body over the top of the rammer while performing this task. If for some reason the rammer becomes stuck (typically due to wet fuel, too large an increment or driving the rammer past the "no-pass" line onto the spindle), remove the spindle from the motor (if possible) and soak the entire assembly in water overnight. The rammer should then be easily removed.



Step 9

Using the brass or wooden rod, gently clean out any fuel that may have gotten inside the rammer. It is highly important to clean rammers in between pressing each increment of fuel. Failure to do so can result in a serious accident.



Step 10

Repeat steps 5-9 until the second line machined into the rammer is visible above the tube after pressing an increment.



Step 11
Switch to the #2 rammer (the second longest with a flush tip).



Step 12
Add another increment of whistle fuel.



Step 13
Lightly seat the rammer with hand pressure.



Step 14

Insert the assembly into the press and compact the fuel to 8,000-9,000psi.




Step 15

Remove the assembly from the press, insert the "T-puller" and with a light twisting motion, remove the rammer from the motor.



Step 16

Using the wooden or brass rod, gently clean the bore of the #2 rammer.



Step 17

Repeat steps 12-16 until the swap-out line is visible above the top of the motor tube after pressing an increment of fuel.



Step 18

Switch to the #3 rammer (the third longest with a flush tip).



Step 19

Switching to the green strobe fuel, use a teaspoon and funnel to add an increment of fuel to the motor.



Step 20

Insert the #3 rammer into the motor tube and seat the fuel with light hand pressure.



Step 21

Insert the entire assembly into the press and compact the fuel to 8,000-9,000psi.



Step 22

Using the puller, apply a slight twisting motion and remove the rammer from the motor tube.



Step 23

Use the brass or wooden rod to gently clean any fuel residue trapped inside the bore of the rammer.



Step 24

Repeat steps 19-23 until the swap-out line is visible above the motor tube after pressing an increment of fuel.



Step 25

Switch to the #4 rammer (the shortest with a solid tip).



Step 26

Continuing to use the green strobe fuel, add an increment of fuel to the motor. When pressed, this strobe fuel should be $3/16''$ - $1/4''$ above the spindle. With the slow burn rate of strobe fuel, adding too much above the spindle could result in a rocket that deploys the header at a very low altitude. It may be necessary to add this last bit of strobe fuel in half-increments to ensure the height above the spindle isn't exceeded.



Step 27

Insert the #4 rammer and seat the fuel with light hand pressure.



Step 28

Insert the entire assembly into the press and compact the fuel to 8,000-9,000psi.



Step 29

Use the puller and a slight twisting motion to remove the rammer from the motor tube.



Step 30

Once the strobe fuel is $3/16$ " - $1/4$ " above the spindle, switch to the whistle fuel with 5-10% titanium for constructing the remainder of the motor. It will be necessary to use a tube extender while loading the last few increments of fuel. Simply slide the tube extender over the top of the tube and dump in an increment of fuel.



Step 31

Place the #4 rammer into the tube extender and use hand pressure to compact the fuel into the motor tube.



Step 32

Slide the tube extender over the rammer and set aside.



Step 33

Insert the entire assembly into the press and compact the fuel to 8,000-9,000psi. Remove the rammer and repeat steps 30-33 until the motor is filled to within 1/2"-1" from the top of the tube.

*The height of the gap at the top of the tube that contains no fuel is dependent upon the speed of your fuel and the weight the motor will be carrying. Lighter payloads may use more fuel and a smaller gap (since they will reach higher altitude) and heavier payloads may need less fuel a larger gap to prevent the motor from coming back to earth before the heading is deployed. A bit of experimentation will be necessary.



Step 34

Remove the entire assembly from the press. Using a 3/16" hex key, remove the base from the spindle.



Step 35

Flip the tube support upside down and insert it into the press. Set the motor removal tool on top of the tube support



Step 36

Bring the ram of the press down to the motor removal tool. Apply a small amount of pressure until the top ring drops. Lower the ram and apply a bit more pressure until the bottom ring drops. Remove the entire assembly from the press.



Step 37

Remove the completed motor.



Step 38

Slip the removal tool over the bottom of the spindle/pressed motor.



Step 39

Set the base on the spindle/pressed motor and insert the 1" long cap screw through the base and into the bottom of the spindle. Using a 3/16" Allen key or T-wrench, tighten the screw until the spindle is pulled out of the pressed motor. Once the screw is "snugged up" it should only take one or two revolutions of the screw to pull the spindle out of the motor.



Step 40

Set your completed motor in the nearest daybox or magazine. Please reference the tutorials on the FireSmith website for information detailing attaching a heading, sticking and fusing rocket motors.