

Orthodontic screws and prosthetic screws can be removed with a single Driver

e-Driver

Orthodontic screw breakage can be prevented by using a correct assembly method, increasing the reliability of abutment fixation and reducing the risk of screw loosening.

Prosthetic screws are included in the e-Driver!

- Correct torque can be applied without being afraid of breaking the screw or causing it to loosen.
- Easy access to posterior teeth for screw removal.
- Easy access to posterior teeth for screw removal.



Orthodontic screws can be removed before placement!

- 15~35Ncm hard kemiye bile yerleştirilebilir/cıkarılabilir
- Torque setting device, calibration screw's breakage/dropping can be reduced to the minimum.



Torque Setting Guide

Prosthetic screw	Torque (Ncm)		교정스크류	扭矩 (Nom)	속도 (RPM)
	Mini	Reg			
Cover Screw, Healing, Imp Coping	5	5	Ø 1.4mm	15	
One piece ABT (Rigid, Solid ABT)	30	30	Ø 1.6mm	20	20 ~ 30
Two piece ABT (Transfer, Angled ABT)	20	30	Ø 1.8mm	30	
Temporary Abutment	20	20			
Cylinder Screw	20	20			

e-Driver's Advantages

1. Powerful and correct torque

- 5Ncm to 35Ncm range (5Ncm increments)
- Automatic stop function for correct torque application
- LCD screen allows real-time torque control
- TCS (Torque Calibration System) for accurate calibration

2. Adjustable speed

- 15RPM to 60RPM (15RPM increments) adjustable
- Manual operation is twice as fast as working time
- Single-handed reverse mode

3. German Technology

- High-quality German-made FAULHABER motor

Motor usage for high torque and fast motor usage