1 Power Connection

- Plug the unit into a 3-pin socket.
- The OLED display will automatically turn ON.

2 Setting the Clock

- Verify the time displayed on the OLED screen.
- To adjust the clock:
  - Press and hold the OK button for 5 seconds, then release.
  - Use the H1 button to set the hour.
  - Use the M1 button to set the minutes.
  - Press OK to confirm the clock time.

3 Power Switch Modes

- Toggle the power switch to select the desired mode:
  - Manual Mode – Normal operation without timer function.
  - Auto Mode – Automatic switching based on timer settings.
    - Each socket (SCK-1,2&3) has option to set for up to 3-time range. Device will automatically switch On and Off daily, as per set time range.

Product Model **Power Button** **OLED Display** **H1** **M1** **M2**

H2

EXTENSION BOX WITH TIMER
MODEL NO:-
STH-300MA
(230VAC. 10A)
MADE IN INDIA
MANUAL / OFF / AUTO

18:38
Mode: MANUAL
Active: SCK-1
         SCK-3
         SCK-3

SIMMANG TECH

MODE H1
OK   M2 M2

SK1 **SK2**

Toggle Switch

SK3

4 Timer Setup (Auto Mode)

When the power switch is set to Auto, follow the steps below to configure timers.

1. Setting Timer for SCK1 (1st socket from the left)
   a) Press the Mode key to enter timer setup for SCK1.
   b) Set the Start Time (24Hr format):
      i. Hour → H1 key
      ii. Minute → M1 key
   c) Set the Stop Time (24Hr format):
      i. Hour → H2 key
      ii. Minute → M2 key
   d) Press OK to confirm the first timer for SCK1.
   e) The selection will move to the second timer. Repeat steps (b) to (d).
   f) Repeat the same process for the third timer.
   g) If no timer is required, set the time to 00:00 – 00:00 and press OK.
2. Setting Timer for SK2 (2nd socket from the left)
   a) Press the Mode key repeatedly until SK2 is selected.
   b) Repeat steps (b) to (d) from section 1 to configure timers for SK2.
3. Setting Timer for SK3 (3rd socket from the left)
   a) Press the Mode key repeatedly until SK3 is selected.
   b) Repeat steps (b) to (d) from section 1 to configure timers for SK3.

Important Notes

- Always confirm timer settings by pressing the OK button.
- Ensure unused timers are set to 00:00 – 00:00 to prevent unintended switching.
- To reset all timers, press and hold Mode key for 5 second.
- Keep the unit connected to a stable power source for reliable operation.
- 0.5 sec actuation delay while changing MODE is made to increase the life span.