



RPBA Test Using the MAKO MK5 5-Valve Test Kit, per USC FCCCHR Manual 10



Step	Procedure
1.	NOTIFY OWNER , identify, inspect, & observe assembly
2.	<p>OPEN TEST COCKS</p> <ul style="list-style-type: none"> a. Open and leave open Test Cock (TC) #4, then TC #3, TC #2, and finally TC #1 b. Fully close TC #1, TC#2, TC #3, and TC #4 <p>Note: If needed, install appropriate fittings to test cocks</p>
3.	<p>ATTACH TEST KIT</p> <ul style="list-style-type: none"> a. Verify MK5 is turned on and captured values are cleared (Hold Down the Back Button) b. Close all MK5 test kit valves and verify high, low, and bypass hoses are all appropriately connected to MK5 c. Connect high side hose to TC #2 d. Connect low side hose to TC #3
4.	<p>BLEED AIR FROM HOSES</p> <ul style="list-style-type: none"> a. Slowly open TC #3 fully, then open low side bleed valve (leave open) b. Slowly open TC #2 fully, then open high side bleed valve (leave open)
5.	<p>ISOLATE</p> <ul style="list-style-type: none"> a. Close #2 shutoff valve b. Close high side bleed valve c. Wait for MK5 psid reading to stabilize, then Slowly Close the low side bleed valve d. If relief valve doesn't open, NOTE the reading as the apparent differential pressure across the #1 Check Valve
6.	<p>TEST RELIEF VALVE</p> <ul style="list-style-type: none"> a. Open high side control valve approximately one turn b. Slowly Open low side control valve slightly, <i>no more than ¼ turn</i> c. RECORD psid reading (Press the Capture Button) at first discharge of water from the Relief Valve d. Close low side control valve
7.	<p>TEST #2 CHECK VALVE</p> <ul style="list-style-type: none"> a. Maintain #2 shutoff valve in closed position and MK5 high side control valve in open position b. Bleed air from the bypass hose by opening the bypass control valve then close the bypass control valve c. Attach the bypass hose from the MK5 to TC #4 and open TC #4 fully d. Open low side bleed valve so the reading exceeds the apparent differential pressure across #1 Check Valve e. Slowly Close the low side bleed valve f. Open the bypass control valve g. Once the reading on the gauge stabilizes: RECORD the #2 Check Valve as "closed tight" (relief valve closed) or "leaked" (relief valve opens)
8.	<p>TEST #1 CHECK VALVE (Static differential pressure across #1 check valve must be greater than the relief valve opening point AND at least 5.0 psid)</p> <ul style="list-style-type: none"> a. Leave bypass hose connected to TC #4 and verify high side and bypass control valves remain open b. Open low side bleed valve so the reading exceeds the apparent differential pressure across #1 Check Valve c. Slowly Close the low side bleed valve d. Once the reading stabilizes: RECORD psid reading (Press the Capture Button) across #1 Check Valve
9.	<p>SUPPLY PRESSURE and EQUIPMENT REMOVAL</p> <ul style="list-style-type: none"> a. If you report the supply pressure, close TC#3 and TC#4 and open the low side bleed valve b. Once satisfied with the reading: RECORD psid reading (Press the Capture Button) for supply pressure c. Close remaining test cocks and remove all test equipment and fittings d. Slowly open #2 shutoff valve e. Open the high, low, bypass valves and the high/low bleed valves; drain water from hose(s) f. Notify owner g. Fill out test report



Scan QR code to see this test being performed