SVBA Test Using a Mako MK2 2-Valve Test Kit

| Step | Procedure SVBA |
|------|--|
| 1. | NOTIFY OWNER, identify, inspect, and observe assembly. |
| 2. | SETUP TEST |
| | a. Remove air inlet valve canopy |
| | b. Open the test cock then close the test cock |
| | c. Open the vent valve (loosen screw) then close the vent valve (tighten screw) |
| | d. Attach bleed-off valve arrangement to test cock |
| | e. Attach high side hose of MK2 to the bleed-off valve arrangement |
| | f. Verify MK2 is turned on and captured values are cleared (Hold Down the Back Button) |
| | g. Close all MK2 test kit valves |
| | Note: Install appropriate fittings if necessary |
| 3. | BLEED AIR FROM HOSE |
| | a. Open test cock and RECORD line pressure (Press the Capture Button) |
| | b. Open high side bleed valve of MK2 |
| | c. Note: To ai <mark>d in det</mark> ermining the opening of the air inlet valve, the area on top of the |
| | valve may be filled with the water from the bleed valve of MK2 |
| | d. Close the high side bleed valve |
| | e. Close #2 shutoff valve |
| | f. Elevate the MK2 Rate-of-Change Graph to same level as the vent valve |
| | g. Close #1 shutoff valve |
| 4. | CHECK VALVE TEST |
| | a. Slowly Open vent valve (loosening or removing screw) |
| | b. Once flow of water from vent valve stops or is no more than a drip AND the reading on |
| | MK2 stabilizes: |
| | c. RECORD psid reading (Press the Capture Button) |
| 5. | AIR INLET VALVE OPENING TEST |
| | a. Maintain the MK2 Rate-of-Change Graph at same level as the vent valve |
| | b. Slowly Open the high side bleed valve no more than ¼ turn |
| | c. RECORD psid reading (Press the Capture Button) when air inlet valve opens |
| | d. Close the high side bleed valve |
| | e. Remove the high side hose from the blee <mark>d-off valve to drain water from t</mark> he body |
| | f. <u>RECORD whether the air inlet valve fully opens</u> |
| | g. Close test cock |
| _ | h. Close the vent valve (replace screw) |
| 6. | REMOVE ALL EQUIPMENT MK2 |
| | a. Slowly open #1 shutoff valve |
| | b. Slowly open #2 shutoff valve |
| | c. Replace the air inlet valve canopy |
| | d. Remove all test equipment and fittings |
| | e. Open Low Bleed and High Bleed valves; drain water from hose(s) |
| | f. Notify owner |
| | g. Fill out test report |