


LADIES MEASUREMENT INSTRUCTIONS:

Originals by Kay:

Please wear your corset and/or appropriate underpinnings when being measured and get a friend to help you if possible. Some of these measurements are virtually impossible to do on your own. (click on the photographs for enlargements) It is important that you mark your torso as shown in the first picture. Please run the armscye markers under the arms and up over the shoulders as shown (so they rest in the small space created by the acromioclavicular joint). Do not push the waist tape down, but let it rest where you are the narrowest in the corset.



Torso measurement :
Please measure very high under your arms and above the bust all the way around your torso - this measure-



Bust: Measure all the way around the fullest part of your bust/chest, making sure the tape does not droop in the back.



Back width:
From armscye marker to armscye marker. Do not run the tape under the arm!



Front body length:
From the base of the throat to the top edge of the waist band.



Back Nape to Waist Measurement:

Begin this measurement at the top of the most prominent cervical vertebra, where the neck begins to curve to the front. Be careful not to begin too low,




Bust point to bust point

Front width:
From armscye marker to armscye marker, do not run the tape under the arm! Similar to the back width measurement.



Side Measurement:
From just within the armpit to the upper



Waist: Measure the waist just above the waist tape.




Wrist Measurement:
Around the wrist



Upper Arm Measurement:
Around the upper arm



Neck Opening:
Around the neck at the base, not in a strangle!



©Copyright, 2003

Originals by Kay:

Kay Gnagey, Proprietress
721 East Wayne Street,
Fort Wayne, IN 46802
(visits by appointment only)
Phone: (260) 422 7617
Email: KGnagey@aol.com
www.Originals-by-Kay.com



Shoulder Slope Measurement 1:

This measurement goes from the center front of the waist tape right past the neck to the center back point of the waist tape, together with the next measurement it helps determine your shoulder slope



Shoulder slope measurement 2:

Now go from the center front point of the waist tape to the center back point of the waist tape, but over your shoulder point as determined by the armscye tape.



Sleeve Measurement: Please measure the front arm length, from the sleeve balance point (just where it tickles) to the wrist, on the front of the relaxed arm.



Neck to shoulder measurement, begin where the neck joins the shoulder, at a point directly below the ear lobe, measure to the armscye marker, this should be about 4.5" on women. The measurement only measures the top of the shoulder and does not extend on top of the arm.



Front Skirt Length:

From waist to floor. Please state over what kind of skirt support this measurement was take - hoop? Corded petticoat? Nothing like that?




Back Skirt Length:

From waist to floor



Total Back Length:

Please measure from the neck to the floor, with the tape running under the waist tape.



Around the Shoulders:

Measure horizontally around the shoulder, about 2" below the

Ordering Drawers?

If so, don't forget to send your measurement from waist to mid-calf!

Contact us:

Originals by Kay:

Kay Gnagey, Proprietress
721 East Wayne Street,
Fort Wayne, IN 46802
(visits by appointment only)
Phone: (260) 422 7617

Email: KGnagey@aol.com
<http://www.Originals-by-Kay.com>