

TUB TO SHOWER DRAIN CONVERSION KIT

Methods Comparison Chart

Current Method Cutting a Wood Subfloor		Current Method Cutting a Concrete Subfloor		Current Method NOT Cutting the Subfloor		Tub to Shower Drain Assembly	
New Plywood	\$30.00	Concrete Mix	\$40.00	Concrete Mix	\$75.00	Concrete Mix	\$40.00
2" PVC Pipe	\$10.00	2" PVC Pipe	\$10.00	2" PVC Pipe	\$10.00	Drain Kit (Retail)	\$139.99
2" Fittings	\$35.00	2" Fittings	\$35.00	2" Fittings	\$35.00	2 Plumber Hours	\$200.00
2" Shower Flange	\$35.00	2" Shower Flange	\$35.00	2" Shower Flange	\$35.00	Strainer	\$30.00
8 Plumber Hours	\$800.00	16 Plumber Hours	\$1,600.00	6 Plumber Hours	\$600.00		
4 Carpenter Hours	\$300.00						
TOTAL:	\$1,210.00	TOTAL:	\$1,720.00	TOTAL:	\$755.00	TOTAL:	\$409.99

