



Full Range Ribbon Loudspeakers

Botticelli & Botticelli X

User's Manual

We would like to congratulate on your purchase of ALSYVOX Botticelli!

Our mission is to make loudspeakers that can bring the musicians in your room by giving the same emotion of a great live performance.

To reach this goal we have experienced that the use of thin diaphragm ribbons and ribbon-planar transducers radiating sound as a dipolar (from both sides) line source is the best approach: the sound vibration is created with all its energy as well as all the details needed to fully respect its message. The diaphragm moves exactly like a layer of air as it is crossed by the sound wave. This gives the sensation of transparency and the sound does not seem to come from the speakers, music is filling all our listening room, or even our house if it is an open loft, with the same coherence and tonal balance that you can experience in the classical center listening position.

All design choices were made to reach our goal, making in house all the critical parts with no cost compromise. With the typical Italian attention to style we have taken top care both in the design and in the quality of each detail.

The company Alsyvox™ audio design

Our designer is an Italian Aerospace Engineer, so Italian Design comes out naturally.

Our speakers are made by hand with love, using exclusive and patented design. All critical parts are made by us, the other parts are sourced from the best worldwide suppliers, typically aesthetical parts are made in Italy, electrical parts are made in Germany, everything is assembled, carefully tested and signed by our chief engineer in our laboratories in Spain.

Our designer started in 1984 by studying the interaction of a dipolar speaker with the room walls using an array of conventional cone speakers mounted on a baffle.

A few years later he studied the technology of ribbon mid-tweeters to extend the line source concept to higher frequencies and in 1994 he designed a ribbon loudspeaker for RES Audio, the Sky 1.

In 2005 he started using neodymium magnets for the Sky 2 to raise the sensitivity of the ribbon speaker.

In 2009 the revolutionary ribbon-planar woofer was born. It reached the same high sensitivity of the neodymium ribbon mid-tweeter thanks to a patented design and a proprietary mix of design skills, covering the technology to make diaphragms, magnet dimensioning, push-pull magnets and steel frame design.

In 2016 he developed a compact mid-tweeter + super-tweeter unit that is seamlessly extending the frequency response beyond human listening threshold to improve sound harmonics and liveliness.

Using these three transducers the result is a breathtaking coherent sound as all the audio frequency band is covered by loudspeakers of the same height, made with the same diaphragm materials and magnets, with a sensitivity of 93dB or more.

Our Technology

All our speakers are dipoles that approximate the ideal concept of a line source. This is giving the best interaction with the room acoustics without the need for heavy room treatment and minimum influence on sound given by the listening position.

Cross-over frequency is low enough to avoid interference and directivity problems, typically at about 700Hz between woofer and mid-tweeter and about 5000Hz between mid-tweeter and super-tweeter. Any phase rotation is limited by the use of moderate slope filtering.

Top quality Mundorf components are used heavily in the cross-over to respect the information contained in the signal, including the very big binding posts.

All our speakers use similar technology with push-pull ribbon (planar) woofer and an exclusive compact unit of ribbon mid-tweeter and ribbon super-tweeter with a frequency response well beyond the audio frequency top limit.

Extremely powerful magnets allow high sensitivity and dynamics.

Our ribbon woofers merge the typical wide surface of planar speakers with the long stroke of cone speakers. This is making an incredibly powerful low frequency response, together with all the typical benefits of planar speakers in terms of speed and micro-dynamics.

The push-pull design used in every transducer is creating low harmonic distortion and the proprietary diaphragms are powered on almost all the surface to create the best control and the reduction of all time domain distortions, the most harmful to the sound.

Heavy gauge steel is used for the structure and it is keeping the distortions related to the frame at the minimum, with the help of the considerable total weight and of our proprietary insulating feet that keep the energy reflected by the constraint to the floor as small as possible. All the other materials used are chosen for their vibration damping behavior like acrylic plastic, PVC and precious solid teak wood.

All these features contribute to the incredible sense of sound out of the air as opposite to the sound out of the speakers, an amazing sense of effortless power and coherence throughout the audio spectrum, so that you can listen to the music and forget about loudspeakers and hi-fi equipment.

Our preferred standard finish is black glossy acrylic with natural teak profiles, but other colors and finishes can be made on request.

Box Content

You have received the speakers in 2 professional flight cases. If you bought Botticelli X there is a third box for the 2 crossovers and 2 thick transparent acrylic bases to be used with silicon feet between base and crossover.

The right speaker case shall be opened first leaving it on top of the other.

Opening the top you will see the speaker with the base laying on top of it as shown in **Photo 2**.

You will also find a cardboard box that contains 7 bolts with 3 special double washers, 1 standard M10 washer, an M10 hexagon wrench, 4 acetal levelers with grub screws and nuts. If you bought Botticelli X you will also find the 6 umbilical cables to connect the crossovers, they are under the speaker.

In the other flight case (left speaker) you will find a cardboard box that contains 7 bolts with 3 special double washers, 1 standard M10 washer, 4 acetal levelers with grub screws and nuts, a microfiber cleaning cloth and a pair of white gloves.

Each flight case is very heavy, about 150Kg each (320Lb) and you will need the help of 3 people to move each of them and heavy duty handles on each side are provided for them.

Of course a cart will help moving them.

Packaging

Save all packaging! We invested a significant amount of money to make a strong and reusable packaging. If you need to transport the speakers they can be shipped safely only in the original packaging.

You may never have to ship or move your loudspeakers, but should the occasion arise, they should not be shipped in any packaging but the original.

Opening the flight case and Assembly

1. Read carefully all the instructions before you start.
2. You will need the help of 3 strong professional movers as the speaker's flight case is very heavy. Everyone shall wear safety shoes and gloves.
3. The 2 flight cases should be delivered in horizontal position one on top of the other (recommended travel position). **Picture 1**

4. Always keep the case you are opening with the other under it or something else with a thickness of 15-20cm to get the right height and put a thick anti-slip rug, rubber mat or carpet with no possibility to shift close to the cases where the speaker will touch the floor when you lift it up. **Picture 1 and Photo 1.**
5. Open the top of the top case and remove it. The speaker is laying flat on the lower part of the case, with binding posts upward. **Picture 2 and Photo 2.** You can see that there is a metal sheet magnetic shield on the tweeter (only if you received the speakers by air), this must be removed and we recommend that you keep it in the PE bubble packaging to avoid sharp edges to be exposed.
6. Push the speaker sliding it till the edge of the speaker closer to the binding posts (lower edge once it will be standing up) is free of the edge of the case. **Picture 3 and Photo 3, be careful to keep the light grey fabric lip between the speaker and the aluminum edge of the flight case.**
7. Clear off the edge of the PE protective film. **Photo 4.**
8. Take one of the bases and notice that 3 special washers and 1 standard washer are already glued in position, take the others and the 7 screws and. **Photo 5.**
9. Prepare the base screwing in the levelers (do not use cups and balls now!) at the 4 angles of the base and putting the screws in the holes in the position as shown in the detail of **Photo 5 and 6.** This means keeping the base in vertical position touching the floor and inserting the 4 top screws with one washer on the outside. The other washers are used as spacer for the optimal vibration transmission between base and speaker and are already in position. The other 3 lower screws can be inserted later.
10. Secure the base to the speaker using the 7 screws, tightening them as much as possible **Photo 7.**
11. Taking the speaker from the edges in a position far away from the base lift it up with one leveler touching the floor well protected by the rug or carpet (**Photo 8**). This rug is not only needed to avoid damages to the floor or the leveler but also to avoid slipping of the leveler as it would make things way more difficult and dangerous; **so be careful, no slipping shall occur.** To lift the speaker

upright 2 strong people are necessary as the total force needed is about 60Kg. Please be also very careful to avoid bending our back as you might hurt yourself, always bend your knees. **Picture 4 and Photo 9**

12. Once the speaker is out of the crate you can move it on the floor using a cart or making it walk by making leverage on side levelers. You can also slide the speaker pushing it in a low position, never close to the top to avoid deflecting the base or tipping over.
13. Once you have placed the speaker in its first trial position you can complete the assembly of the levelers, add one cup with rubber ball at a time lifting a few centimeters on each leveler side. Make sure they are correctly in position before you lower the side and have the speaker on the feet laying in the cups. Here you will need the help of a friend to position the cups while you lift the angle of the speaker's base. Heavy working gloves are strongly recommended to position the cups under the feet and coordination between you and your friend: he should give commands to you to lift and lower the angle with the leveler as he has to make sure not to leave his hands under the leveler.
14. Now you can complete the unpacking taking out the protective film (starting from the lower stripe) and adjust the levelers to have the speakers perfectly vertical. Never use cutters on the film to avoid damages to the speaker! Cotton white gloves are provided to avoid leaving finger prints on the black acrylic surfaces.
15. Connect the speaker cables paying attention to the phase. Here we suggest bi-wiring using identical cables for Tweeter (upper binding posts) and Woofer (lower binding posts), but if you want to use mono-wiring you shall use jumpers (not supplied) to connect in parallel the lower and upper binding post, be careful black with black and red with red!
16. Once both the speakers are in the first trial position and are connected to the amplifier you can start finding the best position as described in the Positioning Chapter.

Amplifier's Choice

94dB effective sensitivity allows the use of low power amplifiers from 7Watt and strong electrical and mechanical design allow the use of high power amplifiers up to 250Watt; of course quality is mandatory as this loudspeaker will cruelly show any deficiency of the components of your system, not only the amplifier, but the source and cables too.

Positioning your ALSYVOX speakers

Positioning in your room requires some move and listen trial, as always, but the line source dipole dispersion will help with minimal room influence on the timbre of the sound.

All sound radiating from the speaker, both directly towards the listener and in any direction to be heard as reflected sound of the room are of the same quality and tonally neutral; so any room will sound quite well. Of course better rooms will sound better and each room will have its best speaker/listener positioning.

Just to start we advise you to position the speakers as symmetrically as possible relatively to the room layout and the listening position with tweeters inside (binding posts outside).

The speakers should be parallel to the rear wall and only later on toed in to be to find the ideal tonal balance and image.

The front wall (behind the speakers) should be between 0.9m (3 feet) and 2.1m (7 feet) away. **The best result is most of the times achieved with a distance equal to 30-40% of the total length of the room.**

Of course what is behind the speaker will highly influence the sound, so avoid any highly absorptive (open door) or highly reflective (window pane) surface.

On the other hand the sound radiated on the plane of the speakers is almost null, so no big influence from reflections of side walls and they can be quite close (not less than 0.15m, 1/2 foot).

The distance between the speakers is not very important, but it should be more than 1.5m (5 feet) and about 0.3m (1 foot) less than the distance from the listener.

The wall behind the listener should be quite absorptive and at least 0.9m (3 feet) away

Trials can be made moving the speakers by 5cm (2") each time and slightly changing the toe in by 1cm (1/2") each time.

In general the best toe in is between 20cm (8") and 25cm (10").

Be careful: These small movements can be performed sliding the speaker on the soft feet with a lot of care. Always apply the force close to the base and do not lift any side to avoid that a leveler could jump out of the cup. Always two people shall do this, one moving the speaker and the other checking the position of the cups under the levelers. You might even push the levelers one after the other moving 1cm each time.

Be careful and do not forget to wear protective gloves.

What you should look for (listen to) is the best bass sound, deep and strongly controlled, and the ideal sound stage, with good focus and depth. No sound should appear to come directly from the speakers even when the recording is totally on the left or right.

Please do not get bored and accept a less than outstanding result here, your new speakers can a must deliver it.

Botticelli or Botticelli X

If you bought **Botticelli** it is possible to upgrade to **Botticelli X** buying the external crossovers. There is a switch in the back below the 4 binding posts. **Switch UP** enables the internal crossover and this is the position that must be used with **Botticelli**, **switch down** bypasses the internal crossover and this is then position that must be used with **Botticelli X**. **(Photo 10)**

In the case of Botticelli X there are 3 umbilical cables that connect the external crossover of each channel to its speaker, to connect them we use 3 Neutrik® SpeakOn® connectors. The connector closer to the woofer (internal) is the **woofer connector (W)**, center connector is for **mid-tweeter (MDTW)** and external connector is for **super-tweeter (STW)**.

Cleaning

Do not use strong chemicals, paint thinners, acetone, alcohol, ammonia or vacuum cleaner to clean the speakers!

Acrylic plastics cover may be cleaned by use of the included microfiber cloth (very slightly humid if necessary). In case of need a mild detergent like hand washing liquid soap can be used.

Never apply pressure when cleaning!

Very light scratches can be eliminated by white car polish and microfiber cloth, deeper scratches will need a professional polishing operation.

Warranty

Many parts, like the black acrylic covers and teak wood profiles, are finished by hand. As a consequence minor defects are totally normal and not covered by our warranty.

ALSYVOX warrants to the purchaser that the Botticelli speakers are free of defects in materials and workmanship for a period of **five years** from date of purchase.

To obtain this warranty, the original purchaser must mail to ALSYVOX within thirty (30) days of the date of purchase this warranty registration form completed, dated and signed by both the purchaser and the selling dealer together with a copy of the bill of sale or other proof of purchase of the product.

ALSYVOX will then validate the warranty to the original purchaser. This warranty is subject to the following conditions and limitation. This warranty applies only to the original purchaser. The warranty is void and inapplicable if the product has been handled other than in accordance with the instructions in the owner's manual, abused or misused, damaged by accident or neglect or in being transported, or the defect is due to the product being repaired or tampered with by anyone other than ALSYVOX or an authorized ALSYVOX repair center.

Speakers are intended for home use only and the warranty will not apply to any outdoor or public performance use.

The warranty does not cover normal maintenance.

ALSYVOX shall not be responsible in any way for consequential or indirect damages or liabilities resulting from the use and operation of the product covered herein or resulting from any breach of this warranty or any implied warranty relating to said product.

The speaker system must be packed in its original shipping container that is in good condition (a new container should be bought if necessary), and shipped to the designated ALSYVOX repair center or factory. All Freight and Insurance costs shall be prepaid by the owner.

A returned product should be accompanied by the warranty and a written description of the defect.

This is a limited warranty only and there are no express or implied warranties of any kind not set forth above, unless your particular state law provides otherwise. There is no implied warranty of fitness for the purpose, nor is there any implied warranty of merchantability.

Warranty info:

Purchase

Date_____

Dealer_____

Purchaser_____

Speaker Serial


Number_____

Send to:

ALSYVOX S.L.


Calle Doctor JJ Domine 4 puerta 2

46011 VALENCIA (SPAIN)




Picture 1


HEAVY RUG
OR RUBBER PAD



Picture 2



Picture 3



Picture 4

NO
SLIPPAGE





Photo 1 - Always keep the other flight case under the one you are opening to reach the right height (or leave something strong under it with about 20cm height)



Photo 2 - Open the top of the flight case, please notice the protective grey lip that prevents touching the aluminum profile when pushing the speaker out of the edge



Photo 3 - Push the speaker till the end with holes for 7 screws (lower side closer to the binding posts) becomes clear of the edge of the case by at least 50mm (2")



Photo 4 – Clear off the edge of the protective PE film



Photo 5 - Put the base in the right orientation (longer steel protrusion at the binding posts side) and position the 4 top screws with 1 washer on the head side and 1 washers on the other side



Photo 6 – Add the other screws making sure they find the hole in the washer at the inside (outside washers missing here but recommended)



Photo 7 - Tighten the screws applying a high torque (recommend 40-50Nm if you have a torque limiter) and screw in the levelers (without cup and ball)



Photo 8- Make sure a thick rug or rubber pad is positioned under the base before you lift it and screw the levelers in if you have not done it already





Photo 9 - Lift the speaker as described in picture 4, minimum 2 strong guys are needed here!



**Photo 10 – Switch in the bypass position (Botticelli X) and 3 Neutrik®
SpeakOn® connectors**