





Produced with: IMAGE CLIP™ Laser Dark

IMAGE CLIP® Laser Light & Laser Dark Heat Transfer Papers are designed for the heat transfer of full color images with color laser printers to light, white, dark, or black fabrics. There is no need to trim the paper. IMAGE CLIP® Transfer Papers are self-weeding and leave no background plastic polymer yet produce a soft, pliable, and highly durable product.



Imaging Sheet
Laser Light



Transfer Sheet
Laser Light



Imaging Sheet
Laser Dark



Transfer Sheet
Laser Dark

- Image should be printed in REVERSE on the Imaging Sheet

TAЭH
REVERSE/MIRRORED

<p>PRINTING:</p>	<ol style="list-style-type: none"> 1. Print the image in reversed/mirrored format onto the 'Imaging Sheet.' 2. Begin by printing on standard paper setting. If toner does not fuse, increase the 'paper weight' setting. (You can check toner fusion by rubbing with a tissue and if tissue comes away clean, the toner is well fused!)
<p>PRE-TRANSFERRING</p>	<p>Prepare the garment/fabric by ensuring the surface is clean, dry, and wrinkle free using a lint brush and your heat press.</p>
<p>TRANSFERRING:</p>	<p>Step 1 IMAGE CLIP® Laser Light:</p> <ol style="list-style-type: none"> 1. Press the printed 'Image Sheet' to the 'Transfer Sheet' and heat press for 20 seconds at 210 to 230° F/ 99 to 110° C using medium pressure (25 to 50 psi/ 1.7 to 3.5 bar). 2. Separate papers while still hot using a smooth even motion. <p>Step 1 IMAGE CLIP® Laser Dark:</p> <ol style="list-style-type: none"> 1. Press the printed 'Image Sheet' to the 'Transfer Sheet' and heat press for 20 seconds at 230 to 250° F/ 110 to 121° C using medium to heavy pressure (40 to 60 psi/ 3 to 4 bar). 2. Separate papers while still hot using a smooth even motion. <p>Step 2 IMAGE CLIP® Laser Light & Laser Dark:</p> <ol style="list-style-type: none"> 1. Press the imaging sheet facedown onto the shirt or substrate. 2. Press 30 seconds at 375° F/190° C using heavy pressure (50 to 60 psi/ 5 bar). 3. Allow to cool to room temperature then peel the backer paper off using a smooth even motion. 4. For best results, "hand" stretch the garment in all directions, then cover with siliconized parchment paper and repress at the conditions listed in Step 2 for 10 seconds.
<p>WASHING:</p>	<p>Turn garment inside out and wash in cold water using a mild detergent. Do not use bleach. Hang dry is highly recommended. Do not iron directly on the transferred area.</p>
<p>STORAGE AND HANDLING:</p>	<p>Store Image Clip® digital transfer papers in a cool, dry area and do not remove from poly bag until you are ready to use.</p>

IMPORTANT: Printers and heat presses vary in accuracy. We have tested our products with numerous printers and presses with excellent results. Nonetheless, we recommend that you test the paper in your equipment to ensure the best results. Neenah's maximum obligation shall be to replace any paper that has proven to be defective.

