
AG8-W-S722

SHOWER DOOR INSTRUCTION




INSTALLATION INSTRUCTION

PLEASE REVIEW THIS ENTIRE MANUAL BEFORE INSTALLATION



All plastic bags are not toys. Keep them out of reach of infants and children to avoid choking hazards.





TOOLS REQUIRED

DESCRIPTION	PART IMAGE
Tape measure	
Spirit level	
Pencil	
Drill bit Ø1/4"(6mm) Ø5/16"(8mm)	
10mm Thick board	
Scissors	
Protective Spectacles	


DESCRIPTION	PART IMAGE
Drill	
Soft Head Hammer	
Cross head Screwdriver	
Inner hexagon Spanner	
Silicone Sealant	
Glove	
Hacksaw	


DETAILED DIAGRAM OF SHOWER DOOR CONPONENTS








INSTALLATION STEPS





































STEP 14


Attach the Roller Assembly (#02) to the glass door (#07) with the wheels facing out.


NOTE: The roller hardware disk can be rotated to


tilt the door glass slightly to create a tight seal with the wall. Make any adjustments after all of the vinyl seals are installed to protect the edge of the door glass.























Apply silicon sealant to the area between the lower water stopper and the floor



NOTE: The surfaces need to be clean and free of debris before applying silicone.

Allow 24 hours for the silicone to fully cure before using the shower.

