TABLE OF CONTENTS

Inoperative Components or Visual Aids Table.	A1
Explanation of Terms/Landing Minima Data	В1
General Information.	C1
Abbreviations	D1
LegendIAP Planview	E1
Legend — IAP Profile	F1
Legend Departure Procedures and Standard Terminal Arrival Charts	G1
Legend Airport Diagram/Sketch	H1
Legend Approach Lighting Systems	11
Frequency Pairing.	1
Index of Terminal Charts and Minimums	K1
IFR Takeoff Minimums, Departure Procedures, and Diverse Vector Area (Radar Vectors)	L1
IFR Alternate Airport Minimums	M1
Radar Minimums	N1
Land and Hold-Short Operations (LAHSO)	01
Hot Spots	P1
Standard Terminal Arrival Charts	Z1
Terminal Charts	Page 1
Rate of Climb/Descent TableInside	Back Cover
Area of CoverageOutside	Back Cover

CORRECTIONS, COMMENTS AND/OR PROCUREMENT

FOR CHARTING ERRORS, OR FOR CHANGES, ADDITIONS, RECOMMENDATIONS ON PROCEDURAL ASPECTS CONTACT:

FAA, Aeronautical Information Services Customer Operations Team 1305 East-West Highway SSMC 4, Suite 4400 Silver Spring, MD 20910-3281 Telephone 1-800-638-8972 Email 9-AMC-Aerochart@faa.gov

FOR PROCUREMENT:

For a list of approved FAA Print Providers, visit our website at http://www.faa.gov/air_traffic/flight_info/aeronav/digital_products/

Frequently asked questions (FAQ) are answered on our website at http://www.faa.gov/go/ais. See the FAQs prior to contact via toll free number or email.

Request for the creation or revisions to Airport Diagrams should be in accordance with FAA Order 7910.4.

GENERAL INFORMATION/INSTRUCTIONS

CHANGE NOTICE (CN) FOR UNITED STATES GOVERNMENT

TERMINAL PROCEDURES PUBLICATION

GENERAL: The United States Terminal Procedures are published in 25 Bound Volumes on a 56-day cycle. This CN is published at the mid 28-day point and contains revisions, additions and deletions to the last complete issue of the 24 volumes covering the conterminous U.S. There is no CN published for airports in the states of Alaska, Hawaii, or Pacific Islands.

OPERATIONAL USE OF THE CHANGE NOTICE: During flight planning or in the case of an in-flight diversion, it is imperative that the pilot first consult this CN before making any decision as to which procedures are current at the airport of intended landing. If the airport of intended landing is not listed in the supplementary information or Index of Charts then the airport information in the basic 24 volumes has not changed.

INDEX OF TERMINAL PROCEDURES: All civil airports which have revised, added or deleted procedures are listed alphabetically by city in the Index. In addition to the airport name, the Index includes the CN page number, the current procedure designation, the affected page and volume number in the last issue of the 24 conterminous US volumes and an indicaton whether the procedure is new, has been deleted, or replaces an existing procedure.

<u>EFFECTIVE DATES</u>: All procedures in this CN are effective on the dates shown on the front cover unless indicated otherwise in the Index, i.e., if the procedure revision is effective on a date other than the CN publication date, this will be noted in the Index instructions by "Effective (date)". This will also be shown on the planview of the affected Chart(s)

CONSULT CURRENT NOTAMS.

TABLE OF CONTENTS

Inoperative Components or Visual Aids Table.	A1
Explanation of Terms/Landing Minima Data	В1
General Information	C1
Abbreviations	D1
Legend — IAP Planview	E1
Legend — IAP Profile	F1
Legend — Departure Procedures and Standard Terminal Arrival Charts	G1
Legend — Airport Diagram/Sketch	H1
Legend — Approach Lighting Systems	11
Frequency Pairing.	1
Index of Terminal Charts and Minimums.	K1
IFR Takeoff Minimums, Departure Procedures, and Diverse Vector Area (Radar Vectors)	L1
IFR Alternate Airport Minimums	M1
Radar Minimums	N1
Land and Hold-Short Operations (LAHSO).	O
Hot Spots	P1
Standard Terminal Arrival Charts	Z1
Terminal Charts	Page 1
Rate of Climb/Descent TableInside	Back Cover

CORRECTIONS, COMMENTS AND/OR PROCUREMENT

FOR CHARTING ERRORS, OR FOR CHANGES, ADDITIONS, RECOMMENDATIONS ON PROCEDURAL ASPECTS CONTACT:

FAA, Aeronautical Information Services Customer Operations Team 1305 East-West Highway SSMC 4, Suite 4400 Silver Spring, MD 20910-3281 Telephone 1-800-638-8972 Email 9-AMC-Aerochart@faa.gov

FOR PROCUREMENT:

For a list of approved FAA Print Providers, visit our website at http://flight_info/aeronav/digital_products/

Frequently asked questions (FAQ) are answered on our website at http://www.faa.gov/go/ais. See the FAQs prior to contact via toll free number or email.

Request for the creation or revisions to Airport Diagrams should be in accordance with FAA Order 7910.4.

INOPERATIVE COMPONENTS OR VISUAL AIDS TABLE (For Civil Use Only)

Straight-in and Sidestep landing minimums published on instrument approach procedure charts are based on full operation of all components and visual aids associated with the particular approach chart being used. Higher minimums are required with inoperative components or visual aids as indicated below. If more than one component is inoperative, each minimum is raised to the highest minimum required by any single component that is inoperative. ILS glideslope inoperative minimums are published on the instrument approach charts as localizer minimums. This table applies to approach categories A thru D and is to be used unless amended by notes on the approach chart. Such notes apply only to the particular approach category(ies) as stated. Category E inoperative notes will be specified when published on civil charts. The inoperative table does not apply to Circling minimums. See legend page for description of components indicated below.

(1) ILS, PAR, LPV, GLS minima

Inoperative Component or Visual Aid	Increase Visibility
All ALS types (except ODALS)	1/4 mile

(2) ILS, LPV, GLS with visibility minima of RVR 1800[†]/2000*/2200*

Inoperative Component or Visual Aid	Increase Visibility			
ALSF 1 & 2, MALSR, SSALR	To RVR 4000† To RVR 4500*			
TDZL or RCLS	To RVR 2400#			
RVR	To ½ mile			

#For ILS, LPV, GLS procedures with a 200 foot HAT, RVR 1800 authorized with use of FD or AP or HUD to DA.

(3) All Approach Types and all lines of minima other than (1) & (2) above

Inoperative Component or Visual Aid	Increase Visibility
ALSF 1 & 2, MALSR, SSALR	½ mile
MALSF, MALS, SSALF, SSALS, SALSF, SALS	1⁄4 mile

(4) Sidestep minima (CAT C-D)

Inoperative Component or Visual Aid to Sidestep Runway	Increase Visibility
ALSF 1 & 2, MALSR, SSALR	½ mile

(5) All Approach Types, All lines of minima

Inoperative Component or Visual Aid	Increase Visibility
ODALS (CAT A-B)	¼ mile
ODALS (CAT C-D)	⅓ mile

TERMS/LANDING MINIMA DATA 17117


25 APR 2019 to

23 MAY 2019

IFR LANDING MINIMA

The United States Standard for Terminal Instrument Procedures (TERPS) is the approved criteria for formulating instrument approach procedures. Landing minima are established for six aircraft approach categories (ABCDE and COPTER). In the absence of COPTER MINIMA, helicopters may use the CAT A minimums of other procedures.

LANDING MINIMA FORMAT



NOTE: The W symbol indicates outages of the WAAS vertical guidance may occur daily at this location due to initial system limitations. WAAS NOTAMS for vertical outages are not provided for this approach. Use LNAV minima for flight planning at these locations, whether as a destination or alternate. For flight operations at these locations, when the WAAS avionics indicate that LNAV/VNAV or LPV service is available, then vertical guidance may be used to complete the approach using the displayed level of service. Should an outage occur during the procedure, reversion to LNAV minima may be required. As the WAAS coverage is expanded, the W will be removed.

RNAV minimums are dependent on navigation equipment capability, as stated in the applicable AFM, AFMS, or other FAA approved document. See AIM paragraph 5-4-5, AC 90-105 and AC 90-107 for detailed requirements for each line of minima.

COLD TEMPERATURE RESTRICTED AIRPORTS

NOTE: A 12°C symbol indicates a cold temperature altitude correction is required at this airport when reported temperature is at or below the published restricted temperature. Pilots familiar with cold temperature procedure in the Notice to Airman Publication (NTAP) and correcting all altitudes from the IAF to the MA final holding altitude do not have to reference the NTAP. Pilots wishing to correct on individual segments must reference the NTAP airport list for affected segments. See Notice to Airman Publication (NTAP) Graphic Notices General for complete list of published airports, temperature, segments, and procedure information. www.faa.gov/air_traffic/publications/notices. Pilots will advise ATC with the required altitude correction when making a correction to any segment other than the final segment. See following Cold Temperature Error Table to make manual corrections.

COLD TEMPERATURE ERROR TABLE HEIGHT AROVE AIRPORT IN EFET

							01117100	J , L , (11()	O 101 11 1						
		200	300	400	500	600	700	800	900	1000	1500	2000	3000	4000	5000
ô	+10	10	10	10	10	20	20	20	20	20	30	40	60	80	90
MΡ	0	20	20	30	30	40	40	50	50	60	90	120	170	230	280
핕	-10	20	30	40	50	60	70	80	90	100	150	200	290	390	490
Б	-20	30	50	60	70	90	100	120	130	140	210	280	420	570	710
E	-30	40	60	80	100	120	140	150	170	190	280	380	570	760	950
Ö	-40	50	80	100	120	150	170	190	220	240	360	480	720	970	1210
Ξ	-50	60	90	120	150	180	210	240	270	300	450	590	890	1190	1500

AIRCRAFT APPROACH CATEGORIES

Aircraft approach category indicates a grouping of aircraft based on a speed of VREF, if specified, or if VREF not specified, 1.3 VSO at the maximum certificated landing weight. VREF, VSO, and the maximum certificated landing weight are those values as established for the aircraft by the certification authority of the country of registry. Helicopters are Category A aircraft. An aircraft shall fit in only one category. However, if it is necessary to operate at a speed in excess of the upper limit of the speed range for an aircraft's category, the minimums for the category for that speed shall be used. For example, an airplane which fits into Category B, but is circling to land at a speed of 145 knots, shall use the approach Category D minimums. As an additional example, a Category A airplane (or helicopter) which is operating at 130 knots on a straight-in approach shall use the approach Category C minimums. See following category limits:

MANEUVERING TABLE

Approach Category	Α	В	C	D	Е
Speed (Knots)	0-90	91-120	121-140	141-165	Abv 165

TERMS/LANDING MINIMA DATA 18312

CIRCLING APPROACH OBSTACLE PROTECTED AIRSPACE

The circling MDA provides vertical obstacle clearance during a circle-to-land maneuver. The circling MDA protected area extends from the threshold of each runway authorized for landing following a circle-to-land maneuver for a distance as shown in the tables below. The resultant arcs are then connected tangentially to define the protected area.

STANDARD CIRCLING APPROACH MANEUVERING RADIUS

Circling approach protected areas developed prior to late 2012 used the radius distances shown in the following table, expressed in nautical miles (NM), dependent on aircraft approach category. The approaches using standard circling approach areas can be identified by the absence of the symbol on the circling line of minima.

Circling MDA in feet MSL		Approach Cate	gory and Circling	, Radius (NM)	
Circling MDA In leer MSL	CAT A	CAT B	CAT C	CAT D	CAT E 4.5
All Altitudes	1.3	1.5	1.7	2.3	4.5

C EXPANDED CIRCLING APPROACH MANEUVERING AIRSPACE RADIUS

Circling approach protected areas developed after late 2012 use the radius distance shown in the following table, expressed in nautical miles (NM), dependent on aircraft approach category, and the altitude of the circling MDA, which accounts for true airspeed increase with altitude. The approaches using expanded circling approach areas can be identified by the presence of the symbol on the circling line of minima.

Circling MDA in feet MSL	Approach Category and Circling Radius (NM)						
Circling MDA in feet MSL	CAT A	CAT B	CAT C	CAT D	CAT E		
1000 or less	1.3	1.7	2.7	3.6	4.5		
1001-3000	1.3	1.8	2.8	3.7	4.6		
3001-5000	1.3	1.8	2.9	3.8	4.8		
5001-7000	1.3	1.9	3.0	4.0	5.0		
7001-9000	1.4	2.0	3.2	4.2	5.3		
9001 and above	1.4	2.1	3.3	4.4	5.5		

Comparable Values of RVR and Visibility

The following table shall be used for converting RVR to ground or flight visibility. For converting RVR values that fall between listed values, use the next higher RVR value; do not interpolate. For example, when converting 4800 RVR, use 5000 RVR with the resultant visibility of 1 mile.

RVR (feet)	Visibility (SM)						
1600	1/4	2400	1/2	3500	5/8	5500	1
1800	1/2	2600	1/2	4000	3/4	6000	11/4
2000	1/2	3000	5/8	4500	7/8		
2200	1/2	3200	5/8	5000	1		

RAD	AR MINIMA		D4/	HAT/			D4/	HAT/	
	RWY GP/TCH/RPI	CAT	DA/ MDA-VIS	HATh/ HAA	CEIL-VIS	CAT	DA/ MDA-VIS	HATh/	
PAR	10 2.5°/42/1000	ABCDE	195 /16	100	(100-1/4)			Visibi	lity
	28 2.5°/48/1068	ABCDE	187 /16	100	(100-1/4)			(RVR	100's of feet)
ASR	10	ABC	560 /40	463	(500-34)	DE	560 /50	463	(500-1)
	28	AB	600 /50	513	(600-1)	CDE	600 /60	513	(600-11/4)
CIR	10	AB	560-11/4	463	(500-11/4)	CDE	560 -11/2	463	(500-1½)
	28	AB	600-11/4	503	(600-11/4)	CDE	600- 1½	503	(600-1½)

25 APR 2019

ಠ

23 MAY 2019

- Visibility in Statute Miles

 All minimums in parentheses not applicable to Civil
 Radar Minima:
 Pilots. Military Pilots refer to appropriate regulations.
 Minima shown are the lowest permitted by established criteria. Pilots should consult applicable directives for their category
- 2. The circling MDA and weather minima to be used are those for the runway to which the final approach is flown- not the landing runway. In the above RADAR MINIMA example, a category C aircraft flying a radar approach to runway 10, circling to land on runway 28, must use an MDA of 560 feet with weather minima of 500-1½.

 NOTE: Military RADAR MINIMA may be shown with communications symbology that indicates emergency frequency monitoring

capability by the radar facility as follows: (E) VHF and UHF emergency frequencies monitored

(V) VHF emergency frequency (121.5) monitored (U) UHF emergency frequency (243.0) monitored

Additionally, unmonitored frequencies which are available on request from the controlling agency may be annotated with an "x".

- A Alternate Minimums not standard. Civil users refer to tabulation. USA/USN/USAF pilots refer to appropriate regulations.
- A NA Alternate minimums are Not Authorized due to unmonitored facility or absence of weather reporting service.
- ▼ Airport is published in the Takeoff Minimums, (Obstacle) Departure Procedures, and Diverse Vector Area (Radar Vectors) tabulation.

to 23 MAY 2019

GENERAL INFORMATION

This publication is issued every 56 days and includes Standard Instrument Approach Procedures (SIAPS), Standard Instrument Departures (SIDs), Standard Terminal Arrivals (STARs), IFR Takeoff Minimums and (Obstacle) Departure Procedures (ODPs), IFR Alternate Minimums, and Radar Instrument Approach Minimums for use by civil and military aviation. The organization responsible for SIAPs, Radar Minimums, SIDs, STARs and graphic ODPs is identified in parentheses in the top margin of the procedure; e.g., (FAA), (FAA-O), (USAF), (USAF), (USN). SIAPS with the (FAA) and (FAA-O) designation are regulated under 14 CFR, Part 97. SIAPs with the (FAA-O) designation have been developed under Other Transaction Agreement (OTA) by private providers and have been certified by the FAA. See 14 CFR, Part 91.175 (a) and the AIM for further details. 14 CFR, Part 91.175 (g) and the Special Notices section of the Chart Supplement contains information on civil operations at military airports.

The FAA uses an internal numbering system on all charts in the TPP. This Approach and Landing (AL) number is located on the top center margin of the chart followed by the organization responsible for the procedure in parentheses, e.g., AL-18 (FAA), AL-227 (USAF).

CHART CURRENCY INFORMATION

Date of Latest Revision 09365

The Date of Latest Revision identifies the Julian date the chart was added or last revised for any reason. The first two digits indicate the year, the last three digits indicate the day of the year (001 to 365/6) in which the latest revision of any kind has been made to the chart.

FAA Procedure	Orig 31DEC09 +	Procedure Amendmen
Amendment Number	→ Amdt 2B 12MAR09 →	Effective Date

The FAA Procedure Amendment Number represents the most current amendment of a given procedure. The Procedure Amendment Effective Date represents the AIRAC cycle date on which the procedure amendment was incorporated into the chart. Updates to the amendment number & effective date represent procedural/criteria revisions to the charted procedure, e.g., course, fix, altitude, minima, etc.

NOTE: Inclusion of the "Procedure Amendment Effective Date" will be phased in as procedures are amended. As this occurs, the Julian date will be relocated to the upper right corner of the chart.

MISCELLANEOUS

★ Indicates a non-continuously operating facility, see Chart Supplement.
For Civil (FAA) instrument procedures, "RADAR REQUIRED" in the planview of the chart indicates that ATC radar must be available to assist the pilot when transitioning from the en route environment. "Radar required" in the pilot briefing portion of the chart indicates that ATC radar is required on portions of the procedure outside the final approach segment, including the missed approach. Some military procedures also have equipment requirements such as "Radar Required", but do not conform to the same charting application standards used by the FAA.
Distances in nautical miles (except visibility in statute miles and Runway Visual Range in hundreds of feet). Runway Dimensions in feet. Elevations in feet. Mean Sea Level (MSL). Ceilings in feet above airport elevation. Radials/bearings/headings/courses are magnetic. Horizontal Datum: Unless otherwise noted on the chart, all coordinates are referenced to North American Datum 1983 (NAD 83), which for charting purposes is considered equivalent to World Geodetic System 1984 (WGS 84).

Terrain is scaled within the neat lines (planview boundaries) and does not accurately underlie not-to-scale distance depictions or symbols.

GENERAL INFO 19003

STANDARD TERMINAL ARRIVALS AND DEPARTURE PROCEDURES

The use of the associated codified STAR/DP and transition identifiers are requested of users when filing flight plans via teletype and are required for users filing flight plans via computer interface. It must be noted that when filing a STAR/DP with a transition, the first three coded characters of the STAR and the last three coded characters of the DP are replaced by the transition code. Examples: ACTON SIX ARRIVAL, file (AQN.AQN6); ACTON SIX ARRIVAL, EDNAS TRANSITION, file (EDNAS.AQN6). FREEHOLD THREE DEPARTURE, file (FREH3.RBV), FREEHOLD THREE DEPARTURE, ELWOOD CITY TRANSITION, file (FREH3.EWC).

PROCEDURE EQUIPMENT REQUIREMENTS

Users will begin to see Performance-Based Navigation (PBN) Requirements and Equipment Requirements prominently displayed in separate, standardized notes boxes. For procedures with PBN elements, the PBN box will contain the procedure's navigation specification(s); and, if required: specific sensors or infrastructure needed for the navigation solution; any additional or advanced functional requirements; the minimum Required Navigation Performance (RNP) value and any amplifying remarks. Items listed in this PBN box are REQUIRED for the procedure's PBN elements. The Equipment Requirements Box will list non-PBN requirements. On procedures with both PBN elements and equipment requirements, the PBN requirements box will be listed first. The publication of these notes will continue incrementally until all charts have been amended to comply with the new standard.

PBN Requirements Box ——	From WINRZ, LIBGE: RNAV-1 GPS, RNAV-1GPS from MAP to YARKU.
Equipment Requirements Box — —	DME required for LOC only.
Standard Procedure Notes Box-	▼ Circling to Rwy 25 NA at night. #For inop MALSR increase S-ILS 16R all cats visibility to 2½ SM.

PILOT CONTROLLED AIRPORT LIGHTING SYSTEMS

Available pilot controlled lighting (PCL) systems are indicated as follows:

- 1. Approach lighting systems that bear a system identification are symbolized using negative symbology, e.g., (a), (b), (c)
- Approach lighting systems that do not bear a system identification are indicated with a negative "0" beside the name.
 A star (*) indicates non-standard PCL, consult Chart Supplement, e.g., 0*

To activate lights, use frequency indicated in the communication section of the chart with a ● or the appropriate lighting system identification e.g., UNICOM 122.8 ●, ♠, ◆

KEY MIKE

7 times within 5 seconds
5 times within 5 seconds

3 times within 5 seconds


Highest intensity available

Medium or lower intensity (Lower REIL or REIL-off) Lowest intensity available (Lower REIL or REIL-off)

FUNCTION

AAUP	Attention All Users Page	GPS	Global Positioning System
ADF	Automatic Direction Finder	GS	
	Air Defense Identification Zone		
	Automatic Flight Information		
,	Service		Height above Touchdown
ΔΙς			
AL3F			
4.0	Sequenced Flashing Lights		Head-up Guidance System
AP	Autopilot System		High Intensity Runway Lights
APCH	Approach		Head-up Display
APP CON	Approach Control		Initial Approach Fix
ARR		ICAO	International Civil Aviation
ASOS	Automated Surface Observing		Organization
	System	IF	Intermediate Fix
ASR/PAR	Published Radar Minimums at	IM	Inner Marker
	this Airport	INOP	Inoperative
ASSC	Airport Surface Surveillance	INT	Intersection
	Systems	K	
ΔTIS	Automatic Terminal Information		
,	Service		Local Area Augmentation
ALINICOM	Automated UNICOM	LV	System
		IDA	
AWO3			Localizer Type Directional Aid
	System	Ldg	
AZ			Low Intensity Runway Lights
BC			Lateral Navigation
BND	Bound	LOC	
C	Circling		Localizer Performance
CAT	Category	LPV	Localizer Performance with
	Counter Clockwise		Vertical Guidance
CDI	Course Deviation Indicator	LR	Lead Radial. Provides at least
Chan			2 NM (Copter 1 NM) of lead to
	Coded Instrument Flight		assist in turning onto the
CII 1	Procedures		intermediate/final course.
CID			
CIR			
CLINC DEL	Clearance Delivery	MALS	Medium Intensity Approach
CNF			Light System
CTAF	Common Traffic Advisory	MALSF	Medium Approach Lighting
	Frequency		System with Sequenced Flasher
CW	Clockwise	MALSR	Medium Intensity Approach
D-ATIS	Digital-Automatic Terminal		Light System with RAIL
	Information Service	MAP	Missed Approach Point
DA	Decision Altitude	MDA	Minimum Descent Altitude
	Departure End of Runway	MIRL	Medium Intensity Runway Lights
	Decision Height		Middle Marker
	Distance Measuring Equipment		Minimum Reception Altitude
DTHP	Displaced Threshold		
	Displaced Threshold		
ELEV			Non-directional Radio Beacon
EMA5	Engineered Material Arresting		National Flight Database
	System	NM	
	Final Approach Fix	NoPT	No Procedure Turn Required
	Flight Director System		(Procedure Turn shall not be
FM	Fan Marker		executed without ATC
FMS	Flight Management System		clearance)
GBAS	Ground Based Augmentation	ODALS	Omnidirectional Approach
	System		Light System
GCO		ODP	Obstacle Departure Procedure
	Ground Based Augmentation	OM	
OLO	System Landing System		Precision Approach Radar
		rar.	FLECISION ANDROGEN KOGOT
CD	Ok I d		
GP	Glidepath Ground Point of Interception		Precision Runway Monitor

OLI ILIOAL II II O	ADDREVIATION
R	Padial
	Radio Altimeter setting height
DAII	Radio Alimeter setting neight
RAIL	
D.C.I.G.	Lights
RCLS	Runway Centerline Light
	System
REIL	
RF	
RLLS	Runway Lead-in Light System
RNAV	
RNP	
	Performance
RPI	Runway Point of Intercept(ion)
RRL	Runway Remaining Lights
Rwy	
RVR	
S	Straight-in
SALS	Short Approach Light System
SALSF	Short Approach Lighting System
	with Sequenced Flashing Lights
SSALF	Simplified Short Approach Lighting
	System with Sequenced Flashers
SSALR	Simplified Short Approach
	Light System with RAIL
SSALS	Simplified Short Approach
	Lighting System
SDF	Simplified Directional Facility
SM	Statute Mile
SOIA	Simultaneous Offset Instrument Approach
TAA	
TAC	
TCH	Threshold Crossing Height
	(height in feet Above
	Ground level)
TDZ	Touchdown Zone
TDZE	
	Touchdown Zone and Runway
	Centerline Lighting
TDZL	Touchdown Zone Lights
THR	
THRE	
TODA	
TORA	
TR	
VASI	
	Indicator
VCOA	Visual Climb Over Airport
VDP	
VGSI	
VNAV	
WP/WPT	Wide Area Augmentation System
VVF/ VVF1	waypoini (kinav)




23 MAY 2019

2

25 APR 2019

25 APR 2019 to

23 MAY 2019



ರ


23 MAY 2019


PROFILE VIEW

Three different methods are used to depict either electronic or vertical guidance: "GS", "GP", or "VDA".

- 1. "GS" indicates that an Instrument Landing System (ILS) electronic glide slope (a ground antenna) provides vertical guidance. The profile section of ILS procedures depict a GS angle and TCH in the following format: GS 3.00°.
- 2. "GP" on GLS and RNAV procedures indicates that either electronic vertical guidance (via Wide Area Augmentation System - WAAS or Ground Based Augmentation System - GBAS) or barometric vertical guidance is provided. GLS and RNAV procedures with a published decision altitude (DA/H) depict a GP angle and TCH in the following format: GP 3.00°.
- 3. An advisory vertical descent angle (VDA) is provided on non-vertically guided conventional procedures and RNAV procedures with only a minimum descent altitude (MDA) to assist in preventing controlled flight into terrain. On Civil (FAA) procedures, this information is placed above or below the procedure track following the fix it is based on.

 Absence of a VDA or a note that the VDA is not authorized indicates that the prescribed obstacle clearance surface is not along and the VDA must not be used that NDA VDA is desirated in the fillusing formatty. 300° surface is not clear and the VDA must not be used below MDA. VDA is depicted in the following format: 🚄 On Copter procedures this is depicted in the following format: $\frac{27.30^{\circ}}{HCH 20}$ TCH 55







Visual Descent Point (VDP)

Visual segment below MDA/DA is clear of obstacles on 34:1 slope. (Absence of shaded area indicates 34:1 is not clear.)

NON-VERTICALLY GUIDED CONVENTIONAL PROCEDURES AND RNAV PROCEDURES WITH MDA ONLY





2400 ALTITUDES PROFILE SYMBOLS Glide Slope/Glidepath Intercept Altitude and final approach fix for vertically guided approach Visual Flight Path Mandatory Altitude 3000 Recommended Altitude

5000 Mandatory Block Minimum Altitude procedures 3000 Altitude 4300 Maximum Altitude Visual Descent Point (VDP) Note: Facilities and waypoints are depicted as a solid vertical line while fixes and intersections are depicted as a dashed vertical Compulsory:

VOR

√ VOR

APR 2019

ರ

23 MAY 2019

VOR/DME 4

Non-Compulsory:

VOR/DME 🤇

protection range

(STAR)

Underline indicates

no voice transmitted

on this frequency

Coordinates

Frequency.

Frequency

LEGEND STANDARD TERMINAL ARRIVAL (STAR) CHARTS DEPARTURE PROCEDURE (DP) CHARTS Applies to both STAR and DP Charts unless otherwise noted. RADIO AIDS TO NAVIGATION **ROUTES** 4500 MEA-Minimum Enroute Altitude *3500 MOCA-Minimum Obstruction Clearance Altitude VORTAC DMF 270° Departure Route - Arrival Route NDB/DME TACAN (65) Mileage between Radio Aids, Reporting Points, NDB and Route Breaks - Transition Route Radial line and value ♦ VORTAC • DME R-275 -NDB/DME ••••• Lost Communications Track 0 **TACAN** NDB Visual Flight Path (DP) V12 180 Airway/Jet Route Identification O LOC □ LOC/DME LMM, LOM DP Holding Pattern STAR Holding Pattern (Compass locator) (shown when installation is offset from its normal position off the end of the runway.) (DP) Marker Beacon (IAS) (IAS) Holding pattern with max. restricted airspeed Localizer Course (175K) applies to all altitudes (210K) applies to altitudes above 6000' to and SDF Course including 14000' SPECIAL USE AIRSPACE (T) indicates frequency (Y) TACAN must be placed R-Restricted W-Warnina in "Y" mode to receive R-352 P-Prohibited A-Alert Identifier distance information MOA-Military Operations Area ORLANDO **ALTITUDES** ORL /:=:. 112.25 (T) Chan 59 (Y) 5500 2300 <u>4800</u> Geographic N28°32.56′ \W81°20.10′-Position Mandatory Altitude Minimum Altitude Maximum Altitude L-19, H-5 DME or (Cross at) (Cross at or above) (Cross at or below) TACAN Enroute Chart Channel 15000 Altitude change at other Reference 12000 than Radio Aids (STAR) Block Altitude Waypoint PRAYS -Name INDICATED AIRSPEED N38° 58.30′ W89° 51.50′ 250K 120K 175K -112 7 CAP 187.1°-56.2 Mandatory Minimum Maximum Radial-Distance Airspeed Airspeed Airspeed (Facility to Reference Facility Waypoint) **AIRPORTS** Elevation FIXES/ATC REPORTING REQUIREMENTS (H) Heliport Joint ·Civil Military Civil-Military → DME Mileage Airports not served by the procedure (when not obvious) shown in screened color (STAR)

Reporting Points N00°00.00' W00°00.00'

Identifier

▲ Fix-Compulsory and

△ Non-Compulsory Position Report

DME fix WAYPOINT



WAYPOINT (Non-Compulsory)





FLYOVER POINT

X Computer Navigation Fix (CNF) - No ATC Function N00°00.00' W00°00.00'

-O- Civil Military MISCELLANEOUS

Changeover Point

Distance not to scale (DP) International Boundary (DP)

Air Defense Identification Zone

Takeoff Minimums and (Obstacle) Departure Procedures entry published. (DP)

ಠ

23 MAY 2019

23 MAY 2019 2 25 APR 2019

INSTRUMENT APPROACH PROCEDURES (CHARTS)

M/AIRPORT SKETCH

		AIRPOR	T DIAGRAM
Runways			
Hard Surface	Other Than Hard Surface	Stopways,Taxiw Parking Areas, Water Runways	rays, Displaced Threshold
× × Closed Runway	××× Closed Surface	: : Under Construction	Meta l Surface
e.g., BAk not app l i	(12, MA-1A etc	ific arresting gea ., shown on airpo lots. Military Pilo ations.	ort diagrams,
uni-di	rectional	bi-directional	} Jet Barrier
ARRESTING	S SYSTEM	(EMAS)	
REFERENC	E FEATURES		
Runway Ho	olding Position <i>I</i>	Markings	
		#	
		<i></i>	
			•
Airport Bed	acon #		☆ 🚱
Runway			_
			_
		d Rotating Beaco I will be used and	

further identified as TWR.

A fuel symbol is shown to indicate 24-hour self-serve fuel available, see appropriate Chart Supplement for information.

Runway length depicted is the physical length of the runway (end-to-end, including displaced thresholds if any) but excluding areas designated as stopways.

A D symbol is shown to indicate runway declared distance information available, see appropriate Chart Supplement for distance information.

Helicopter Alighting Areas 🕀 🛨 🖽 🛕 🛨 Negative Symbols used to identify Copter Procedures landing point.....

NOTE:

Landmark features depicted on Copter Approach insets and sketches are provided for visual reference only.

Runway Threshold elevation.....THRE 123 Runway TDZ elevation......TDZE 123 -0.3% DOWN (shown when runway slope is greater than or equal to 0.3%)

NOTE:

Runway Slope measured to midpoint on runways 8000 feet or longer.

U.S. Navy Optical Landing System (OLS) "OLS" location is shown because of its height of approximately 7 feet and proximity to edge of runway may create an obstruction for some types of aircraft.

Approach light symbols are shown in the Flight Information Handbook.

Airport diagram scales are variable.

True/magnetic North orientation may vary from diagram to diagram

Coordinate values are shown in 1 or ½ minute increments. They are further broken down into 6 second ticks, within each 1 minute increments.


Positional accuracy within ±600 feet unless otherwise noted on the chart.

NOTE:

All new and revised airport diagrams are shown referenced to the World Geodetic System (WGS) (noted on appropriate diagram), and may not be compatible with local coordinates published in FLIP. (Foreign Only)

Runway Weight Bearing Capacity/or PCN Pavement Classification Number is shown as a codified expression.

Refer to the appropriate Supplement/Directory for applicable codes e.g., RWY 14-32 PCN 80 F/D/X/U S-75, D-185, 2S-175, 2D-325




SCOPE

Airport diagrams are specifically designed to assist in the movement of ground traffic at locations with complex runway/taxiway configurations. Airport diagrams are not intended to be used for approach and landing or departure operations. For revisions to Airport Diagrams: Consult FAA Order 7910.4.

ಠ

23 MAY 2019




LEGEND 15344

INSTRUMENT APPROACH PROCEDURES (CHARTS) APPROACH LIGHTING SYSTEM - UNITED STATES

Approach lighting and visual glide slope systems are indicated on the airport sketch by an identifier, (2), (V) etc.

A dot " • " portrayed with approach lighting letter identifier indicates sequenced flashing lights (F) installed with the approach lighting system e.g., (A). Negative symbology, e.g., (A) , (V) indicates Pilot Controlled Lighting (PCL).

PRECISION APPROACH (P) PATH INDICATOR PAPI Too low Slightly low On correct approach path 0000 Too high Slightly high



PULSATING VISUAL APPROACH

CAUTION: When viewing the pulsating visual approach slope indicators in the pulsating white or pulsating red sectors, it is possible to mistake this lighting aid for another aircraft or a ground vehicle. Pilots should exercise caution when using this type of system.

(V_1) "T"-VISUAL APPROACH SLOPE INDICATOR "T"-VASI "T" ON BOTH SIDES OF RWY ALL LIGHTS VARIABLE WHITE. CORRECT APPROACH SLOPE-ONLY CROSS BAR VISIBLE. UPRIGHT "T" - FLY UP INVERTED "T" - FLY DOWN. RED "T"- GROSS UNDERSHOOT.

25 APR 2019

ಠ

23 MAY 2019

Legend: □ White ■ Red

(V_4) TRI-COLOR VISUAL APPROACH SLOPE INDICATOR TRCV On Glide Path Green Below Glide Path

CAUTION: When the aircraft descends from green to red, the pilot may see a dark amber color during the transition from green to red.

(V_5) ALIGNMENT OF ELEMENTS SYSTEMS APAP On Glide Path Below Glide Path Above glide path Painted panels which may be lighted at night. To use the system the pilot positions the aircraft so the elements are in alignment.

FREQUENCY PAIRING TABLE

TACAN	VHF	TACAN	VHF	TACAN	VHF
CHANNEL	FREQUENCY	CHANNEL	FREQUENCY	CHANNEL	FREQUENCY
1 <i>7</i> Y	108.05	40X	110.30	88Y	114.15
18X	108.10	40Y	110.35	89Y	114.25
18Y	108.15	41Y	110.45	90Y	114.35
19Y	108.25	42X	110.50	91Y	114.45
20X	108.30	42Y	110.55	92Y	114.55
20Y	108.35	43Y	110.65	93Y	114.65
21Y	108.45	44X	110. <i>7</i> 0	94Y	114.75
22X	108.50	44Y	110. <i>75</i>	95Y	114.85
22Y	108.55	45Y	110.85	96Y	114.95
23Y	108.65	46X	110.90	97Y	115.05
24X	108.70	46Y	110.95	98Y	115.15
24Y	108.75	47Y	111.05	99Y	115.25
25Y	108.85	48X	111.10	100Y	115.35
26X	108.90	48Y	111.15	101Y	115.45
26Y	108.95	49Y	111.25	102Y	115.55
27Y	109.05	50X	111.30	103Y	115.65
28X	109.10	50Y	111.35	104Y	11 <i>5.75</i>
28Y	109.15	51Y	111.45	105Y	115.85
29Y	109.25	52X	111.50	106Y	115.95
30X	109.30	52Y	111.55	107Y	116.05
30Y	109.35	53Y	111.65	108Y	116.15
31Y	109.45	54X	111. <i>7</i> 0	109Y	116.25
32X	109.50	54Y	111 <i>.75</i>	110Y	116.35
32Y	109.55	55Y	111.85	111Y	116.45
33Y	109.65	56X	111.90	112Y	116.55
34X	109.70	56Y	111.95	113Y	116.65
34Y	109.75	80Y	113.35	114Y	116. <i>75</i>
35Y	109.85	81Y	113.45	11 <i>5</i> Y	116.85
36X	109.90	82Y	113.55	116Y	116.95
36Y	109.95	83Y	113.65	11 <i>7</i> Y	11 <i>7</i> .05
37Y	110.05	84Y	113 <i>.75</i>	118Y	11 <i>7</i> .15
38X	110.10	85Y	113.85	119Y	117.25
38Y	110.15	86Y	113.95		
39Y	110.25	87Y	114.05		

CLIMB/DESCENT TABLE 10042

25 APR 2019 to 23 MAY 2019

INSTRUMENT TAKEOFF OR APPROACH PROCEDURE CHARTS RATE OF CLIMB/DESCENT TABLE

(ft. per min)

A rate of climb/descent table is provided for use in planning and executing climbs or descents under known or approximate ground speed conditions. It will be especially useful for approaches when the localizer only is used for course guidance. A best speed, power, altitude combination can be programmed which will result in a stable glide rate and altitude favorable for executing a landing if minimums exist upon breakout. Care should always be exercised so that minimum descent altitude and missed approach point are not exceeded.

	approach point are not exceeded.												
DE:	CLIMB												
	and nths)		60	90	120	150	180	210	240	270	300	330	360
	2.0	210	210	320	425	530	635	743	850	955	1060	1165	1275
	2.5	265	265	400	530	665	795	930	1060	1195	1325	1460	1590
$\lceil \rceil$	2.7	287	287	430	574	717	860	1003	1147	1290	1433	1576	1 <i>7</i> 20
Ė	2.8	297	297	446	595	743	892	1041	1189	1338	1486	1635	1 <i>7</i> 83
VERT-CAL	2.9	308	308	462	616	<i>77</i> 0	924	1078	1232	1386	1539	1693	18 <i>47</i>
	3.0	318	318	478	637	797	956	1115	1274	1433	1593	1 <i>7</i> 52	1911
P A T H	3.1	329	329	494	659	823	988	1152	1317	1481	1646	1810	1975
Ι.	3.2	340	340	510	680	850	1020	1189	1359	1529	1699	1869	2039
AZGLE	3.3	350	350	526	701	876	1052	1227	1402	1 <i>577</i>	1752	1927	2103
E	3.4	361	361	542	722	903	1083	1264	1444	1625	1805	1986	2166
	3.5	370	370	555	745	930	1115	1300	1485	1670	1860	2045	2230
	4.0	425	425	640	850	1065	1275	1490	1700	1915	2125	2340	2550
	4.5	480	480	715	955	1195	1435	1675	1915	2150	2390	2630	2870
	5.0	530	530	795	1065	1330	1595	1860	2125	2390	2660	2925	3190
	5.5	585	585	880	1170	1465	1755	2050	2340	2635	2925	3220	3510
	6.0	640	640	960	1275	1595	1915	2235	2555	2875	3195	3510	3830
	6.5	690	690	1040	1385	1730	2075	2425	2770	3115	3460	3805	4155
	7.0	745	745	1120	1490	1865	2240	2610	2985	3355	3730	4105	4475
	7.5	800	800	1200	1600	2000	2400	2800	3200	3600	4000	4400	4800
	8.0	855	855	1280	1 <i>7</i> 10	2135	2560	2990	3415	3845	4270	4695	5125
	8.5	910	910	1360	1815	2270	2725	3180	3630	4085	4540	4995	5450
	9.0	960	960	1445	1925	2405	2885	3370	3850	4330	4810	5295	5775
	9.5	1015	1015	1525	2035	2540	3050	3560	4065	4575	5085	5590	6100
	0.0	1070	1070	1605	2145	2680	3215	3750	4285	4820	5355	5890	6430

CLIMB/DESCENT TABLE 10042