# With the **Nee-Vo App** you can

and get notified





fuel supplier



Nee-Vo

Consult your

NEVER RUN OUT OF FUEL AGAIN

level of your tanks


# **Nee-Vo App Tutorial**

Create Your Account Add a Tank Tank View, Explained Historical Usage Chat, Explained Contact Page, Explained Tank Details and Settings Add/Remove Authorized Users Reset Your Password


#### Edit the Nee-Vo App For internal use only

Edit Contact Page Edit App Theme Assign App Theme to Branch Share Primary Activation Code Revoke Ownership

# **CREATE YOUR ACCOUNT**



To get started, click Create account



Then choose your preferred measurement system

Fill in the required information

Then click Create

#### **CREATE YOUR ACCOUNT**

Continued...




This document, together with the <u>Privacy Policy</u>, (the "Terms of Use") is a contract between You ("you") and Otodata Wireless Network Inc. ("us" or "we") concerning your use of the Otodata mobile application (the "Application"). By accepting these Terms of Use and by continuing to use the Mobile Application and our services, you agree to all the terms and condition stated in these Terms of Use. The use of updated versions of this Mobile Application may be subject to new or additional Terms of Use. The Application allows a device compatible with the application and its related systems to report and display information to the user. The device may be installed on your tank or reservoir by us or our affiliates or authorized by us for use to connect your tank to the services we offer you, including the functionalities of the Application, namely the remote monitoring and displaying of tank levels and software updates or customized features. (the "Services").

#### 1. Conditions of use

You are only allowed to make use of the Application and the Services if you comply with the following:


- You shall only use the Services and the Application when it is safe to do so, and you shall only use them in compliance with the law, safety regulations and these Terms of Service. You are solely responsible for the use of the Services and the Application.
- If third parties use the Services and Application through your user account, you shall ensure that they only use the Services and the Application when it is safe to do so, and in compliance with the law and these Terms of Use. These Terms of Use apply to all users of your Connected Device. You are responsible and liable for all activities of users of your Connected Device, including all


5.
Review the Terms of
Use. Then click Accept



# **ADD A TANK**

Continued...






Take a moment to name the tank. Then click **Done** 

You can also Skip this step.


If skipped, tank name will be monitor's serial number.

# **ADD A TANK**


Continued...




4.
You have now successfully added your first tank!




# HISTORICAL USAGE CHART, EXPLAINED



A handy chart that illustrates your usage over a 3-month period



# **TANK DETAILS AND SETTINGS**




Delivery scheduled

Be notified if a delivery has been scheduled by your fuel

See following page for more

# **ADD/REMOVE AUTHORIZED USERS**




Authorized Users are people the *account owner* has chosen to share tank-level data with

They will have the ability to offer or revoke access to their tank's data from other users

Note: Authorized Users (i.e. secondary users) can view fill levels, set level-alerts, and request a fill (if feature is activated) via the Nee-Vo app. They cannot add or remove authorized users.

To add an Authorized User, can click the <u>Plus button</u> in the bottom right corner of your screen




Then click the <u>Generate a</u> new authorization code to create shareable code

# **ADD/REMOVE AUTHORIZED USERS**

Continued...




Once a Share Code has been generated, you can click the green button to copy/paste the code and send it to a friend




Alternately, you can return to the previous screen and copy/paste the code from here

### **RESET YOUR PASSWORD**




On the login screen, click Forgot Password



Then input the email address associated with your Nee-Vo App account and click Send temporary password


# **RESET YOUR PASSWORD**

Continued...



Click  $\underline{\mathsf{OK}}$  and check your emails


Be sure to check your Spam and Junk folders.



Copy/paste the temporary password from the email you received and use it to log in

# **RESET YOUR PASSWORD**

Continued...



Upon logging in, you will be required to update your password

Because the temporary password was sent by email, it is no longer considered "secure". So, an update is necessary.

Input the *temporary* password in the Old password field

Then input the *new, secure* password in the two fields below

Finally, click Save