

Vector Smart[™] North American Mosquito East (NAM-e) Kit



NAMe-K-001

Vector Smart[™] North American Mosquito East (NAM-e) Kit CO-DIAGNOSTICS, INC.



CO-DIAGNOSTICS, INC. | 2401 Foothill Dr., Ste D, Salt Lake City, UT 84109 USA

Product Information Document CO-DIAGNOSTICS INC. Vector Smart™ North American Mosquito East (NAM-e) (NAMe-K-001) Instructions for Use

Table of Contents

1	In	Intended Use2					
2	Ki	Kit Components					
3	VECTOR SMART™ NORTH AMERICAN MOSQUITO EAST (NAM-E) Storage, Handling, & Disposal2						
4	Warnings and Precautions						
5	Ba	ackground Information	4				
	5.1	West Nile virus (WNV)	4				
	5.2	St. Louis Encephalitis virus (SLEV)	4				
	5.3	Eastern Equine Encephalitis virus (EEEV)	4				
	5.4	Mosquito Selection, Collection, Storage, and Handling Recommendations	5				
6	Pi	oduct Description	5				
7	Μ	laterials and devices (required but not provided)	5				
8	Pi	ocedure	6				
	8.1	Mosquito Collection	6				
	8.2	Mosquito Preparation	6				
	8.3	Vector Smart™ NAMe Reagent Setup	7				
	8.4	Reaction Setup	7				
	8.5	PCR Instrument Setup	8				
9	D	ata Analysis	8				
	9.1	Validity of Test Runs	9				
	9.2	Interpretation of Results	9				
10)	Troubleshooting	10				
	10.1	Stability	11				
	10.2	User Errors	11				
	10.3	Invalid Results/Inconclusive Results	11				
11	L	Limitations	12				
12	<u>)</u>	Quality Control	13				
13 Technical assistance		Technical assistance	13				
14	ŀ	References	13				
15 Trademarks and disclaimers		Trademarks and disclaimers	13				
16	5	Legend of Package Symbols	14				





Manufacturer: Co-Diagnostics, Inc 2401 S Foothill Dr. Ste D Salt Lake City, UT 84109



Phone: +1 (801) 438-1036 Email: info@codiagnostics.com Website: <u>www.codiagnostics.com</u>

1 INTENDED USE

The **Vector Smart™ North American Mosquito East (NAM-e)** kit is a research use only multiplex test, based on real-time PCR (qPCR) technology, for the simultaneous qualitative detection of the West Nile virus (WNV), St. Louis encephalitis virus (SLEV), and Eastern equine encephalitis virus (EEEV) specific RNA in mosquitoes.

For research use only (RUO). Not for use in diagnostics procedures.

2 KIT COMPONENTS

Lid Color	Component	Symbol	Catalog Number	Description	Amount
Black Vector Smart™ NAM-e Master Mix		MM	NAMe-MM- 001	Proprietary blend of CoPrimers™ and PCR reagents	1x500µL (100 reactions)
Red	Vector Smart™ NAM-e Positive Control	PC	NAMe-PC- 001	Proprietary blend of target templates	1x500µL (100 reactions)
Clear	Nuclease-Free Water	NTC	GEN-NF-001	DNase/RNase-free water	1x500μL (100 reactions)
Orange	Extraction Control	EC	NAMe-EC-001	Proprietary blend of target	1x500µL (100 reactions)

Kit Catalog Number is NAMe-K- 001. Contact Sales at 801-438-1036 ext. 02 or at www.codiagnostics.com/contact/ to order.

3 VECTOR SMART[™] NORTH AMERICAN MOSQUITO EAST (NAM-E) STORAGE, HANDLING, & DISPOSAL

- The Vector Smart[™] North American Mosquito East (NAM-e) kit is shipped on dry ice. The components of the kit should arrive frozen. If one or more of the components are not frozen upon receipt, or are compromised during shipment, contact your distributor for assistance.
 O Upon receipt of kit, laboratory should follow internal procedures for quality control.
- > All components should be stored below -20°C upon arrival to prevent degradation of reagents.



- Repeated thawing and freezing of components (more than four times) should be avoided, specifically the master mix, as this might affect the performance of the assay. The reagents should be frozen in multiple aliquots if they are to be used intermittently.
- Co-Diagnostics recommends storage between +2°C and +8°C should not exceed a period of 4 hours.
- If you work in an area prone to power outages, it is recommended to have a back-up generator for your freezer as well as a temperature data log system to ensure that the Vector Smart™ NAM-e test kit remains frozen at -20°C.
- > Protect Master Mix from light.
- > Expired products should not be used, as the integrity of the components cannot be guaranteed.
- The product is not a biological waste. See Safety Data Sheets (SDS) for hazard classification. Disposal should be in accordance with applicable regional, national, and local laws and regulations.

4 WARNINGS AND PRECAUTIONS

WARNING!



Read this *Instructions for Use* carefully before using the product. Before first use check the components for:

- Integrity
- Frozenness upon arrival

Users should pay attention to the following:

- Use of this product should be limited to personnel instructed and trained in the techniques of real-time PCR.
- Samples should always be treated as infectious and/or biohazardous. Use standard precautions.
- Wear protective gloves, lab coat, and eye protection when handling samples. Always wear gloves when handling kit components.
- > Always use DNase/RNase-free disposable pipette tips with filters.
- Use segregated working areas for sample preparation, reaction setup, and amplification/detection activities. The workflow in the laboratory should proceed in a unidirectional workflow. To prevent contamination, change PPE between areas.
- Store and extract positive materials (specimen, controls, and amplicons) separately from other reagents. Dedicate supplies and equipment to separate working areas and do not move them from one area to another.
- ➤ Consult appropriate Safety data Sheets (SDS) for safety. The SDS for the Vector Smart[™] NAM-e test kit is provided with the shipment. If not provided with shipment the SDS can be retrieved from Co-Diagnostics website at the link: <u>http://codiagnostics.com/resources/safetydata-sheets/</u>
- > Do not open the reaction tubes/plates post amplification.



- Do not autoclave reaction tubes/plates after the PCR, since this will not degrade the amplified nucleic acid and will pose a risk to the laboratory area to contamination.
- > Do not use components of the kit that have passed expiration date.
- > Discard sample and assay waste according to your local safety regulations.

5 BACKGROUND INFORMATION

5.1 West Nile virus (WNV)

- About: West Nile virus (WNV) is the leading cause of mosquito-borne disease in the continental United States. The virus was introduced to the US in 1999 after the New York outbreak where there were 62 cases and 6 fatalities. The WNV had other outbreaks in the US from time to time.
- > The virus: is an enveloped, single-stranded (+) RNA virus part of the *Flaviviridae* family.
- Transmission: Most commonly spread to people by the bite of an infected Culex spp. mosquito, in special Culex pipiens in the northern half of the US, Culex quinquefasciatus in the southern states, and Culex tarsalis in the western states where it overlaps with Cx pipiens and quinquefasciatus. Cases of WNV occur during mosquito season, which starts in the summer and continues through fall. 94% of human cases are reported from July through September, however cases of WNV can happen year-round. The transmission can also happen through blood transfusion and organ donation. Since 2003, the US blood supply and organs are tested for WNV year-round. For more information consult: West Nile Virus in the United States: Guidelines for Surveillance, Prevention, and Control (Division of Vector-Borne Diseases, 2013).

5.2 St. Louis Encephalitis virus (SLEV)

- About: Saint Louis encephalitis virus (SLEV) is an arbovirus that is largely spread through the US, but periodic outbreaks and epidemics have primarily occurred in the Mississippi Valley and along the Gulf Coast. In temperate areas of the United States, SLEV disease cases occur primarily in the late summer or early fall. In southern states, cases can occur year-round (Saint Louis Encephalitis, n.d.)
- > The virus: is an enveloped, single-stranded (+) RNA virus part of the *Flaviviridae* family.
- Transmission: SLEV is spread to people by the bite of Culex species mosquito. The most common vectors are Culex pipiens, Culex quinquefasciatus, Culex tarsalis, and Culex nigripalpus.

5.3 Eastern Equine Encephalitis virus (EEEV)

- About: Eastern equine encephalitis (EEEV) is an arbovirus that is associated with both human and equine encephalitis. The EEEV is a summertime infection found in the east of the US, usually around freshwater hardwood swamps in the Atlantic, Gulf coast areas, and Great Lakes region... It is more common in rural areas (Eastern Equine Encephalitis, n.d.). Approximately 30% of people with Eastern Equine Encephalitis die and many survivors have ongoing neurologic problems (Eastern Equine Encephalitis, n.d.).
- The virus: is an enveloped, single-stranded (+) RNA virus part of the Alphavirus genus of the family Togaviridae.
- Transmission: EEEV is maintained in a cycle between Culiseta melanura mosquitoes and avian hosts in freshwater hardwood swamps. Cs. melanura is not considered to be an important



vector of EEEV to humans because it feeds almost exclusively on birds. Transmission to humans requires a bite from infected mosquito species, after biting an infected bird. Mosquito species known to "bridge" transmission from infected avian hosts to uninfected animal hosts includes *Aedes, Coquillettidia,* and *Culex* species (Eastern Equine Encephalitis, n.d.).

5.4 Mosquito Selection, Collection, Storage, and Handling Recommendations

The sample selection, collection, storage, and handling play an essential part on the performance of nucleic acid assays. Thus, valuable information is presented here to help laboratories develop better procedures for the analysis of results and troubleshooting other problems. For more information visit the CDC website in the following addresses:

- CDC, West Nile virus: https://www.cdc.gov/westnile/index.html
- CDC, Saint Louis Encephalitis: https://www.cdc.gov/sle/index.html
- CDC, Eastern Equine Encephalitis Virus Disease: https://www.cdc.gov/easternequineencephalitis/index.html

6 PRODUCT DESCRIPTION

The **Vector Smart™ NAM-e** kit is a research use only multiplex test, based on real-time polymerase chain reaction technology. It tests for the presence or absence of ribonucleic acid (RNA) of the West Nile, St. Louis encephalitis, and Eastern equine encephalitis viruses. Specifically, in *Culex spp.* and *Aedes spp.* mosquitos. This test is designed for mosquito surveillance purposes which are especially important for public health officials working towards mosquito abatement.

The Vector Smart[™] NAM-e test includes an internal control to identify possible qPCR inhibition, confirm the integrity of the reagents, and verify the quality of sample extraction. The Vector Smart[™] NAM-e test also includes a positive control which includes three synthetic RNA molecules carrying sequences that are homologous to West Nile (WNV), St. Louis encephalitis (SLEV), and Eastern equine encephalitis (EEEV) viruses and are targeted by this multiplex assay. Positive controls represent a source of cross-contamination. Precautions should be taken to prevent and minimize the risk.

CoPrimers[™] included in the Vector Smart[™] NAM-e test are:


- > CoPrimers[™] that are targeting WNV are labelled with the FAM[™] fluorophore
- > CoPrimers[™] that are targeting SLEV are labelled with the Quasar® 670 fluorophore
- > CoPrimers[™] that are targeting EEEV are labelled with the CAL Fluor® Orange 560 fluorophore
- CoPrimers[™] that are targeting the Mosquito Enhancer of the Internal Positive Control (IPC) DNA are labelled with CAL Fluor[®] Red 610 fluorophore

7 MATERIALS AND DEVICES (REQUIRED BUT NOT PROVIDED)

- Appropriate 4-channel real-time PCR instrument, compatible with the fluorophores used in this test.
- > Appropriate nucleic acid extraction system or kit
- Vortex mixer
- Centrifuge with a rotor for 2 mL reaction tubes
- Pipettes (adjustable)
- Pipette tips with filters (disposable)



- Powder-free gloves (disposable)
- ≻ Ice
- Biosafety cabinet, ideally BSL-2 facility
- > Copper coated premium BB's (for extraction) or another sample homogenizer



8 PROCEDURE

8.1 Mosquito Collection

Mosquitos are typically collected using commercially available mosquito traps, such as the CDC miniature light trap Model 512. The mosquitoes collected from a single collection site are often called a pool. The pool of mosquitoes is sexed and speciated based upon the specific target being tested for.

After being sexed and speciated, the mosquitoes are either stored frozen or can go through the extraction process. After extraction, the mosquito extract can then be tested or stored frozen, preferably at -70°C for future testing.

8.2 Mosquito Preparation

The quality of the extraction of the RNA from the samples is essential for the performance of **Vector Smart™ NAM-e**. The extraction protocol to be followed should be performed following manufacturer's instructions or an internally validated protocol. The suitability of the nucleic acid extraction procedure for use with **Vector Smart™ NAM-e** must be validated by the user.

To prepare the mosquitoes before the extraction, place a pool of 10-50 mosquitoes in a snap top 1.5 or 2.0 mL microcentrifuge tube, and add 10 μ L per mosquito of (TE Buffer with 1% Triton X-100) to the tube, and 1 copper coated premium BB (for 19 or less mosquitoes) or 2 BB's (for 20 or more mosquitoes). Vortex the tube for 5 minutes, and centrifuge at 21,380 x g for 5 minutes. Remove the supernatant and continue with the extraction.



An important step to ensure that the extraction process is working is to add 5 μ L of **Extraction Control**, after the lysis step or when instructed by the extraction kit, into every sample pool being extracted. Due to the variability of mosquito populations, this will ensure that there is consistent amplification of the Mosquito Internal Positive Control (IPC).

For additional information and technical support regarding preparation please contact Technical support 1-801-438-1036 ext. 04.

PID-1039-00

INNOVATING REVOLUTIONARY MOLECULAR DIAGNOSTICS Page 6 of 14





If your sample preparation system is using washing buffers containing ethanol, make sure to eliminate any traces of ethanol prior to elution of the nucleic acid. Ethanol is a strong inhibitor of real-time PCR.

The use of carrier RNA is crucial for extraction efficiency and stability of the extracted nucleic acid.

Do not use buffer from other products besides the buffer in the sample extraction kit. Products like the RAMP grinding buffer is known as a PCR inhibitor and should not be used (Burkhalter, Horiuchi, Biggerstaff, Savage, & Nasci, 2014).

8.3 Vector Smart[™] NAM-e Reagent Setup

- When preparing reagents, clean all working surfaces with a fresh 10% bleach solution followed by molecular grade alcohol, or another equivalent method of cleaning that disinfects and degrades nucleic acids.
- All Vector Smart[™] NAM-e Master Mix, Positive Control (PC), Extraction Control (EC), no template control nuclease-free water (NTC), and sample tubes should be vortexed for 3 seconds, and briefly spun down before using to ensure properly mixed reagents, and to remove any condensation or residue from the lids.
- > Thaw all reagents and samples on **ice**, or on a cold block, before starting setup.

8.4 Reaction Setup

- 8.4.1 Every reaction setup should include enough reaction wells for the number of samples and at least one positive and one NTC (**# samples + 2 = total reaction wells needed**). Example: 5 samples to test + 1 PC well + 1 NTC well = 7 total reaction wells.
- 8.4.2 All pipetting should be done on **ice**, if possible. Pipetting of PC and sample elution is recommended to be done in a separate area, if possible, or at a separate time, than the Master Mix and NTC. Change pipette tips in-between sample elution and change pipette tips after pipetting each component. Pipet PC last if possible, to avoid contamination events.
- 8.4.3 Pipet 5 μL of **Master Mix** into each well being used in an appropriate optical plate or optical reaction tube (example: CoDx Box real-time PCR instrument uses 48-well reaction tubes).
- 8.4.4 Pipet 5 μL of sample (elution from nucleic acid extraction) or 5 μL of a control (NTC and Positive Control) to the appropriate well(s). At least one positive and one NTC control must be included in each run.
- 8.4.5 Seal the reaction plate with an optical adhesive film or the reaction tubes with appropriate lids.
- 8.4.6 Place plate or tubes into real-time PCR instrument in the correct orientation and start run.



8.5 PCR Instrument Setup

- 8.5.1 For basic information regarding setup and programming of the different real-time PCR instruments, please refer to the user manual of the respective instrument. For programming instructions questions regarding the use of other real-time PCR instruments please contact the Laboratory 801-438-1036 ext.04 or at www.codiagnostics.com/contact/.
- 8.5.2 If using Co-Diagnostics Inc. CoDx Box, contact the Laboratory 801-438-1036 ext. 04 or at <u>www.codiagnostics.com/contact/</u> for the template file for download. The template file comes pre-programmed with the PCR instrument setup described in this section. When not using a template, or using another device, use the settings outlined below to program the PCR instrument.
 - 8.5.2.1 In order to achieve optimal performance from the test, it is important to make sure that the instrument is compatible with the conditions outlined below.
- 8.5.3 Define the following settings:

Reaction Volume	10 μL
Ramp Rate	Default
Passive Reference	None

8.5.4 Program PCR instrument with the cycling conditions below:

	Stage	Cycles	Temperature	Time
Reverse Transcription	Activation	1	45°C	15 minutes
Initial Denaturation	Hold	1	95°C	2 minutes
Amplification		50	95°C	3 seconds
Amplification	Cycling	50	55°C	32 seconds

- 8.5.1 Ensure that PCR instrument being used is compatible with fluorophores below. Some devices may not have options for the quencher. If needing help or have questions, contact Co-Diagnostics Inc. technical support at 801-438-1036 ext. 04 or at: www.codiagnostics.com/contact/.
- 8.5.2 Define the fluorescence detectors (dyes):

Target	Target Detector Name		Quencher	
WNV specific RNA	WNV	FAM™	BHQ® - 1	
SLEV specific RNA	SLEV	Quasar® 670	BHQ® - 1	
EEEV specific RNA	EEEV	CAL Flour® Orange 560	BHQ® - 2	
Mosquito Internal Positive Control	IPC	CAL Flour® Red 610	BHQ® - 2	

> When the run is finished, ensure that the run file is saved.

9 DATA ANALYSIS

For basic information regarding data analysis on specific real-time PCR instruments please refer to the user manual of the respective instrument.

PID-1039-00

Product Information Document CO-DIAGNOSTICS INC. Vector Smart™ North American Mosquito East (NAM-e) (NAMe-K-001) Instructions for Use

9.1 Validity of Test Runs

- 9.1.1 Valid Test Run
- > Check to see that both the positive and no template control passed.

Control Type	Control Name	Purpose of Control	WNV	SLEV	EEEV	Mosquito Internal Control (NAM.18s)
	WNV (FAM™)		+	+	+	+
NAM-e Positive	SLEV (Q®670)	Verifies the performance of the				
Control	EEEV (CF®560)	master mix				
	IPC (CF®610)					
No Template Master Mix + Control Water		Verifies the reagents are free of contamination	-	-	-	-

9.1.1.1 The following control conditions must be met:

- > If controls pass, interpret the sample results.
- 9.1.2 Invalid Test Run
 - 9.1.2.1 If any of the controls fail, the run is invalid. Document the run and initiate troubleshooting.

9.2 Interpretation of Results

Once the controls have passed, the unknown samples can be interpreted based on three possible outcomes:

- > Positive
- > Negative
- > Inconclusive

A **Positive** result will show an amplification curve or cycle threshold value for WNV, SLEV, or EEEV. The cut off value should be determined by in house validation testing. However, internal studies have shown rare primer-dimer formation or other non-specific amplification at 45 cycles. This fact can be attributed to the nature of the CoPrimers[™] (Satterfield, 2014) (Poritz & Ririe, 2014). The amplification of the RNaseP (IPC) shows that the extraction was successful.

A **Negative** result will show no amplification for WNV, SLEV, or EEEV; The absence of a curve for NAMe indicates a negative result ONLY when the RNaseP (IPC) marker is positive.

An **Inconclusive** result will result if any of the controls fail. See troubleshooting.



The interpretation of results can be translated to the following table:

Marker	WNV	SLEV	EEEV	Mosquito Internal Positive Control (NAM.18S)	Vector Smart™ Positive Control	No Template Control (NTC) Vector Smart™ Master Mix + Nuclease-Free Water	Result
	+	+	+		NAM-e +		
	-	-	-				NAM-e -
	+	-	-				
E	-	+	-		WNV- SLEV+ EEEV -		
adinç	-	-	+		WNV- SLEV- EEEV+		
Instrument Reading	+	+	-		WNV+ SLEV+ EEEV-		
Instrur	- + +				WNV- SLEV+ EEEV+		
	+	-	+		WNV+ SLEV- EEEV+		
				Fail Pass			
	Any Result		Pass Pass		Pass	Inconclusive: See Troubleshooting	
					Fail		
The cut off value will determine what results are to be considered positive or negative. It should be determined by the assay development.							

10 TROUBLESHOOTING

Co-Diagnostics Inc. values customer feedback and we would like to be informed of any issues with the **Vector Smart™ NAM-e kit**, even if the recommended steps for troubleshooting solve the issue. To give feedback please fill out the Customer Feedback Form by visiting <u>www.codiagnostics.com/contact/feedback/</u>



10.1 Stability

Real-time and accelerated shelf-life and in-use stability studies are currently under testing. Presently, the expiration date of this product has been established as 12 months. It is not recommended to use expired kit reagents, doing so may lead to inaccurate results.

Always use the most recent version of this document for updates as more stability information will be added when studies are completed.

10.2 User Errors

Good Laboratory Practices for Molecular Biology Diagnostics (Viana & Wallis, 2011) are necessary for the use of this product. This product is not intended to be used by untrained personnel.

It is essential for the user to have some molecular biology experience and be familiar with proper pipetting technique to prevent errors, such as splashes, crossover contamination, and errors on volume selection. Pipette tips must be replaced after every pipetting. Gloves must be replaced often. Equipment, such as pipettes and real-time PCR instruments, should be calibrated when applicable.

90 minutes of online training for Good Laboratory Practices for Molecular Genetics Testing (Centers for Disease Control and Prevention, 2017) is available at the CDC website at the following link https://www.cdc.gov/labtraining/training-courses/good-lab-practices-molecular-genetics-testing.html

10.3 Invalid Results/Inconclusive Results

10.3.1 Vector Smart[™] NAM-e Positive Control not amplifying

No amplification from the PC could be the result of one or multiple factors, such as:

- Pipetting errors (pipetting control into the wrong well, missing a well, pipetting inadequate amount of reagent),
- > Incorrect placement of plates or tubes into the real-time PCR instrument,
- ➤ Vector Smart[™] NAM-e Master Mix or Vector Smart[™] NAM-e Positive Control degradation (result of reagents being at temperatures above -20°C for an extended period),
- Use of expired reagents,
- > or the wrong reagents being used.

Without further evidence, it is best to disregard the results from the samples and re-test by reamplification. If the positive control fails again, then an investigation should be conducted to identify possible causes for error, and the test must be reprocessed from extraction or not, depending on the investigation results and risks identified in the process. If failure of the positive control happens a third time after re-extraction and re-amplification, open a new **Vector Smart™ NAM-e Positive Control** or **Master Mix**, and retest. If still failing, please contact Co-Diagnostics Inc. technical support by calling 801-438-1036 ext. 04 visiting <u>www.codiagnostics.com/contact/</u>.

10.3.2 NAM.18S (Mosquito Internal Positive Control (IPC)) not amplifying in samples

No amplification from the NAM.18s (IPC) channel could be the result of one or multiple factors, such as:

- > Not enough nuclear material in the sample,
- > PCR inhibitors such as: ethanol and heparin,
- > the extraction was performed incorrectly,

Product Information Document CO-DIAGNOSTICS INC. Vector Smart™ North American Mosquito East (NAM-e) (NAMe-K-001) Instructions for Use

or the extraction kit used is not compatible or has a step that eliminates a crucial element for extraction.

Negative results cannot be trusted and re-testing by re-amplification should be performed. If the IPC fails again, then samples should be re-extracted and re-amplified. If it fails after a third time an investigation should be conducted to identify possible causes for error. If the cause for the error is clear, the test can either be signed out as **inconclusive** due to either PCR inhibitors being present or not enough nuclear material being present. If the cause for error is unclear, contact Co-Diagnostics Inc. technical support by calling 801-438-1036 ext. 04 or by visiting <u>www.codiagnostics.com/contact/</u>.

10.3.3 No Template Control showing amplification

Amplification of NAM-e in a No Template Control indicates contamination in one or more of the reagents, incorrect placement of plate or tube into the real-time PCR instrument, or pipetting errors.

None of the results can be trusted and re-testing by re-amplification should be performed. If the NTC fails again, then an investigation should be conducted to identify possible causes for error, and the test must be reprocessed from extraction or not, depending on the investigation results and risks identified in the process. If failure of the NTC, after re-extraction and re-amplification, happens a third time, open a new nuclease-free water and retest. If still failing, please contact Co-Diagnostics Inc. technical support by calling 801-438-1036 ext. 04 or by visiting <u>www.codiagnostics.com/contact/</u>.

11 LIMITATIONS

- This product is intended for research use only. Not intended for use in clinical diagnostics for its performance for diagnostic applications has not be established.
- Strict compliance with this document is required for optimal results. Please, always use the most recent version of this document. This can be downloaded for free at: <u>www.codiagnostics.com/resources/instructions-for-use/</u> or by visiting <u>www.codiagnostics.com/contact/</u>.
- Use of this product is to be limited to trained and instructed personnel in real-time PCR techniques.
- Good laboratory practices are essential for the proper performance of this assay. It is also recommended that upon receipt of reagents a test run be performed to check the integrity, and performance of the reagents prior to testing on samples.
- Appropriate collection, transport, storage, and processing procedures of samples are required for optimal results.
- Do not use the Vector Smart[™] NAM-e kit components directly on the specimens collected. Perform an appropriate nucleic acid extraction prior to using this assay.
- > The presence of PCR inhibitors may cause false negatives or invalid results.
- Potential mutations of the target regions of the WNV, SLEV, and EEEV genome covered by this test kit may result in failure to detect the presence of the pathogens.



12 QUALITY CONTROL

In accordance with the Co-Diagnostics Inc.'s ISO 13485-certified Quality Management System, each lot of **Vector Smart™ NAM-e** kit is tested against predetermined specifications to ensure consistent product quality.

13 TECHNICAL ASSISTANCE

For technical assistance, please contact our Technical Support:

- Website: <u>http://codiagnostics.com/contact/</u>
- Email: info@codiagnostics.com
- Phone: 801-438-1036 ext. 04

14 REFERENCES

- Burkhalter, K. L., Horiuchi, K., Biggerstaff, B. J., Savage, H. M., & Nasci, R. S. (2014). Evaluation of a Rapid Analyte Measurement Platform and Real-Time Reverse-Transcriptase Polymerase Chain Reaction Assay West Nile Virus Detection System in Mosquito Pools. *Journal of the American mosquito Control Association, 30*(1), 21-30.
- Centers for Disease Control and Prevention. (2017, Oct 27). CDC Laboratory Training: Good Laboratory Practices for Molecular Genetics Testing. Retrieved Mar 5, 2019, from CDC: https://www.cdc.gov/labtraining/training-courses/good-lab-practices-molecular-geneticstesting.html
- Division of Vector-Borne Diseases. (2013, Jun 14). West Nile Virus in the United States: Guidelines for Surveillance, Prevention, and Control. Retrieved from CDC: https://www.cdc.gov/westnile/resources/pdfs/wnvGuidelines.pdf
- *Eastern Equine Encephalitis*. (n.d.). Retrieved from Centers for Disease Control and Prevention: https://www.cdc.gov/easternequineencephalitis/index.html
- Poritz, M. A., & Ririe, K. M. (2014). Getting Things Backwards to Prevent Primer Dimers. *The Journal of Molecular Diagnostics*, *16*(2), 159-162. doi:10.1016/j.jmoldx.2014.01.001
- Saint Louis Encephalitis. (n.d.). Retrieved from Centers for Disease Control and Prevention: https://www.cdc.gov/sle/index.html
- Satterfield, B. (2014, Mar). Cooperative primers: 2.5 million-fold improvement in the reduction of nonspecific amplification. *The Journal of Molecular Diagnostics, 16*(2), 163-173. doi:10.1016/j.jmoldx.2013.10.004
- Viana, R. V., & Wallis, C. L. (2011). Good Clinical Laboratory Practices (GLCP) for Molecular Based Tests Used in Diagnostic Laboratories. In D. I. Akyar, *Wide Spectra of Quality Control* (pp. 29-52). InTech. Retrieved from http://www.intechopen.com/books/wide-spectra-of-qualitycontrol/goodclinical-laboratory-practice-gclp-for-molecular-based-tests-used-in-diagnosticlaboratories

15 TRADEMARKS AND DISCLAIMERS

Registered names, trademarks, etc. used in this document, even if not specifically marked as such, are not to be considered unprotected by law.

Product not available in all countries.

PID-1039-00



16 LEGEND OF PACKAGE SYMBOLS

REF	Catalog number
LOT	Batch Code
CAP	Cap color
COMP	Component
CONT	Content/Volume
NUM	Number
	Use-by-date
∑ ∑	Contains sufficient for X tests/ reactions X = 20 sample size X = 100 regular size
类	Protect from light
-20 °C	Temperature limit
(i	Consult Instructions for Use
NON STERILE	Non-Sterile product – Do not sterilize
	Manufacturer
RUO	Research Use Only