




ASSEMBLING THE BOOST BAR


www.manplow.com/assembly-instructions

1. Assemble Leg between Hips

This will be a snug fit. You may need to use tools. Do not over tighten. This is your Tension Control. You will want the leg to swing up and down with some resistance. You can adjust tension at any time.



BOOST BAR ANATOMY



2. Handle Leg Sleeves

When adding Boost Bar to existing equipment, remove the blade and handle connectors. Slide Handle Leg Sleeves over bottom of handle legs. With new equipment, assemble Handle Top U and Handle Legs first. Slide the Handle Leg Sleeve over the Handle Leg.

Assembled Handle Leg Sleeve to Handle Leg



3. Attach blade to Handle Legs


Follow assembly instructions. Hand tighten. Tighten with tools after Cross Bar is attached.

4. Attach the Cross Bar to U Handle

The Cross Bar attaches on the user side (opposite the blade) of the Handle Legs. Follow hardware sequence.



Hardware Sequence



Assembled Boost Bar



5. Tighten all fasteners with tools.

Tighten firmly but do not over tighten.

Boost Mode

ACTIVATED

With the Boost Bar's Foot down, you are in Boost Mode!

The safer way to lift and toss snow!



Boost Mode

DEACTIVATED

Bring the Leg up and over the cross bar until you're ready to Boost.

Keep the Foot out from under foot!



www.manplow.com/assembly-instructions