MODEL 122 Control Panel

Single phase, duplex alternating pump control with override.

The Model 122 control panel is designed to alternately control two 120, 208, or 240 VAC single phase pumps in water and sewage installations. The alternating action equalizes pump wear. In addition to the alternating pump control, this system provides override control should either pump fail. If an alarm condition occurs, an alarm switch activates the audio/visual alarm system. Common applications include pump chambers, sump pump basins, irrigation systems and lift stations.

PANEL COMPONENTS

- **Enclosure** measures 10 X 10 X 6 inches (25.4 X 25.4 X 15.24 cm). Choice of NEMA 1 (steel for indoor use), or NEMA 4X (ultraviolet stabilized thermoplastic with removable mounting feet for outdoor or indoor use). **Note:** Options selected may increase enclosure size and change layout.
- 2. Magnetic Motor Contactors control pumps by switching electrical lines.
- HOA Switches for manual pump control (mounted on circuit board). 3.
- Control Circuit Board provides pump control and alternation.
- Green pump Run Indicator Lights (mounted on circuit board).
- Circuit Breakers (optional) provide pump disconnect and branch circuit 6. protection.
- Ground Lugs
- Float Status Indicator Lights (mounted on circuit board).
- Control and Alarm Power Indicator Lights (mounted on circuit board)
- 10. Auxiliary Alarm Contact, form C (mounted on circuit board).

NOTE: Schematic is located inside the panel on enclosure cover.

STANDARD ALARM PACKAGE

- 11. Red Alarm Beacon provides 360° visual check of alarm condition. Note: NEMA 1 style utilizes a door mounted indicator in lieu of a beacon.
- 12. Alarm Horn provides audio warning of alarm condition (83 to 85 decibel rating).


Note: NEMA 1 style utilizes an internally mounted buzzer in lieu of horn.


- 13. Exterior Alarm Test/Normal/Silence Switch allows horn and light to be tested and horn to be silenced in an alarm condition. Alarm automatically resets once alarm condition is cleared.
- 14. Horn Silence Relay (mounted on circuit board).

NOTE: other options available.

FEATURES

- Entire control system (panel and switches) is UL Listed to meet and/or exceed industry safety standards
- Dual safety certification for the United States and Canada
- Standard package includes three 20' control switches or EZconnex® float system
- Complete with step-by-step installation instructions
- Five-year limited warranty





Model Shown 1221W114X6A





PO Box 1708, Detroit Lakes, MN 56502 1-888-DIAL-SJE • 1-218-847-1317 1-218-847-4617 Fax

	7	122]		7 [7		7 [6A	
	MC	DDEL 12	2					_ '		_						
		RM PACKAG														
		select options or no alarm package IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII														
		LOSURE RA		3 103	.	SIICIIC	Je Switc	,, iuse	, rea ligi	it, & i						
		Indoor, NEMA)												
	W =	Weatherproof	f, NÈMA 4	X (eı	ngineere	d ther	moplas	tic)								
		RTING DEVIC	_													
		magnetic mot magnetic mot				40V										
		IP FULL LOA	D AMPS													
\vdash		0-7 FLA 7-15 FLA														
		15-20 FLA														
	3 =	20-30 FLA														
		IP DISCONNE														
\vdash		no pump disc circuit breake		seled	t START	ING I	DEVICE	ontion	9 ahov	e)						
	•	on our broake			0V (seled						oove)					
	FLOAT SWITCH APPLICATION															
		L = pump dow														
		EZconnex® floa	at switch s	syste	m (selec	t 34 o	r 35 opt	tion)								
	X = r	no floats														
	OPTIONS Listed below —															
*		If you sele			OSURE re of the			two ★★	options							
	CODE	DESCRIPTION							0005	DEO	ODIDTION					
_ `		Red beacon or	alv / no aud	io				г	_		CRIPTION Cord in lieu	ı of 20' (ner float)			
ш	IA	(must select "0			age)			į			cord in lie		,			
	1C	Horn only / no						<u> </u>			cord in lieu		.,			
□ ⋆.	- 3∆	(must select "0 Alarm flasher	" for alarm	раска	age)			F			cord in lieu SignalMa			(pe	er float)	
		Manual alarm r	eset					<u>ו</u>			SignalMa					r float)
	★ 4A	Redundant off						-			sor Float® sor Float®					
	4B	(select Option Red redundant						F			sor Float®					i)
		(must select O						Ī	17F	Sen	sor Float®	Mini / ex	kternally w	veighte	ed 🛦 (pe	r float)
	4D	Redundant off		ole st	17			Ē			sor Float®			per flo	at)	
	★ 5A	(must select 4A) Thermal cutout	. , ,					F			d lag seled rth float to			ınction	from lag	
_	A 0/1	(for pumps w/th						Ī		TOA	A (Test/Off	/Automa	tic) switch			ın lights
		Seal failure circ			or (2 wire)			г	101		ugh door i			shee o	nd numn	run liahte
	ъΑ	Auxiliary alarm (included as sta		ıın C				L	190		4 (Hand/O ugh door ।			nico di	na punip	run ngintə
<u></u> ★	8A	Elapsed time n	-							Doc	r mounted	d pump r	un indicat			
⊟ *		Event (cycle) c							340		onnex® 4- ling plug 3		, w/10' flo	ats (3)	/pipe cla	mp,
□ *	9_A	Pump overload specify ampera		ımber	9 followe	d bv le	tter "A"	Г	34E		iing plug 4 onnex® 4-		, w/10' flo	ats (3)	/pipe cla	mp,
		Example: 912A	-			,		_		sea	ling plug 🔰	k				•
*	\vdash	0-25 FLA							34G		onnex® 4- ling plug ≯		, w/20' flo	ats (3)	/pipe cla	mp,
*	<u>ப</u> 10E	25-30 FLA Lockable latch	- NEMA 4X	(Г	34F		onnex® 4		, w/20' flo	ats (3)	/pipe cla	mp,
		Lockable latch						_		sea	ling plug 🔰	ķ				
		Lightning arres		oump	circuit brea	aker)		Ę			onnex® 4-connex® 4-					
 *		Anti-condensat NEMA 1 alarm						F			onnex® 4-			. ,		
		NEMA 4X alarr	-					Ì			onnex® 4-					
\square *	14B	Main disconne		-		_										
		door, non-fused	•			positio	n,									
		door interlock i	-		11 <i>)</i>											
*[0-20 FLA (total		,												
*[20-60 FLA (tota	al of both p	umps)											