

Spray Tans

Everything you need to know to get the most out of your Spray Tan!

Preparation

- Shower, shave, and exfoliate, and moisturize the night before your service.
- Arrive with little to no makeup, perfume, deodorant, oils, or lotions on your skin.
- Wear dark, comfortable, loose-fitting clothing to your service.

After a Spray Tan

- Allow your spray tan to develop between 8 and 24 hours before showering. (Your tan will look better and fade more nicely if you let it develop for the full 24 hours.)
- Stay as dry as possible. Avoid all soap, water, and sweating until the tan fully develops.
- If you need to sanitize your hands, only put a small amount of sanitizer on the palms of your hands. Do not rub over the backs of your hand.
- When you are ready to shower, do not use any exfoliating products or tools such as washcloths, loofahs, or razers.
- After showering, pat your skin dry with a towel. Rubbing your skin will cause the tan to fade faster.
- To help maintain your tan, moisturize your skin 1-2 time(s) per day.

Additional Information

- If you need a manicure or pedicure, get them done at least one day before your service.