


# PARKING ACCESS CARD


## ENTRY AND EXIT QUICK REFERENCE GUIDE



SUCCESS PARKING SOLUTIONS, LLC  
 400 West Capital Ave., Suite 1700  
 Little Rock, Arkansas 72201  
 Office: (501) 683-9600  
 Toll Free: (877) 683-5001  
[support@successparkingsolutions.com](mailto:support@successparkingsolutions.com)  
[www.successparkingsolutions.com](http://www.successparkingsolutions.com)

### KIOSK COMPONENTS

1. Interactive touch-screen display
2. Credit card reader (for payments and access)
3. Ticket/receipt dispenser (pull-tear mechanism)
4. Barcode scanner (mobile and barcodes)
5. Parking access card reader
6. Integrated intercom (video, mic, and speaker)



### ENTRY PROCESS

- STEP 1:** Touch the parking card flat to the card reader sensor as shown in photo image.
- STEP 2:** The parking card reader will display a green light.
- STEP 3:** Gate will open.
- STEP 4:** Proceed to Enter the parking facility.



### EXIT PROCESS

- STEP 1:** Drive up to the Pay Station. Machine will activate when you pull up along side the kiosk.
- STEP 2:** Touch the parking card adjacent to the card reader sensor.
- STEP 3:** Gate will open. Proceed to drive out of parking facility exit.



### PAY STATION KIOSK OVERVIEW

- ▶ Entry/Exit Smart Stations are the essential elements needed to manage parking access.
- ▶ Pay station kiosk are mobility solutions used for entry and exit of parking facilities designed to give customers the best parking experience.
- ▶ Monthly Parkers receive an assigned Parking Access Card to swipe over the card reader for Entry and Exit of the parking facility.
- ▶ Smart Bluetooth technology captures date/time stamp of parkers entry and exit from the parking facility.

### CARD USAGE TIPS

- ▶ The card will deactivate if it is placed against or near a cell phone which will demagnetize the card enabling to not work.
- ▶ It's recommended the card be placed in separate secure pouch such as a plastic employee badge holder, key ring and/or personal wallet to ensure card works properly.
- ▶ Tickets can receive only one validation per ticket for a specific time period. Applying multiple validations to one ticket as payment to exit a garage is prohibited.

### QUESTIONS

Contact: (501) 683-9600 or  
 Toll Free: (877) 683-5001  
[support@successparkingsolutions.com](mailto:support@successparkingsolutions.com)