



Zimmer®  
Trilogy® IT  
Acetabular  
System

Surgical Technique




## Device Description


- The *Trilogy* IT Shell is hemispherical in shape with an exterior of commercially pure titanium Fiber Metal Material that is bonded to a *Tivanium*® alloy substrate. The Shell has a snap fit locking groove for acceptance of the *Vivacit-E*® Vitamin E Highly Crosslinked Polyethylene Neutral or Elevated Liners and the *Longevity*® Highly Crosslinked Polyethylene Neutral or Elevated Liners. Twelve scallops, equally spaced in 30° increments, included on the Shell face mate with twelve anti-rotation tabs on the *Vivacit-E* Vitamin E and *Longevity* Liners.

## Indications/Intended Use


- The system is indicated for primary or revision surgery in skeletally mature individuals for rehabilitating hips damaged as a result of noninflammatory degenerative joint disease (NIDJD) or its composite diagnoses of osteoarthritis, avascular necrosis, protrusio acetabuli, traumatic arthritis, slipped capital epiphysis, fused hip, fracture of the pelvis, and diastrophic variant.
- The system is intended for use either with or without bone cement in total hip arthroplasty.



Acetabular Reamer  
54mm Reamer has a 54mm O.D.



Shell Provisional  
54mm Provisional has a 54mm O.D.



Acetabular Cup  
54mm Trilogy IT Cup has a 54mm O.D.

## Introduction

- The labeled outside diameter (O.D.) of the acetabular cup represents the true hemispherical diameter of the Implant. An appropriate undersized reamer must be used to prepare the acetabulum if a press fit condition is desired.
- The amount of press fit used should be determined at the time of surgery and be based on bone quality.
- Shell Implants are labeled with the exterior size and a corresponding two letter code (e.g. 56 KK). The matching Liner Implants are identified with the matching letter code and head diameter (e.g. 28 KK, 32 KK, 36 KK, 40 KK).

## Templating

- The primary goal of templating is to estimate the size and position of the acetabular Implant.
- 45 degrees of abduction and 20 degrees of forward flexion is recommended in most cases. Use of the alignment guides with various patient positions is outlined in later sections of the technique.
- To increase the accuracy of templating, digital imaging or x-rays with magnification markers should be used. The magnification of the x-rays and the templates should be compared when sizing the Implant.

Templating should start with the A/P radiograph. (Fig. 1)

- The component should NOT be more medial than the cortyloid notch and should NOT be against the radiographic tear drop.
- To avoid vertical cup placement a line drawn along the cup template opening should intersect the obturator foramen.
- It may be helpful to cross-check the acetabular component size on the lateral radiograph, which can provide a view of the hemispherical subchondral bone.
- The largest component that meets these requirements should be selected. However, the final decision on component size should be made during surgery, when all aspects of the acetabulum can be fully visualized.




Fig. 1

AP Templating View.

## Surgical Approach

The *Trilogy* IT Cup may be implanted using a variety of standard surgical approaches.

- N** **Note:** While the surgeon's approach may vary, the approach must provide adequate exposure to visualize the entire acetabular rim.

## Acetabular Preparation

Excise the acetabular labrum and remove any large peripheral osteophytes. Excise the ligamentum teres to expose the true floor of the acetabulum.

- N** **Note:** It is important to visualize the entire bony rim of the acetabulum to reduce the likelihood of soft tissue entrapment which may prevent the cup from seating during insertion.

## Acetabular Reaming

- From templating and preoperative planning, determine the desired head position.
- Start with a smaller reamer and proceed to the next largest reamer in 1-2mm increments. Reaming depth is based on bone quality but usually is completed after bleeding cancellous bone is exposed.

- N** **Note:** Take extra care to avoid eccentric reaming by holding the reamer steady. Apply constant pressure in the recommended final Implant orientation of 45 degrees of abduction and 20 degrees of forward flexion.

**Caution:** Throughout the entire procedure, take care in handling sharp Implants or Instruments.

## Shell Provisional Insertion and Alignment

- Proper care must be taken to assess bone quality and to determine the appropriate Implant size and type.
- You may use either the Straight Shell Inserter (Fig. 2a), Hybrid Offset Shell Inserter (Fig. 2b) or the *Trilogy* Cup Positioner (Fig. 2c) with the appropriate metal cap to Insert the Provisional Shell.

If using the Straight Shell Inserter or Hybrid Offset Shell Inserter:

- Place the Shell Inserter Adapter, with or without Rotational Control, onto the tip of either the Straight Shell Inserter or Hybrid Offset Shell Inserter. (Fig. 3)
- Insert a Ball Head Hex Driver through the window and into the locking Screw at the tip of the Inserter. (Fig. 4)
- While holding the Shell Provisional in place, securely thread the Locking Screw into the Polar Hole of the Shell Provisional.
- Attach the Alignment Frame or Gunsight Alignment Guide to the Inserter and tighten the Thumb Screw.



Fig. 2a



Fig. 2b



Fig. 2c

### Shell and Provisional Shell Inserter Options



Fig. 3

### The Shell Inserter with Adapter mating with the Provisional Shell.



Fig. 4

### Attaching the Shell Provisional to the Inserter Handle using the Hex-Head Driver.

**N** **Note:** The Alignment Support Frame on the Shell Inserter will not be vertical to the floor and should not be used as a positioning guide. (Fig. 5) The arms on the Guide are used to correctly position the Provisional Shell and/or Implant. See the diagrams for use instructions on the lateral and supine approaches (Pages 13-16).

- With the Shell Provisional in the appropriate alignment, use a mallet to impact the handle of the Inserter. To prevent thread damage, verify that the Locking Screw is fully tightened to the Shell as repetitive impacts could cause the screw to loosen.
- The Shell Provisional has fenestrations to assess proper cup seating inside the acetabulum.
- When the Shell Provisional is fully seated, turn the Driver counterclockwise to loosen the attachment Screw on the Inserter.
- Remove the Inserter.

If using the *Trilogy* Cup Positioner (Fig. 6):

- Select the appropriate Positioner cap based on shell size.
  - Shells 44-46mm use the Micro Cap (Fig. 7)
  - Shells 48-68mm use the existing *Trilogy* Cap (Fig. 8)
- Thread the Shell Provisional onto the Positioner until secure.
- Rotate the Alignment Connector to achieve desired shell screw hole orientation.
- Fix the Alignment Connector into place by tightening the Locking Nut.
- Using the small slaphammer on their shafts, impact one of the following Alignment guides in the alignment connector to engage onto the taper:
  - Lateral A-Frame Alignment Guide
  - Supine A-Frame Alignment Guide
  - Lateral Gunsight Alignment Guide
  - Supine Gunsight Alignment Guide

If using Lateral or Supine Gunsight Alignment Guide, insert Alignment Rod into appropriate hole (Left or Right).


**See the diagrams for use instructions on the lateral and supine approaches (Pages 13-16).**

- With the Shell Provisional in the appropriate alignment, use a mallet to impact the handle of the Positioner.
- When the Shell Provisional is fully seated unscrew the Positioner from the Shell Provisional.
- Thread the Locking Screw into the Polar Hole of the Shell Provisional.



**Fig. 5**

Do not use the support frame to align the Provisional Shell or Shell Implant.



**Fig. 6**

*Trilogy* Cup Positioner



**Fig. 7**

*Trilogy* Micro Cap



**Fig. 8**

*Trilogy* Cap

## Provisional Liner Insertion

### Inserting the Provisional Liner

- There are two different Provisional Liners. One with a Locking Screw that is **independent** of the Provisional Liner (**Fig. 9**) and one with a Locking Screw **permanently affixed** within the Provisional Liner. (**Fig. 10**)

**N Note: The Permanently Affixed Locking Screw should not be removed.**

- Select the Provisional Liner size that matches the selected Provisional Shell.
- The selected Shell Provisional will be identified through a size and a two letter code (e.g. 50 HH). There are different inner diameter Implant sizes available for each Shell size. The Provisional Liner will be identified by letter code matching the Shell diameter and desired inner diameter (e.g. 32 HH).
- Both types of Provisional Liners are inserted the same way; however, the Provisional Liner with Independent Locking Screw must first be assembled by using a Hex-head Driver to insert the Provisional Locking Screw through the Polar Hole of the Provisional Liner. The Provisional Locking Screw will have a silver ring.
- Insert the Provisional Liner by hand into the Provisional Shell.
- If applicable, ensure that the anti-rotation tabs of the Provisional Liner are engaged in the Shell Provisional scallops.

**N Note: Do not impact the Provisional Liner as damage may occur.**

- Thread the Locking Screw into the Polar Hole of the Shell Provisional.

### Trial Range of Motion

- Insert a head/neck Provisional onto the Implanted Stem or Rasp Cone Provisional and perform a trial reduction.
- Check for stability and range of motion.
- Remove the Provisional components.

**N Note: Refer to Zimmer's product compatibility website, [www.productcompatibility.zimmer.com](http://www.productcompatibility.zimmer.com), to determine compatibility among all selected components.**

## Implant Insertion

If using the Straight Shell Inserter or Hybrid Offset Inserter:


- There are two Adapters for the Inserter Handles. The Adapter with Rotational Control locks to prevent the Implant from rotating freely on the Inserter handle. If this Adapter is used with a Cluster Hole Shell, the dark etch on the Adapter should be in line with the alignment frame on the Inserter to allow for Cluster Hole placement in the posterior superior and posterior inferior quadrants.

**N Note: The Shell Inserter Adapter without Rotational Control will allow the Implant to rotate freely on the Inserter. Use this Adapter when it is necessary to position the Screw Holes in a specific location within the acetabulum.**

- The Shell Inserter Adapter with Rotational Control has two pins that will fit into slots at the tip of the Inserter. These pins are not found on the Shell Inserter Adapter without Rotational Control.
- To insert the Implant, follow the same procedure described previously for inserting provisional shells using the Straight Shell Inserter or Hybrid Offset Shell Inserter.

If using the *Trilogy* Cup Positioner:

- The *Trilogy* Cup Positioner does not have rotational control. Control of Implant orientation is at the discretion of the surgeon and can be adjusted by rotating the position of the Alignment Connector relative to the shaft of the *Trilogy* Cup Positioner.
- To insert the Implant, follow the same procedure described previously for inserting provisional shells using the *Trilogy* Cup Positioner.



**Fig. 9**

Provisional Liner with Independent Locking Screw



**Fig. 10**


Provisional Liner with Permanently Affixed Locking Screw

- With the Implant in the appropriate position and alignment, use a mallet to impact the handle of the Inserter.
- When the Implant is fully seated, turn the Driver counterclockwise to loosen the Attachment Screw on the Inserter.
- Remove the Inserter.

**N** **Note:** The impact required to seat the Implant is dictated by the bone quality.

**N** **Note:** Do not lever on the Shell or the Shell Inserter to reposition the Implant, as damage may occur to the threads or inner diameter of the Shell.

**N** **Note:** The potential for neurologic and vascular injury can be minimized if the posterior quadrants are used for transacetabular screw placement.\* The Shell should be positioned to allow screw placement in the posterior superior and/or posterior inferior quadrants of the acetabulum. (Fig. 11) The *Trilogy* IT screw holes are located closer to the polar region as compared to the *Trilogy* shell.



**Fig. 11**

Correct location for Screw placement in shaded regions.

\* Wasielewski RC, Cooperstein LA, Kruger MP, Rubash HE. Acetabular anatomy and the transacetabular fixation of screws in total hip arthroplasty. *J Bone Joint Surg.* 1990;72-A(4):501-508.

## Screw Insertion

If Screw placement is desired:

- Carefully following these steps for Screw insertion can help to minimize Screw push-through or torque-out after initial implantation.
- Drill a pilot hole, using either a Modular or One-Piece Flex Drill.
- If using the Modular Flex Drill attach the selected bit using the Hex Wrench. **(Fig. 12)** Check the bit to ensure that it is not dull.
- Position the Adjustable Drill Guide and Flex Drill into the selected Screw Hole. **(Fig. 13)**
- The screw angle may vary by as much as 33 degrees (inclusive). The effective lengths of the three drill bits available are 15mm, 30mm and 45mm.
- Upon seating of the drill bit completely into the drill guide, the drilled holes will correspond to the effective length of the drill bit.
- For sclerotic bone, an option may be to tap the Screw hole.
  - Attach the Modular Tap Shaft into the Modular Handle by pulling back on the snap-lock collet and aligning the hole in the shaft with the etched line on the collet.
  - Attach the appropriate Tap to the Modular Tap Shaft.
  - Bicortical tapping the entire depth should be done with care by turning the Tap Handle clockwise.

## Set Screw Removal

- To loosen the set screw, turn it counterclockwise until the thread fully disengages from the flexible shaft. The set screw will be captured in the flexible drill shaft between the threads and the screw stop. **(Fig. 14)**
- Alternatively, the set screw can be removed by turning it clockwise to fully disengage the set screw and placing it into the set screw holder in the instrument tray.
- After either loosening or removing the set screw, remove the drill bit.



**Fig. 12**

Attaching the bit to the Flex Drill with the Hex Wrench.



**Fig. 13**

Inserting the Adjustable Drill Guide and Modular Flex Shaft into the Shell.



**Fig. 14**

Loosening the Flex Drill set screw.



After drilling the pilot or tapping the Screw hole:

- Use the Depth Gauge to measure the depth of the Screw hole. (Fig. 15)
- Select the appropriate length *Trilogy* Screw.
- Use a Screwdriver to insert it into the selected Screw hole. Screws cannot be inserted into the Polar Hole at the dome of the Shell. (Fig. 16)

**N** **Note:** Countersink screw heads below the interior surface of the shell to prevent the liner from contacting the screw head. Ensure that the screw heads are properly seated. Screw heads that protrude in to the inner shell can prevent adequate seating of the liner. Use a 3.2mm diameter drill prior to insertion of the 4.5 or 6.5mm diameter screws. Avoid penetration beyond the inner cortex of the pelvis when drilling holes and inserting screws. (Fig. 17)

- Place additional Screws as necessary.
- Carefully evaluate the bone quality, and avoid over-tightening the Screws.
- To remove a Screw, engage the Screw with a Hex Head Driver and turn it *counterclockwise*.

**Warning:** Avoid Screw placement through the Shell into the anterior inferior and anterior superior quadrants of the acetabulum to prevent injury to the neurovascular structures.



Fig. 15

Using the Depth Gauge to measure the screw hole depth.




Fig. 16

Using a screwdriver to insert the screws.



Fig. 17

Checking to ensure that the screws are properly seated.

## Optional Screw Hole Plugs

### Screw Hole Plug

- Place a Screw Hole Plug on the appropriate Hex Head Driver to ensure it is perpendicular to the Screw Hole Plug.
- Align the Plug and Screw Hole until the Plug clearly drops into the Hole.

**N** **Note: The Screw Hole Plugs are slightly oval in shape and engage by providing an interference fit.**

- To lock the Plug, turn it in either direction. The Plug will lock in place with a partial turn.
- To remove the Hole Plug, turn in the opposite direction to release the interference fit. (Fig. 18)

## Provisional Liner Positioning

- Clean and dry the cup with a sterile cloth, wipe or sponge to remove third-body debris.
- Clear all soft tissue from around the perimeter of the Shell and assess visualization.
- Insert the Provisional Liner by hand into the Shell.
- If applicable, ensure that the anti-rotation tabs of the Provisional Liner are engaged in the Shell scallops.

**N** **Note: Do not impact the Provisional Liner as damage may occur.**

- Thread the Locking Screw into the Polar Hole of the Shell.

## Optional Dome Hole Plugs

- Insert a Plug into the Polar Hole and thread it into place.
- When correctly inserted the Plug will be slightly inset relative to the interior surface of the Shell, but it will be slightly proud within the recessed square at the pole. (Fig. 19)
- Take care not to overtighten the Dome Hole Plug.



**Fig. 18**

Screw Hole Plug insertion.



**Fig. 19**

Correct seating of the Polar Hole Plug.

## Liner Insertion

### Vivacit-E Vitamin E Polyethylene Liner Longevity Polyethylene Liner

- The *Vivacit-E* Vitamin E Liners and the *Longevity* Liners have identical geometries.
- Prior to inserting the *Vivacit-E* Liner or the *Longevity* Liner, ensure that the Shell interior is clean and dry.
- Place the final polyethylene Liner into the implanted Shell by hand, or use the Liner Insertion Instrument.
- If inserting by hand, spin the Liner until scallops engage.

**N** **Note:** Before impaction, the polyethylene Liner will not be flush with the rim of the Shell.

- Select the proper size Dome Impactor and attach it to the Universal Handle.
  - Align the pins on the Universal Handle with the keyhole slot on the underside of the Impactor.
  - Push the Impactor onto the handle and twist in either direction to lock it in place.
- Verify that the Liner is in the desired position prior to impacting the Liner.
- Place the Impactor on the Liner and strike the Liner until it is fully seated.

**N** **Note:** Once the liner is seated within the shell, it cannot be removed without causing damage to the liner, thus necessitating removal and disposal.


## Verifying Liner Seating

**Neutral Liner** Verify that the neutral polyethylene Liner is properly seated by running finger around the face of the Shell to ensure the Liner is flush. (Fig. 20)

**Elevated Liner** Verify the elevated polyethylene Liner is seated by running a finger around the exposed portion of the Shell face to ensure the Liner is flush relative to the face of the Shell. (Fig. 21) If additional Liner seating verification is desired gently move the elevated portion of the Liner to ensure that it is locked into place. (Fig. 22)

## Final Reduction

Perform a final reduction and assess range of motion, hip stability, and limb length.



**Fig. 20**

Verify that the Neutral Poly Liner is properly seated into the Shell.



**Fig. 21**

Verify that the Elevated Poly Liner is seated flush into the Shell.



**Fig. 22**

Verify that the elevated portion of the Poly Liner is properly seated into the Shell.

## Liner Removal

- Upon removal of any Liner, inspect the taper and polyethylene locking mechanisms for damage.
- Special care should be taken not to lever against the Shell during Liner removal.

**N** **Note:** These Instructions are included for use in possible revisions for previously implanted devices.

### Polyethylene Liner Removal (Bone Screw Method)

- Locate a 3.2mm or 3.5mm drill bit included in the Screw Kit.
- Drill a pilot hole into the dome of the Liner between the pole and the taper region of the Shell.
- Locate a non-self tapping screw. (**Fig. 23**)
- **A self tapping screw should NOT be used. (Fig. 24)**
- Drive the screw into the pilot hole by hand until the Liner is lifted out of the Shell. (**Fig. 25**)
- Special care should be taken not to damage the Shell taper or locking mechanism during removal of the Liner.

### Intraoperative Shell Removal

If you are using the Straight Hybrid Inserter or Offset Hybrid Inserter:

- Place an Adapter on the end of the inserter handle.
- Place the inserter with attached Adapter into the Shell Polar Hole.
- Turn the locking Screw clockwise to secure the locking Screw.
- Remove the inserter and Shell.


If you are using the *Trilogy* Cup Positioner:

- Place the cap on the end of the *Trilogy* Cup Positioner.
- Thread the inserter into the Shell Polar Hole until it is fully engaged.
- Remove the *Trilogy* Cup Positioner and Shell.



## Lateral Patient Positioning “A-Frame”

- Insert the Shell Provisional or Implant into the prepared acetabulum.
- To achieve 45° of abduction and 20° of forward flexion, ensure that the Alignment Frame is parallel to the floor and the anterior rod of the Alignment Frame is in line with the longitudinal body axis. (Fig. 26)
- Patient positioning is the same for the Straight Inserter, Hybrid Offset Inserter and *Trilogy* Cup Positioner.



### Lateral Patient Positioning “Gunsight”

- Insert the Shell Provisional or Implant into the prepared acetabulum.
- The “Gunsight” alignment extension needs to be parallel with the longitudinal body axis to achieve a 45° inclination (abduction) and 20° of forward flexion. (Fig. 27)
- Patient positioning is the same for the Straight Inserter, Hybrid Offset Inserter and *Trilogy* Cup Positioner.




Fig. 27

Lateral view

## Supine Patient Positioning “A-Frame”

- Insert the Shell Provisional or Implant into the prepared acetabulum.
- To achieve 45° of abduction and 20° of forward flexion, ensure that the Alignment Frame is parallel to the floor and the lateral arm is parallel with the longitudinal body axis. (Fig. 28)
- Patient positioning is the same for the Straight Inserter, Hybrid Offset Inserter and *Trilogy* Cup Positioner.




Fig. 28

### Supine Patient Positioning “Gunsight”

- Insert the Shell Provisional or Implant into the prepared acetabulum.
- The “Gunsight” alignment extension needs to be parallel with the longitudinal body axis to achieve a 45° inclination (abduction) and 20° of forward flexion. (Fig. 29)
- Patient positioning is the same for the Straight Inserter, Hybrid Offset Inserter and *Trilog* Cup Positioner.




Fig. 29



## Shell and Articulation Liner Sizing Chart

The articulation diameter along with its corresponding head diameter is represented by the number in the shaded area of the chart below (e.g. 28mm is a 28mm head and liner combination).

Shell Size in mm	44	46	48	50	52	54	56	58	60	62	64	66	68
<b>Trilogy IT Shells</b>	EE	FF	GG	HH	II	JJ	KK	LL	MM	NN	OO	PP	QU
<b>Vivacit-E</b> Vitamin E Highly Crosslinked Polyethylene	28mm Neutral and Elevated												
	32mm Neutral and Elevated												
	36mm Neutral and Elevated												
	40mm Neutral												
<b>Longevity</b> Highly Crosslinked Polyethylene	28mm Neutral and Elevated												
	32mm Neutral and Elevated												
	36mm Neutral and Elevated												
	40mm Neutral												

## Implants

### TrilogY IT Shell, Cluster-Hole

Item Number	Description
00-8753-044-01	TrilogY IT Shell, Cluster, 44 EE
00-8753-046-01	TrilogY IT Shell, Cluster, 46 FF
00-8753-048-01	TrilogY IT Shell, Cluster, 48 GG
00-8753-050-01	TrilogY IT Shell, Cluster, 50 HH
00-8753-052-01	TrilogY IT Shell, Cluster, 52 II
00-8753-054-01	TrilogY IT Shell, Cluster, 54 JJ
00-8753-056-01	TrilogY IT Shell, Cluster, 56 KK
00-8753-058-01	TrilogY IT Shell, Cluster, 58 LL
00-8753-060-01	TrilogY IT Shell, Cluster, 60 MM
00-8753-062-01	TrilogY IT Shell, Cluster, 62 NN
00-8753-064-01	TrilogY IT Shell, Cluster, 64 OO
00-8753-066-01	TrilogY IT Shell, Cluster, 66 PP
00-8753-068-01	TrilogY IT Shell, Cluster, 68 QU

### TrilogY IT Shell, Multi-Hole

00-8753-044-02	TrilogY IT Shell, Multi, 44 EE
00-8753-046-02	TrilogY IT Shell, Multi, 46 FF
00-8753-048-02	TrilogY IT Shell, Multi, 48 GG
00-8753-050-02	TrilogY IT Shell, Multi, 50 HH
00-8753-052-02	TrilogY IT Shell, Multi, 52 II
00-8753-054-02	TrilogY IT Shell, Multi, 54 JJ
00-8753-056-02	TrilogY IT Shell, Multi, 56 KK
00-8753-058-02	TrilogY IT Shell, Multi, 58 LL
00-8753-060-02	TrilogY IT Shell, Multi, 60 MM
00-8753-062-02	TrilogY IT Shell, Multi, 62 NN
00-8753-064-02	TrilogY IT Shell, Multi, 64 OO
00-8753-066-02	TrilogY IT Shell, Multi, 66 PP
00-8753-068-02	TrilogY IT Shell, Multi, 68 QU

### TrilogY IT Hole Plugs

00-8753-000-01	Dome Hole Plug - Single Pack
00-8753-000-02	Screw Hole Plug - Three Pack

### Bone Screws

SCREWS are available in 5mm LENGTH increments up to 40mm 6250-SIZE-LENGTH

Item Number	Description
00-6250-045-15	Bone Screw, 4.5x15mm, Self-Tapping Through
00-6250-045-40	Bone Screw, 4.5x40mm, Self-Tapping
00-6250-045-50	Bone Screw, 4.5x50mm, Self-Tapping
00-6250-045-60	Bone Screw, 4.5x60mm, Self-Tapping
00-6250-065-15	Bone Screw, 6.5x15mm, Self-Tapping Through
00-6250-065-40	Bone Screw, 6.5x40mm, Self-Tapping
00-6250-065-50	Bone Screw, 6.5x50mm, Self-Tapping
00-6250-065-60	Bone Screw, 6.5x60mm, Self-Tapping
00-6250-065-70	Bone Screw, 6.5x70mm, Self-Tapping
00-6250-065-80	Bone Screw, 6.5x80mm, Self-Tapping

**Warning:** These screws are not approved for screw attachment or fixation to the posterior elements (pedicles) of the cervical, thoracic, or lumbar spine.

## Implants

### **Vivacit-E Vitamin E Highly Crosslinked Liner, Neutral, 28mm**

Item Number	Description
00-8851-006-28	<i>Vivacit-E</i> Liner, Neutral, 44 EE x 28
00-8851-007-28	<i>Vivacit-E</i> Liner, Neutral, 46 FF x 28

### **Vivacit-E Vitamin E Highly Crosslinked Liner, Neutral, 32mm**

00-8851-008-32	<i>Vivacit-E</i> Liner, Neutral, 48 GG x 32
00-8851-009-32	<i>Vivacit-E</i> Liner, Neutral, 50 HH x 32
00-8851-010-32	<i>Vivacit-E</i> Liner, Neutral, 52 II x 32
00-8851-011-32	<i>Vivacit-E</i> Liner, Neutral, 54 JJ x 32
00-8851-012-32	<i>Vivacit-E</i> Liner, Neutral, 56 KK x 32
00-8851-013-32	<i>Vivacit-E</i> Liner, Neutral, 58 LL x 32
00-8851-014-32	<i>Vivacit-E</i> Liner, Neutral, 60 MM x 32
00-8851-015-32	<i>Vivacit-E</i> Liner, Neutral, 62 NN x 32
00-8851-016-32	<i>Vivacit-E</i> Liner, Neutral, 64 OO x 32
00-8851-017-32	<i>Vivacit-E</i> Liner, Neutral, 66 PP x 32
00-8851-018-32	<i>Vivacit-E</i> Liner, Neutral, 68 QU x 32

### **Vivacit-E Vitamin E Highly Crosslinked Liner, Neutral, 36mm**

00-8851-010-36	<i>Vivacit-E</i> Liner, Neutral, 52 II x 36
00-8851-011-36	<i>Vivacit-E</i> Liner, Neutral, 54 JJ x 36
00-8851-012-36	<i>Vivacit-E</i> Liner, Neutral, 56 KK x 36
00-8851-013-36	<i>Vivacit-E</i> Liner, Neutral, 58 LL x 36
00-8851-014-36	<i>Vivacit-E</i> Liner, Neutral, 60 MM x 36
00-8851-015-36	<i>Vivacit-E</i> Liner, Neutral, 62 NN x 36
00-8851-016-36	<i>Vivacit-E</i> Liner, Neutral, 64 OO x 36
00-8851-017-36	<i>Vivacit-E</i> Liner, Neutral, 66 PP x 36
00-8851-018-36	<i>Vivacit-E</i> Liner, Neutral, 68 QU x 36

### **Vivacit-E Vitamin E Highly Crosslinked Liner, Neutral, 40mm**

00-8851-012-40	<i>Vivacit-E</i> Liner, Neutral, 56 KK x 40
00-8851-013-40	<i>Vivacit-E</i> Liner, Neutral, 58 LL x 40
00-8851-014-40	<i>Vivacit-E</i> Liner, Neutral, 60 MM x 40
00-8851-015-40	<i>Vivacit-E</i> Liner, Neutral, 62 NN x 40
00-8851-016-40	<i>Vivacit-E</i> Liner, Neutral, 64 OO x 40
00-8851-017-40	<i>Vivacit-E</i> Liner, Neutral, 66 PP x 40
00-8851-018-40	<i>Vivacit-E</i> Liner, Neutral, 68 QU x 40

### **Vivacit-E Vitamin E Highly Crosslinked Liner, Elevated, 28mm**

00-8852-006-28	<i>Vivacit-E</i> Liner, Elevated, 44 EE x 28
00-8852-007-28	<i>Vivacit-E</i> Liner, Elevated, 46 FF x 28

### **Vivacit-E Vitamin E Highly Crosslinked Liner, Elevated, 32mm**

Item Number	Description
00-8852-008-32	<i>Vivacit-E</i> Liner, Elevated, 48 GG x 32
00-8852-009-32	<i>Vivacit-E</i> Liner, Elevated, 50 HH x 32
00-8852-010-32	<i>Vivacit-E</i> Liner, Elevated, 52 II x 32
00-8852-011-32	<i>Vivacit-E</i> Liner, Elevated, 54 JJ x 32
00-8852-012-32	<i>Vivacit-E</i> Liner, Elevated, 56 KK x 32
00-8852-013-32	<i>Vivacit-E</i> Liner, Elevated, 58 LL x 32
00-8852-014-32	<i>Vivacit-E</i> Liner, Elevated, 60 MM x 32
00-8852-015-32	<i>Vivacit-E</i> Liner, Elevated, 62 NN x 32
00-8852-016-32	<i>Vivacit-E</i> Liner, Elevated, 64 OO x 32
00-8852-017-32	<i>Vivacit-E</i> Liner, Elevated, 66 PP x 32
00-8852-018-32	<i>Vivacit-E</i> Liner, Elevated, 68 QU x 32

### **Vivacit-E Vitamin E Highly Crosslinked Liner, Elevated, 36mm**

00-8852-010-36	<i>Vivacit-E</i> Liner, Elevated, 52 II x 36
00-8852-011-36	<i>Vivacit-E</i> Liner, Elevated, 54 JJ x 36
00-8852-012-36	<i>Vivacit-E</i> Liner, Elevated, 56 KK x 36
00-8852-013-36	<i>Vivacit-E</i> Liner, Elevated, 58 LL x 36
00-8852-014-36	<i>Vivacit-E</i> Liner, Elevated, 60 MM x 36
00-8852-015-36	<i>Vivacit-E</i> Liner, Elevated, 62 NN x 36
00-8852-016-36	<i>Vivacit-E</i> Liner, Elevated, 64 OO x 36
00-8852-017-36	<i>Vivacit-E</i> Liner, Elevated, 66 PP x 36
00-8852-018-36	<i>Vivacit-E</i> Liner, Elevated, 68 QU x 36

## Implants

### Longevity Highly Crosslinked Liner, Neutral, 28mm

Item Number	Description
00-8751-006-28	Longevity Liner, Neutral, 44 EE x 28
00-8751-007-28	Longevity Liner, Neutral, 46 FF x 28
00-8751-008-28	Longevity Liner, Neutral, 48 GG x 28
00-8751-009-28	Longevity Liner, Neutral, 50 HH x 28
00-8751-010-28	Longevity Liner, Neutral, 52 II x 28
00-8751-011-28	Longevity Liner, Neutral, 54 JJ x 28
00-8751-012-28	Longevity Liner, Neutral, 56 KK x 28
00-8751-013-28	Longevity Liner, Neutral, 58 LL x 28
00-8751-014-28	Longevity Liner, Neutral, 60 MM x 28
00-8751-015-28	Longevity Liner, Neutral, 62 NN x 28
00-8751-016-28	Longevity Liner, Neutral, 64 OO x 28
00-8751-017-28	Longevity Liner, Neutral, 66 PP x 28
00-8751-018-28	Longevity Liner, Neutral, 68 QU x 28

### Longevity Highly Crosslinked Liner, Neutral, 32mm

00-8751-008-32	Longevity Liner, Neutral, 48 GG x 32
00-8751-009-32	Longevity Liner, Neutral, 50 HH x 32
00-8751-010-32	Longevity Liner, Neutral, 52 II x 32
00-8751-011-32	Longevity Liner, Neutral, 54 JJ x 32
00-8751-012-32	Longevity Liner, Neutral, 56 KK x 32
00-8751-013-32	Longevity Liner, Neutral, 58 LL x 32
00-8751-014-32	Longevity Liner, Neutral, 60 MM x 32
00-8751-015-32	Longevity Liner, Neutral, 62 NN x 32
00-8751-016-32	Longevity Liner, Neutral, 64 OO x 32
00-8751-017-32	Longevity Liner, Neutral, 66 PP x 32
00-8751-018-32	Longevity Liner, Neutral, 68 QU x 32

### Longevity Highly Crosslinked Liner, Neutral, 36mm

00-8751-010-36	Longevity Liner, Neutral, 52 II x 36
00-8751-011-36	Longevity Liner, Neutral, 54 JJ x 36
00-8751-012-36	Longevity Liner, Neutral, 56 KK x 36
00-8751-013-36	Longevity Liner, Neutral, 58 LL x 36
00-8751-014-36	Longevity Liner, Neutral, 60 MM x 36
00-8751-015-36	Longevity Liner, Neutral, 62 NN x 36
00-8751-016-36	Longevity Liner, Neutral, 64 OO x 36
00-8751-017-36	Longevity Liner, Neutral, 66 PP x 36
00-8751-018-36	Longevity Liner, Neutral, 68 QU x 36

### Longevity Highly Crosslinked Liner, Neutral, 40mm

Item Number	Description
00-8751-012-40	Longevity Liner, Neutral, 56 KK x 40
00-8751-013-40	Longevity Liner, Neutral, 58 LL x 40
00-8751-014-40	Longevity Liner, Neutral, 60 MM x 40
00-8751-015-40	Longevity Liner, Neutral, 62 NN x 40
00-8751-016-40	Longevity Liner, Neutral, 64 OO x 40
00-8751-017-40	Longevity Liner, Neutral, 66 PP x 40
00-8751-018-40	Longevity Liner, Neutral, 68 QU x 40

### Longevity Highly Crosslinked Liner, Elevated, 28mm

00-8752-006-28	Longevity Liner, Elevated, 44 EE x 28
00-8752-007-28	Longevity Liner, Elevated, 46 FF x 28
00-8752-008-28	Longevity Liner, Elevated, 48 GG x 28
00-8752-009-28	Longevity Liner, Elevated, 50 HH x 28
00-8752-010-28	Longevity Liner, Elevated, 52 II x 28
00-8752-011-28	Longevity Liner, Elevated, 54 JJ x 28
00-8752-012-28	Longevity Liner, Elevated, 56 KK x 28
00-8752-013-28	Longevity Liner, Elevated, 58 LL x 28
00-8752-014-28	Longevity Liner, Elevated, 60 MM x 28
00-8752-015-28	Longevity Liner, Elevated, 62 NN x 28
00-8752-016-28	Longevity Liner, Elevated, 64 OO x 28
00-8752-017-28	Longevity Liner, Elevated, 66 PP x 28
00-8752-018-28	Longevity Liner, Elevated, 68 QU x 28

### Longevity Highly Crosslinked Liner, Elevated, 32mm

00-8752-008-32	Longevity Liner, Elevated, 48 GG x 32
00-8752-009-32	Longevity Liner, Elevated, 50 HH x 32
00-8752-010-32	Longevity Liner, Elevated, 52 II x 32
00-8752-011-32	Longevity Liner, Elevated, 54 JJ x 32
00-8752-012-32	Longevity Liner, Elevated, 56 KK x 32
00-8752-013-32	Longevity Liner, Elevated, 58 LL x 32
00-8752-014-32	Longevity Liner, Elevated, 60 MM x 32
00-8752-015-32	Longevity Liner, Elevated, 62 NN x 32
00-8752-016-32	Longevity Liner, Elevated, 64 OO x 32
00-8752-017-32	Longevity Liner, Elevated, 66 PP x 32
00-8752-018-32	Longevity Liner, Elevated, 68 QU x 32

### Longevity Highly Crosslinked Liner, Elevated, 36mm

00-8752-010-36	Longevity Liner, Elevated, 52 II x 36
00-8752-011-36	Longevity Liner, Elevated, 54 JJ x 36
00-8752-012-36	Longevity Liner, Elevated, 56 KK x 36
00-8752-013-36	Longevity Liner, Elevated, 58 LL x 36
00-8752-014-36	Longevity Liner, Elevated, 60 MM x 36
00-8752-015-36	Longevity Liner, Elevated, 62 NN x 36
00-8752-016-36	Longevity Liner, Elevated, 64 OO x 36
00-8752-017-36	Longevity Liner, Elevated, 66 PP x 36
00-8752-018-36	Longevity Liner, Elevated, 68 QU x 36

## Implants

### **BIOLOX® delta Ceramic Femoral Head, 28mm**

Item Number	Description
00-8775-028-01	Ceramic Fem Hd, 12/14, 28 x -3.5
00-8775-028-02	Ceramic Fem Hd, 12/14, 28 x 0
00-8775-028-03	Ceramic Fem Hd, 12/14, 28 x +3.5

### **BIOLOX delta Ceramic Femoral Head, 32mm**

00-8775-032-01	Ceramic Fem Hd, 12/14, 32 x -3.5
00-8775-032-02	Ceramic Fem Hd, 12/14, 32 x 0
00-8775-032-03	Ceramic Fem Hd, 12/14, 32 x +3.5
00-8775-032-04	Ceramic Fem Hd, 12/14, 32 x +7

### **BIOLOX delta Ceramic Femoral Head, 36mm**

00-8775-036-01	Ceramic Fem Hd, 12/14, 36 x -3.5
00-8775-036-02	Ceramic Fem Hd, 12/14, 36 x 0
00-8775-036-03	Ceramic Fem Hd, 12/14, 36 x +3.5
00-8775-036-04	Ceramic Fem Hd, 12/14, 36 x +7

### **BIOLOX delta Ceramic Femoral Head, 40mm**

00-8775-040-01	Ceramic Fem Hd, 12/14, 40 x -3.5
00-8775-040-02	Ceramic Fem Hd, 12/14, 40 x 0
00-8775-040-03	Ceramic Fem Hd, 12/14, 40 x +3.5
00-8775-040-04	Ceramic Fem Hd, 12/14, 40 x +7

### **Metasul® Femoral Head, 28mm**

00-8770-028-01	<i>Metasul</i> ® Fem Hd, 12/14, 28 x -3.5
00-8770-028-02	<i>Metasul</i> Fem Hd, 12/14, 28 x 0
00-8770-028-03	<i>Metasul</i> Fem Hd, 12/14, 28 x +3.5
00-8770-028-04	<i>Metasul</i> Fem Hd, 12/14, 28 x +7
00-8770-028-05	<i>Metasul</i> Fem Hd, 12/14, 28 x +10.5

### **Metasul Femoral Head, 32mm**

00-8770-032-01	<i>Metasul</i> Fem Hd, 12/14, 32 x -3.5
00-8770-032-02	<i>Metasul</i> Fem Hd, 12/14, 32 x 0
00-8770-032-03	<i>Metasul</i> Fem Hd, 12/14, 32 x +3.5
00-8770-032-04	<i>Metasul</i> Fem Hd, 12/14, 32 x +7
00-8770-032-05	<i>Metasul</i> Fem Hd, 12/14, 32 x +10.5

### **Metasul Femoral Head, 36mm**

00-8770-036-01	<i>Metasul</i> Fem Hd, 12/14, 36 x -3.5
00-8770-036-02	<i>Metasul</i> Fem Hd, 12/14, 36 x 0
00-8770-036-03	<i>Metasul</i> Fem Hd, 12/14, 36 x +3.5
00-8770-036-04	<i>Metasul</i> Fem Hd, 12/14, 36 x +7
00-8770-036-05	<i>Metasul</i> Fem Hd, 12/14, 36 x +10.5

### **Metasul Femoral Head, 40mm**

00-8770-040-01	<i>Metasul</i> Fem Hd, 12/14, 40 x -3.5
00-8770-040-02	<i>Metasul</i> Fem Hd, 12/14, 40 x 0
00-8770-040-03	<i>Metasul</i> Fem Hd, 12/14, 40 x +3.5
00-8770-040-04	<i>Metasul</i> Fem Hd, 12/14, 40 x +7
00-8770-040-05	<i>Metasul</i> Fem Hd, 12/14, 40 x +10.5

\**Metasul* Heads to be used only with *Longevity* Highly Crosslinked Liner

## Instrument Trays Kits

### Acetabular Cup Straight Handle Instrument

#### Kit #KT-8790-100-00

Item Number	Description
00-8792-001-00	Full DIN Case Base
00-5900-099-00	Full DIN Case Lid
00-8790-015-32	Dome Impactor Sz 32
00-8790-015-36	Dome Impactor Sz 36
00-8790-015-40	Dome Impactor Sz 40
00-9000-002-98	Liner Insertion Instrument
00-8790-001-00	Provisional Locking Screw (6)
00-8790-010-00	Universal Handle
00-8790-003-10	Cup Inserter Adapter w/o Rot. Cont.
00-8790-003-00	Cup Inserter Adapter w/ Rot. Cont.
00-7804-015-20	Straight Shell Inserter
9375-00-032	Ball Hex Screwdriver
00-8790-007-00	Non Modular Straight Screwdriver
01-00502-008	MIS Screw Hole Plug Instrument
00-8790-013-32	HB Rim Impactor Sz 32
00-8790-013-36	HB Rim Impactor Sz 36
00-8790-013-40	HB Rim Impactor Sz 40
00-8790-004-00	Single Point Hard Bearing Remover

### Acetabular Cup MIS Curved Handle Instrument

#### Kit # KT-8790-150-00

(Same as Kit #KT-8790-100-00, with the following curved handle instruments replacing the straight handled instruments)

00-8790-010-30	Curved Universal Handle
00-7804-025-20	Hybrid Offset Shell Inserter
<b>Optional (need to include one of the following alignment guides)</b>	
A-Frame Guides	
00-7807-015-02	Lateral Alignment Frame
00-7807-015-01	Supine Alignment Frame
Gunsight Alignment Guides	
01-00639-725	Lateral Positioning Guide 20°
01-00639-705	Positioning Guide spoke lateral
01-00639-745	Supine Positioning Guide 20°
01-00639-755	Positioning Guide spoke supine

#### Additional Items

00-9000-002-92	Disposable Suction Cup
75.11.01-05	Replacement Locking Screw
00-8790-015-28	Dome Impaction Adapter Sz 28
00-8790-013-28	HB Rim Impaction Adapter Sz 28

### Instruments for *Trilogy* Cup Positioner

Item Number	Description
00-6260-018-00	<i>Trilogy</i> Cup Positioner
00-6260-015-12	<i>Trilogy</i> Cap (included with <i>Trilogy</i> Cup Positioner)
00-8790-003-20	<i>Trilogy</i> Micro Cap (40mm-46mm)

### Alignment Guides for *Trilogy* Cup Positioner

Gunsight Alignment Guides	
00-6260-047-00	Lateral Gunsight Alignment Guide
00-8790-003-35	Supine Gunsight Alignment Guide
00-5785-079-00	Alignment Rod
A-Frame Guides	
00-6260-046-00	Lateral A-Frame Alignment Guide*
00-8790-003-30	Supine A-Frame Alignment Guide*

\*Will not fit in *Trilogy* Cup Positioner Case (00-8792-001-00)

### Acetabular Cup Screw Instrumentation

#### Kit # KT-8790-200-00

00-8792-002-00	Full DIN Case Base
00-5900-099-00	Full DIN Case Lid
00-8790-007-01	Adjustable Drill Guide
00-6260-013-00	Screw Holding Forceps 15°
00-2360-087-00	Ratcheting Modular Handle
00-8790-005-20	Straight 3.5mm shaft
00-8790-005-25	U-joint 3.5mm shaft
00-8790-007-05	Modular Flex Shaft
75.11.00-04	Hex Wrench
00-8790-007-02	Modular Flex Drill Bit (15mm)
00-8790-007-03	Modular Flex Drill Bit (30mm)
00-8790-007-04	Modular Flex Drill Bit (45mm)
75.80.15	Depth Gauge

#### Optional

00-6260-008-02	Tap Guide 6.5
00-8790-005-30	Tap Shaft
00-6260-007-02	Tap 6.5

### Instrument Tray for Provisional Liners & Shells

00-8792-000-00	Instrument Tray
00-5900-099-00	Instrument Tray Lid

## Provisional Shell Set

### **Continuum<sup>®</sup> Provisional Shell Core Set**

#### **Kit # KT-8790-303-00**

Item Number	Description
00-8792-005-00	Provisional Shell Rack
00-8791-048-00	IT Provisional Shell, 48 mm
00-8791-050-00	IT Provisional Shell, 50 mm
00-8791-052-00	IT Provisional Shell, 52 mm
00-8791-054-00	IT Provisional Shell, 54 mm
00-8791-056-00	IT Provisional Shell, 56 mm
00-8791-058-00	IT Provisional Shell, 58 mm
00-8791-060-00	IT Provisional Shell, 60 mm
00-8791-062-00	IT Provisional Shell, 62 mm
00-8791-064-00	IT Provisional Shell, 64 mm
00-8791-066-00	IT Provisional Shell, 66 mm
00-8791-068-00	IT Provisional Shell, 68 mm

### **Trilog<sup>®</sup> IT Micro Provisional Shells**

00-8791-044-00	IT Provisional Shell, 44 mm
00-8791-046-00	IT Provisional Shell, 46 mm

## Provisional Kits with Independent Locking Screw

### Trilogy IT Micro Provisional Liners

Item Number	Description
00-8731-006-28	Prov Liner, Neutral, 44 EE x 28
00-8731-007-28	Prov Liner, Neutral, 46 FF x 28
00-8731-007-32	Prov Liner, Neutral, 46 FF x 32*
00-8732-006-28	Prov Liner, Elevated, 44 EE x 28
00-8732-007-28	Prov Liner, Elevated, 46 FF x 28

### Continuum Neutral Liner Largest Head Core Set

#### Kit # KT-00-8791-003-99

Item Number	Description
00-8792-006-00	Neutral Provisional Liner Rack
00-8731-008-32	Prov Liner, Neutral, 48 GG x 32
00-8731-009-32	Prov Liner, Neutral, 50 HH x 32
00-8731-010-36	Prov Liner, Neutral, 52 II x 36
00-8731-011-36	Prov Liner, Neutral, 54 JJ x 36
00-8731-012-40	Prov Liner, Neutral, 56 KK x 40
00-8731-013-40	Prov Liner, Neutral, 58 LL x 40
00-8731-014-40	Prov Liner, Neutral, 60 MM x 40
00-8731-015-40	Prov Liner, Neutral, 62 NN x 40
00-8731-016-40	Prov Liner, Neutral, 64 OO x 40
00-8731-017-40	Prov Liner, Neutral, 66 PP x 40
00-8731-018-40	Prov Liner, Neutral, 68 QU x 40

### Continuum 28mm Neutral Prov. Liner Core Set

#### Kit # KT-8791-003-28

Item Number	Description
00-8792-007-00	Neutral Provisional Liner Rack
00-8731-008-28	Prov Liner, Neutral, 48 GG x 28
00-8731-009-28	Prov Liner, Neutral, 50 HH x 28
00-8731-010-28	Prov Liner, Neutral, 52 II x 28
00-8731-011-28	Prov Liner, Neutral, 54 JJ x 28
00-8731-012-28	Prov Liner, Neutral, 56 KK x 28
00-8731-013-28	Prov Liner, Neutral, 58 LL x 28
00-8731-014-28	Prov Liner, Neutral, 60 MM x 28
00-8731-015-28	Prov Liner, Neutral, 62 NN x 28
00-8731-016-28	Prov Liner, Neutral, 64 OO x 28
00-8731-017-28	Prov Liner, Neutral, 66 PP x 28
00-8731-018-28	Prov Liner, Neutral, 68 QU x 28

### Continuum 32mm Neutral Prov. Liner Core Set

#### Kit # KT-8791-003-32

Item Number	Description
00-8792-008-00	Neutral Provisional Liner Rack
00-8731-008-32	Prov Liner, Neutral, 48 GG x 32
00-8731-009-32	Prov Liner, Neutral, 50 HH x 32
00-8731-010-32	Prov Liner, Neutral, 52 II x 32
00-8731-011-32	Prov Liner, Neutral, 54 JJ x 32
00-8731-012-32	Prov Liner, Neutral, 56 KK x 32
00-8731-013-32	Prov Liner, Neutral, 58 LL x 32
00-8731-014-32	Prov Liner, Neutral, 60 MM x 32
00-8731-015-32	Prov Liner, Neutral, 62 NN x 32
00-8731-016-32	Prov Liner, Neutral, 64 OO x 32
00-8731-017-32	Prov Liner, Neutral, 66 PP x 32
00-8731-018-32	Prov Liner, Neutral, 68 QU x 32

### Continuum 36mm Neutral Prov. Liner Core Set

#### Kit # KT-8791-003-36

Item Number	Description
00-8792-009-00	Neutral Provisional Liner Rack
00-8731-010-36	Prov Liner, Neutral, 52 II x 36
00-8731-011-36	Prov Liner, Neutral, 54 JJ x 36
00-8731-012-36	Prov Liner, Neutral, 56 KK x 36
00-8731-013-36	Prov Liner, Neutral, 58 LL x 36
00-8731-014-36	Prov Liner, Neutral, 60 MM x 36
00-8731-015-36	Prov Liner, Neutral, 62 NN x 36
00-8731-016-36	Prov Liner, Neutral, 64 OO x 36
00-8731-017-36	Prov Liner, Neutral, 66 PP x 36
00-8731-018-36	Prov Liner, Neutral, 68 QU x 36

Continuum and Trilogy IT Systems use the same Core Provisional Instrument Kits.

\* Due to size constraints, these liners utilize a peg to align with the acetabular shell polar hole instead of the Provisional Screw.



## Provisional Kits with Independent Locking Screw

### Continuum 40mm Neutral Prov. Liner Core Set

#### Kit # KT-8791-003-40

Item Number	Description
00-8792-010-00	Neutral Provisional Liner Rack
00-8731-011-40	Prov Liner, Neutral, 54 JJ x 40*
00-8731-012-40	Prov Liner, Neutral, 56 KK x 40
00-8731-013-40	Prov Liner, Neutral, 58 LL x 40
00-8731-014-40	Prov Liner, Neutral, 60 MM x 40
00-8731-015-40	Prov Liner, Neutral, 62 NN x 40
00-8731-016-40	Prov Liner, Neutral, 64 OO x 40
00-8731-017-40	Prov Liner, Neutral, 66 PP x 40
00-8731-018-40	Prov Liner, Neutral, 68 QU x 40

### Continuum 28mm Elevated Rim Prov. Liner Core Set

#### Kit # KT-8792-003-28

Item Number	Description
00-8792-011-00	Elevated Provisional Liner Rack
00-8732-008-28	Prov Liner, Elevated, 48 GG x 28
00-8732-009-28	Prov Liner, Elevated, 50 HH x 28
00-8732-010-28	Prov Liner, Elevated, 52 II x 28
00-8732-011-28	Prov Liner, Elevated, 54 JJ x 28
00-8732-012-28	Prov Liner, Elevated, 56 KK x 28
00-8732-013-28	Prov Liner, Elevated, 58 LL x 28
00-8732-014-28	Prov Liner, Elevated, 60 MM x 28
00-8732-015-28	Prov Liner, Elevated, 62 NN x 28
00-8732-016-28	Prov Liner, Elevated, 64 OO x 28
00-8732-017-28	Prov Liner, Elevated, 66 PP x 28
00-8732-018-28	Prov Liner, Elevated, 68 QU x 28

### Continuum 32mm Elevated Rim Prov. Liner Core Set

#### Kit # KT-8792-003-32

Item Number	Description
00-8792-012-00	Elevated Provisional Liner Rack
00-8732-008-32	Prov Liner, Elevated, 48 GG x 32
00-8732-009-32	Prov Liner, Elevated, 50 HH x 32
00-8732-010-32	Prov Liner, Elevated, 52 II x 32
00-8732-011-32	Prov Liner, Elevated, 54 JJ x 32
00-8732-012-32	Prov Liner, Elevated, 56 KK x 32
00-8732-013-32	Prov Liner, Elevated, 58 LL x 32
00-8732-014-32	Prov Liner, Elevated, 60 MM x 32
00-8732-015-32	Prov Liner, Elevated, 62 NN x 32
00-8732-016-32	Prov Liner, Elevated, 64 OO x 32
00-8732-017-32	Prov Liner, Elevated, 66 PP x 32
00-8732-018-32	Prov Liner, Elevated, 68 QU x 32

### Continuum 36mm Elevated Rim Prov. Liner Core Set

#### Kit # KT-8792-003-36

Item Number	Description
00-8792-013-00	Elevated Provisional Liner Rack
00-8732-010-36	Prov Liner, Elevated, 52 II x 36
00-8732-011-36	Prov Liner, Elevated, 54 JJ x 36
00-8732-012-36	Prov Liner, Elevated, 56 KK x 36
00-8732-013-36	Prov Liner, Elevated, 58 LL x 36
00-8732-014-36	Prov Liner, Elevated, 60 MM x 36
00-8732-015-36	Prov Liner, Elevated, 62 NN x 36
00-8732-016-36	Prov Liner, Elevated, 64 OO x 36
00-8732-017-36	Prov Liner, Elevated, 66 PP x 36
00-8732-018-36	Prov Liner, Elevated, 68 QU x 36

Continuum and Trilogy IT Systems use the same Core Provisional Instrument Kits.

\*Due to size constraints, these liners utilize a peg to align with the acetabular shell polar hole instead of the Provisional Screw.

## Provisional Kits with Permanently Affixed Locking Screw

### Trilogy IT Micro Prov. Liners

Item Number	Description
00-8831-006-28	Prov Liner, Neutral, 44 EE x 28
00-8831-007-28	Prov Liner, Neutral, 46 FF x 28
00-8831-007-32	Prov Liner, Neutral, 46 FF x 32*
00-8832-006-28	Prov Liner, Elevated, 44 EE x 28
00-8832-007-28	Prov Liner, Elevated, 46 FF x 28

### Continuum Neutral Prov. Liner Largest Head Core Set

#### Kit # KT-8831-003-99

Item Number	Description
00-8792-006-00	Neutral Provisional Liner Rack
00-8831-008-32	Prov Liner, Neutral, 48 GG x 32
00-8831-009-32	Prov Liner, Neutral, 50 HH x 32
00-8831-010-36	Prov Liner, Neutral, 52 II x 36
00-8831-011-36	Prov Liner, Neutral, 54 JJ x 36
00-8831-012-40	Prov Liner, Neutral, 56 KK x 40
00-8831-013-40	Prov Liner, Neutral, 58 LL x 40
00-8831-014-40	Prov Liner, Neutral, 60 MM x 40
00-8831-015-40	Prov Liner, Neutral, 62 NN x 40
00-8831-016-40	Prov Liner, Neutral, 64 OO x 40
00-8831-017-40	Prov Liner, Neutral, 66 PP x 40
00-8831-018-40	Prov Liner, Neutral, 68 QU x 40

### Continuum 28mm Neutral Prov. Liner Core Set

#### Kit # KT-8831-003-28

Item Number	Description
00-8792-007-00	Neutral Provisional Liner Rack
00-8831-008-28	Prov Liner, Neutral, 48 GG x 28
00-8831-009-28	Prov Liner, Neutral, 50 HH x 28
00-8831-010-28	Prov Liner, Neutral, 52 II x 28
00-8831-011-28	Prov Liner, Neutral, 54 JJ x 28
00-8831-012-28	Prov Liner, Neutral, 56 KK x 28
00-8831-013-28	Prov Liner, Neutral, 58 LL x 28
00-8831-014-28	Prov Liner, Neutral, 60 MM x 28
00-8831-015-28	Prov Liner, Neutral, 62 NN x 28
00-8831-016-28	Prov Liner, Neutral, 64 OO x 28
00-8831-017-28	Prov Liner, Neutral, 66 PP x 28
00-8831-018-28	Prov Liner, Neutral, 68 QU x 28

### Continuum 32mm Neutral Prov. Liner Core Set

#### Kit # KT-8831-003-32

Item Number	Description
00-8792-008-00	Neutral Provisional Liner Rack
00-8831-008-32	Prov Liner, Neutral, 48 GG x 32
00-8831-009-32	Prov Liner, Neutral, 50 HH x 32
00-8831-010-32	Prov Liner, Neutral, 52 II x 32
00-8831-011-32	Prov Liner, Neutral, 54 JJ x 32
00-8831-012-32	Prov Liner, Neutral, 56 KK x 32
00-8831-013-32	Prov Liner, Neutral, 58 LL x 32
00-8831-014-32	Prov Liner, Neutral, 60 MM x 32
00-8831-015-32	Prov Liner, Neutral, 62 NN x 32
00-8831-016-32	Prov Liner, Neutral, 64 OO x 32
00-8831-017-32	Prov Liner, Neutral, 66 PP x 32
00-8831-018-32	Prov Liner, Neutral, 68 QU x 32

### Continuum 36mm Neutral Prov. Liner Core Set

#### Kit # KT-8831-003-36

Item Number	Description
00-8792-009-00	Neutral Provisional Liner Rack
00-8831-010-36	Prov Liner, Neutral, 52 II x 36
00-8831-011-36	Prov Liner, Neutral, 54 JJ x 36
00-8831-012-36	Prov Liner, Neutral, 56 KK x 36
00-8831-013-36	Prov Liner, Neutral, 58 LL x 36
00-8831-014-36	Prov Liner, Neutral, 60 MM x 36
00-8831-015-36	Prov Liner, Neutral, 62 NN x 36
00-8831-016-36	Prov Liner, Neutral, 64 OO x 36
00-8831-017-36	Prov Liner, Neutral, 66 PP x 36
00-8831-018-36	Prov Liner, Neutral, 68 QU x 36

Continuum and Trilogy IT Systems use the same Core Provisional Instrument Kits.

\* Due to size constraints, these liners utilize a peg to align with the acetabular shell polar hole instead of the Provisional Screw.

## Provisional Kits with Permanently Affixed Locking Screw

### Continuum 40mm Neutral Prov. Liner Core Set

#### Kit # KT-8831-003-40

Item Number	Description
00-8792-010-00	Neutral Provisional Liner Rack
00-8831-011-40	Prov Liner, Neutral, 54 JJ x 40*
00-8831-012-40	Prov Liner, Neutral, 56 KK x 40
00-8831-013-40	Prov Liner, Neutral, 58 LL x 40
00-8831-014-40	Prov Liner, Neutral, 60 MM x 40
00-8831-015-40	Prov Liner, Neutral, 62 NN x 40
00-8831-016-40	Prov Liner, Neutral, 64 OO x 40
00-8831-017-40	Prov Liner, Neutral, 66 PP x 40
00-8831-018-40	Prov Liner, Neutral, 68 QU x 40

### Continuum 28mm Elevated Prov. Liner Core Set

#### Kit # KT-8832-003-28

Item Number	Description
00-8792-011-00	Elevated Provisional Liner Rack
00-8832-008-28	Prov Liner, Elevated, 48 GG x 28
00-8832-009-28	Prov Liner, Elevated, 50 HH x 28
00-8832-010-28	Prov Liner, Elevated, 52 II x 28
00-8832-011-28	Prov Liner, Elevated, 54 JJ x 28
00-8832-012-28	Prov Liner, Elevated, 56 KK x 28
00-8832-013-28	Prov Liner, Elevated, 58 LL x 28
00-8832-014-28	Prov Liner, Elevated, 60 MM x 28
00-8832-015-28	Prov Liner, Elevated, 62 NN x 28
00-8832-016-28	Prov Liner, Elevated, 64 OO x 28
00-8832-017-28	Prov Liner, Elevated, 66 PP x 28
00-8832-018-28	Prov Liner, Elevated, 68 QU x 28

### Continuum 32mm Elevated Prov. Liner Core Set

#### Kit # KT-8832-003-32

Item Number	Description
00-8792-012-00	Elevated Provisional Liner Rack
00-8832-008-32	Prov Liner, Elevated, 48 GG x 32
00-8832-009-32	Prov Liner, Elevated, 50 HH x 32
00-8832-010-32	Prov Liner, Elevated, 52 II x 32
00-8832-011-32	Prov Liner, Elevated, 54 JJ x 32
00-8832-012-32	Prov Liner, Elevated, 56 KK x 32
00-8832-013-32	Prov Liner, Elevated, 58 LL x 32
00-8832-014-32	Prov Liner, Elevated, 60 MM x 32
00-8832-015-32	Prov Liner, Elevated, 62 NN x 32
00-8832-016-32	Prov Liner, Elevated, 64 OO x 32
00-8832-017-32	Prov Liner, Elevated, 66 PP x 32
00-8832-018-32	Prov Liner, Elevated, 68 QU x 32

### Continuum 36mm Elevated Prov. Liner Core Set

#### Kit # KT-8832-003-36

Item Number	Description
00-8792-013-00	Elevated Provisional Liner Rack
00-8832-010-36	Prov Liner, Elevated, 52 II x 36
00-8832-011-36	Prov Liner, Elevated, 54 JJ x 36
00-8832-012-36	Prov Liner, Elevated, 56 KK x 36
00-8832-013-36	Prov Liner, Elevated, 58 LL x 36
00-8832-014-36	Prov Liner, Elevated, 60 MM x 36
00-8832-015-36	Prov Liner, Elevated, 62 NN x 36
00-8832-016-36	Prov Liner, Elevated, 64 OO x 36
00-8832-017-36	Prov Liner, Elevated, 66 PP x 36
00-8832-018-36	Prov Liner, Elevated, 68 QU x 36



Continuum and Trilogy IT Systems use the same Core Provisional Instrument Kits.

\* Due to size constraints, these liners utilize a peg to align with the acetabular shell polar hole instead of the Provisional Screw.

### Vivacit-E Vitamin E Polyethylene and Longevity Polyethylene Liner Thickness Chart

Shell Size	Head Size	Pole (mm)	45° (mm)	Chamfer (mm)
<b>22mm Elevated Liners</b>				
40CC	22	5.3	5.6	4.1
42DD	22	6.2	6.8	4.3
<b>28mm Neutral and Elevated Liners</b>				
44EE	28	4.3	5.3	3.0
46FF	28	5.4	5.7	3.7
48 GG	28	6.4	6.7	4.9
50 HH	28	7.3	7.7	5.7
52 II	28	8.4	8.7	6.9
54 JJ	28	9.3	9.7	7.9
56 KK	28	10.3	10.7	8.9
58 LL	28	11.4	11.7	9.9
60 MM	28	12.3	12.7	10.9
62 NN	28	13.3	13.7	12.1
64 OO	28	14.4	14.7	13.1
66 PP	28	15.3	15.7	14.1
68 QU	28	16.4	16.7	15.1
<b>32mm Neutral and Elevated Liners</b>				
48 GG	32	4.3	4.7	2.9
50 HH	32	5.3	5.7	3.7
52 II	32	6.4	6.7	4.9
54 JJ	32	7.3	7.7	5.9
56 KK	32	8.3	8.7	6.9
58 LL	32	9.3	9.7	7.9
60 MM	32	10.3	10.7	8.9
62 NN	32	11.3	11.7	10.1
64 OO	32	12.3	12.7	11.1
66 PP	32	13.3	13.7	12.1
68 QU	32	14.4	14.7	13.1
70 RR	32	15.3	15.7	14.1
72 SS	32	16.3	16.7	15.1
74 TT	32	17.3	17.7	16.1
76 UU	32	18.3	18.7	17.0
78/80 VV	32	19.3	19.7	18.0

Shell Size	Head Size	Pole (mm)	45° (mm)	Chamfer (mm)
<b>36mm Neutral and Elevated Liners</b>				
52 II	36	4.4	4.7	2.9
54 JJ	36	5.3	5.7	3.9
56 KK	36	6.3	6.7	4.9
58 LL	36	7.4	7.7	5.9
60 MM	36	8.3	8.7	6.9
62 NN	36	9.3	9.7	8.1
64 OO	36	10.4	10.7	9.1
66 PP	36	11.3	11.7	10.1
68 QU	36	12.4	12.7	11.1
70 RR	36	13.3	13.7	12.1
72 SS	36	14.3	14.7	13.1
74 TT	36	15.4	15.7	14.0
76 UU	36	16.3	16.7	15.0
78/80 VV	36	17.3	17.7	16.0
<b>40mm Neutral Liners</b>				
56 KK	40	4.3	4.7	2.9
58 LL	40	5.3	5.7	3.9
60 MM	40	6.3	6.7	4.9
62 NN	40	7.3	7.7	6.1
64 OO	40	8.3	8.7	7.1
66 PP	40	9.3	9.7	8.1
68 QU	40	10.4	10.7	9.1
70 RR	40	11.3	11.7	10.1
72 SS	40	12.3	12.7	11.0
74 TT	40	13.3	13.7	12.0
76 UU	40	14.3	14.7	13.0
78/80 VV	40	15.3	15.7	14.0









\* *BIOLOX*<sup>®</sup> is a trademark of CeramTec GmbH

This documentation is intended exclusively for physicians and is not intended for laypersons. Information on the products and procedures contained in this document is of a general nature and does not represent and does not constitute medical advice or recommendations. Because this information does not purport to constitute any diagnostic or therapeutic statement with regard to any individual medical case, each patient must be examined and advised individually, and this document does not replace the need for such examination and/or advice in whole or in part. Please refer to the package inserts for important product information, including, but not limited to, contraindications, warnings, precautions, and adverse effects.



Contact your Zimmer representative or visit us at [www.zimmer.com](http://www.zimmer.com)

The CE mark is valid only if it is also printed on the product label.

